

BlueDAQ Software Manual



Notes on this guide

- Colored texts indicate buttons of the program-
Otherwise, italic text generally means designations in the program-
Further information is partly in small print-

The first part "Quick Start Guide" is an introduction. In the second part, "Planning and Managing Measurement Tasks", recommendations and important information are given, while in the third part, "Advanced Functions", extensive possibilities are presented; however, knowledge of these is not absolutely necessary for the basic use of the program.

Table of contents

Notes on this guide.....	1
Quick Start Guide BlueDAQ	5
Connecting the Amplifier	5
Index card Configuration	6
Input Type	7
Scaling	8
Recorder Yt.....	9
Load and save measurement job.....	11
Graphic display Graph Display	12
Large display Value Display	12
Display of recorded measurement data	13
Further help and sources of information	13
Blanket Software Notes.....	13
Scheduling and Managing Measurement Tasks.....	14
Channels	14
Types of Devices and Measurement Channels	15
Load and save measurement session.....	15
Master-slave synchronization with multiple amplifiers	16
Remove channels or devices.....	18
Selection of the measurement data rate.....	18
Analysis of noise and signal-to-noise ratio	20
Reducing out noise around zero (Noise Cut).....	24
Manage device settings data	25
Assign and name device setting data for the BSC2.....	26
Restoring Device Settings Files from a Settings Archive	28
Porting the device settings on the BSCD8.....	28
Porting the session file to another PC.....	29
Protect device settings from modification	30
Observation and evaluation of live data during the measurement period	31
Numerical display in the Recorder Yt and XY	32
Configuring the Time Duration of the Acquisition Interval.....	34
Decimal Places of Numerical Readings.....	35

Recording and viewing of measurement data and subsequent evaluation	35
Configuration of data logger devices	36
Accessing the recorded measurement data of the data loggers	40
Additional features	42
Integration of multi-axis sensors	42
More information on the multi-axis sensor-Dialog	45
Notes on sensor modes:	45
Changing the Sensor Configuration and Using Multiple Multi-Axis Sensors	47
Other display and control elements in the Multi-Axis Sensor Window	48
Measuring with strain gages	48
Stress measurement with rosette strain gages	49
Switching between stress and strain measurement	51
Sensors with TEDS	53
The TEDS usage -> Sensor Info	53
Configuring TEDS Device Behavior	54
Reading and viewing TEDS content	55
Editing and writing TEDS data	57
Adjustment of sensors with of a known load	58
Startup	60
XY Recorder	61
Software Options for XY Recorder	62
Configuring the recording of measurement data	62
Automatically start and stop recording	63
Launch	63
Termination Condition	64
Using Automatic Recording	66
Additional Configuration Options for Data Recording	67
Index card Save Memory Data	67
Index card Data Reduction	67
Index card Auto export	68
Index card Advanced	69
Formatting the file name	71
Using the File Monitor	72
Using the cursor	75
Editing and exporting measured values	77
Exporting to other file formats	77
to the clipboard	78
Copy and paste at measurement time	80
Copying Metrics to the Clipboard	80
Inserting a measured value text into other programs using the F key	80
The Formatting String Output Format	83
Insertion of a measured value text into other programs via trigger	83
Edit Thresholds	84
Notes (Annotations) in measurement files	86
Setting Notes While Recording a Measurement	86
Setting Notes in the File Monitor	89

Offset and Zero Point.....	89
Limitations of Zeroing.....	90
Restricting Zeroing for Single Channels.....	91
Memory behavior of the zero point on the BX6.....	92
Auto-zero (Auto-Zero).....	92
Analog and digital filters.....	95
Analog Filters.....	95
Digital Filters.....	96
FIR Filter.....	96
IIR Filter.....	98
Filter Configuration and Simulation with BX6 and BX8.....	99
Communication Interfaces and Measurement Data Frames.....	101
Bitrate/Baud Rate, On/Off.....	102
Permanent measurement data transmission.....	104
CAN and CANopen settings.....	105
CRC on BX6 and BX8.....	105
Data Frame: Channel number and data type.....	106
Data type for BSC2 and BSC1.....	106
Formatting of the measured value text display.....	107
Data type for BX6 and BX8.....	107
Number of channels in the measurement data frame.....	108
Data Frame and Measurement Data Rate.....	109
Bluetooth settings on the BX6BT.....	109
Device behavior when the Bluetooth connection is closed.....	110
Other BT Settings Displays and Controls.....	111
Transfer of the maximum or minimum value.....	111
Definable measured value text for embedding other Devices.....	112
Automatic resumption in case of loss of communication connection.....	115
Digital inputs/outputs and threshold switches.....	116
Threshold switch.....	119
Active/inactive level, inversion.....	122
Default Digital Output Level.....	122
Analog output on the BX8.....	123
Analog Output Mode.....	125
Analog output of software channels.....	126
Counters and Frequency Measurement with BX6BT and BX8.....	127
Meter Measurement.....	129
Frequency / RPM / Speed by Count.....	130
Frequency / speed / velocity by period duration measurement.....	130
BX8: Frequency / Speed Measurement with Auto-Period Mode.....	131
Examples of working with User Scale To adapt to specific encoders.....	131
Learn more about device administration.....	132
Fault memory of the BX8.....	132
Hour meter of the BX8 and BX6BT.....	134
BSC2 Menu Language.....	134
Drift compensation with BSC2.....	134

Other Software-Preferences.....	136
Tools for Measurement Data Files <i>TDMS Tools</i>	138
Assemble master-slave files from BX6BT	138
Problem treatment	140
1. The device cannot be connected in <i>Add Channel</i> to be opened	140
2. There are no readings.....	142
3. The measured values run slowly and jerkily in the graphical display	142
4. When using multiple strain gage amplifiers, the readings are divergent in time.	143
5. Deleting data from a graphical chart	144
6. Attempting to change a configuration setting in multiple strain gage amplifier fails	144
7. The readings are not within the expected range	145
8. The readings are unstable	145
9. Problems with data evaluation with TDMS files	146
Appendix A: Hotkeys	147
Appendix B: TDMS Properties.....	148

Quick Start Guide BlueDAQ

BlueDAQ (long form: BlueDAQchannel) is an application program for displaying and recording measurement data and for configuring digital amplifiers. The following models are supported: BX8, BX6, BSC4D, BSC1, BSC2 and BSC8D. One or more strain amplifiers can be used at the same time, so that up to 127 measurement channels can be displayed and processed.

Connecting the Amplifier


After starting the BlueDAQ software, the functions

Add Channel, **Open Session** and **File Monitor** are available.

Add Channel opens the dialog for entering the connection data to open a strain gage amplifier or additional channels of a device.

Please select the device model with device *type*, the *COMport number*¹ and the desired input channel(s).

Repeat **Add Channel** until you have all the channels and devices you want.




Tips: For devices with multiple input channels, Open all *input channels* allow you to open all available inputs from this amplifier. The default setting of the communication bit rate (bits/s) is automatically pre-selected based on the device model. If this is different, it must be set correctly.

¹In the BSC8D, BX3-HD44-CON, and the BX6-ETH/CAN it is a device number; here the *communication interface* is set or set accordingly.

Configuration tab

In this tab, navigate to the desired channels by selecting Actual Channel in the upper right corner. The names of the channels, e.g. "Chan. 3_1" you can overwrite Channel name with your own name in the text field and finish typing with Enter. Alternatively, you can do this from the menu bar with *channel > name*.



With the four buttons in the center, you define the essential properties of the sensor on the currently selected channel:

Set Zero: Performs a zero adjustment of the sensor. The button in yellow-orange color indicates that this setting is stored in the memory of the amplifier/sensor.

Note for temperature and voltage inputs: By default, the software prohibits zeroing of temperature and voltage inputs. This can be changed in Menubar→Options, see S.85.

User Scaling: This opens a window for entering the scale or calibration data for the sensor. As a rule, this setting must be made once during commissioning, see S. 8. Before changing the scale, the **Input Type** should be set, if it is not already set correctly.

Data Frequency: This is where the number of measured values sent via the interface per second is entered. Please select the frequency required for the measurement task. For multi-channel devices, it is automatically the same for all input channels.

For multi-channel devices, it means the number of whole data frames with input channels, i.e. the total number of all measured values of all channels = **Data Frequency** x Input Channels. The lower the frequency, the lower the noise, i.e. the better the effective measurement resolution, s.p. 16.

Input Type: Here the input type and the electrical measuring range are selected, see S. 7. This step is usually performed first to configure a new sensor.


Load Settings can be used to restore the factory settings (*default*) of the amplifier or those that have previously been stored by the user in the memory of the device with **Save Settings** (Users 1-6, *if available for the device model*).

Input Type

The **Input Type** button opens the dialog for setting the electrical input range for the selected channel; if necessary, different physical input types can be selected. The adjustment options depend on the model of the connected amplifier; In the following, they are shown as examples of the BX8.

Three measuring ranges of 2.0 mV/V, 3.5 mV/V and 7.0 mV/V are available for sensors with strain gages. The three measuring ranges of the BX8 are connected to three permanently assigned bridge supply voltages.

- 2 mV/V: 8.75 V (Note: This supply voltage is not recommended for some sensors; see the sensor data sheet for more information).
- 3.5 mV/V: 5.0 V
- 7 mV/V: 2.5 V



The selected measurement range should be greater than or equal to the electrical output range of the sensor, i.e. greater than its characteristic value at its nominal value.

Tip: For some amplifiers, e.g. BSC4D and BX8, temperature sensors or single-ended voltage inputs can also be selected. Other types of sensors almost always need to be connected to other ports on the device, and other cables may need to be used. The operating instructions of the devices provide information on this.

The definition of the bridge type (full, half or quarter bridge) for strain gages is also done via the hardware of the multiple strain gage amplifier, for example via other connections or switches/jumpers. See its instruction manual and S.45

Note: If the input type is changed, the scaling (*user scaling*) is usually automatically reset, so that a previous sensor configuration may be overwritten! This is done so that the strain gage amplifier

displays the new electrical input variable (or temperature) correctly. The scaling may then need to be readjusted for a specific sensor.


Scaling

The **User Scaling** button opens the dialog for entering or calculating the scaling factor with which sensors are adjusted.

The scaling factor is calculated from:

- The measuring range of the sensor (*Physical Full Scale*)
- The output signal change of the sensor at this 100% load (*Electrical Full-Scale output*). This usually corresponds to the characteristic value specified in the test protocol of the sensor.
- The physical measuring range of the amplifier (*input range*). This is usually read automatically by the software.

The choice of unit does not affect the result; it is merely a label. Enter the *Physical full scale* of the sensor accordingly.



Enter the values and then press **Calculate** and then **OK / Set** to save the scale in the amplifier. The value will then appear in the *Configuration* tab next to *User Scaling* under *Range*. It corresponds to the full electrical input range, but usually not to that of the sensor, which is usually smaller.

Tip: If you connect sensors with TEDS, you don't need to enter the scale because it is set automatically. See p. 49

Recorder Yt


In the **Recorder Yt** tab, the measured values are displayed graphically in real time over the current time.

Use "Start Measuring" or "**Stop Measuring**" to start or stop the graphical display. **Start Recording**, **Stop Recording**, to start or stop recording measurement data to a file.

The displayed index card may be changed at any time, even during a measurement or recording, which is not affected by it.

Set All Zero performs zeroing for all channels. Note that the **Set Zero** button may be disabled for individual channels, e.g. for force/torque sensors or for other calculated channels. Then **Set All Zero** should be used.

Right-clicking on the graphic opens the context menu for various settings, such as: **Autoscale**.




If **Autoscale Y** is disabled, you can click on the minimum and maximum values of the y-axis and change them by changing the full scale values and pressing Enter.

You can set the temporally visible range with **Time Visible**.

Under **Display** There is a selection of options for the display of the numerical measured values with a turquoise background, the so-called "Numerical Values". **Single Value Display**:

For example, by **Max-Min** the noise amplitude or by **Resol Parts PP** a quality number "measuring range / noise amplitude" can be displayed, see p.18.



With the button **Configure Recording** , the properties for the recording of measured values, e.g. start and stop conditions as software triggers, can be defined. See p. 58.

With the Add **Graph Window** button you can open more graphic windows, e.g. to display forces and moments in different windows with their own graphical scaling or to perform a spectral analysis (FFT).


Load and save measurement job

All settings regarding the graphics window and naming of channels, as well as interface numbers etc. can be saved in a session **file of type *.ucf when leaving the program or with the help of the Save Session** button, and can be restored by Open Session or by double-clicking on the ucf file before starting the program. No amplifier settings are stored in this file.

When restoring the channels, all saved channels of all devices are opened and other settings are also loaded, see S. 14.

Graphic Display Graph Display


The *Graph Display* tab provides graphical displays over time for each channel.



The right-click menu offers similar capabilities as in Yt Recorder. Up to 16 channels can be displayed here.

Large Value Display

Below this index card, a large numerical display of all channels is available.



Display of recorded measurement data

With **File Monitor** in the index card *Configuration* a file selection window opens, in which the last file with **Start Recording** is pre-selected. After confirming with OK, the display window

for measurement data files opens. They can be displayed graphically or as a table of values and with **Export** can also be converted to other formats such as Excel or CSV. With the mouse scroll wheel or the zoom options of the graphics palette, the display can be enlarged, reduced or moved, and cursors for various functions can also be displayed; see p.67

Further help and sources of information

- Context Help can be opened under the menu bar → **Help** → **Show Context Help**. This is a small help window that displays information for each control when you hover over it.
- On the Internet, on the website me-systeme.de there is more information
- For some special functions, e.g. **MathScript/MathChannel** (only for PRO version) has its own instructions
- The operating instructions of the amplifiers used should be read during initial commissioning

General Information About the Software

- *Buttons or other controls that cause settings to be saved in the device are highlighted in yellow.*
- *When operating functions that require multiple inputs within a dialog box, the operating order is usually from top to bottom and/or from left to right.*
- *All buttons and other input elements of the main window are also accessible via the menu bar at the top. This does not apply the other way around, i.e. there are also functions or dialog boxes that can only be accessed via the menu bar.*
- *For many functions, the menu bar also mentions keyboard shortcuts (so-called hotkeys) that also trigger this function. If it is noted here: Ctrl+<key>, press and hold the Ctrl key (control) first, while then pressing <key>, e.g. Ctrl+PageUp: First hold down Ctrl, then scroll up: Enlarge the displayed channel in Configuration.*

Scheduling and Managing Measurement Tasks

Before carrying out a measurement, it is useful to clarify the following questions:

- Which sensors and measurement channels are needed?
- Which measurement data rate should be chosen?
- Should the evaluation only take place during the measurement runtime, i.e. as a live view in real time, or should the measurement be recorded first and evaluated later?

Especially in the case of measurements with important results or those that are time-consuming to perform, it is recommended to carry out one or more test measurements

after planning and configuring the measurement system. If possible, this should be done with the same device, and sensor copies in the same place and on the same PC where the actual measurement is to take place.

Channels

A measurement channel represents a physical quantity that is usually converted by sensors into electrical quantities that the amplifier captures and digitizes. In this process, the analog values are converted into numbers with a fixed number of measured values per second, the measurement data rate (data *frequency*). The BSC2 and BSC1 amplifiers have only one measurement channel; for all others, the input to which the measurement channel belongs, as well as the device name, are displayed next to *Input in the* upper right corner of the *Configuration* tab. The device serial number appears next to *Device Serial No.*

The channel number that you see next to *Actual Channel* is determined by the order in which the channels were added by *Add Channel* and is usually freely selectable. An exception to this is *MathChannels*, which represent calculated software channels and are added to channels according to the hardware, or are automatically sorted accordingly, as ² well as counter channels, see below.

It is convenient to give the measurement channels descriptive names. You can do this by changing the name directly in the *Channel Name* display field and then pressing the Enter key or by clicking on the menu bar → *channel* → *name...* click.


When the channels are added, up to 32 different colors are automatically assigned. You can change them in *the Add Channel* dialog at the bottom left or later with the menu bar → *Channel* → *Color...*

This color is also used to display the channel name under *Channel Name* in the *configuration* tab, and graphs of recorded measurement data files are also displayed in the *File Monitor* with this color.

Types of Devices and Measurement Channels

In the free version of BlueDAQ there are currently two basic types of channels: analogue channels and counter input channels. The BSCD8, BX6BT and BX8 amplifiers provide counter inputs that can be used to count digital pulses or measure frequency. A counter channel can be added after at least one analog channel of the same device has already been added. To do this, select *Function = Digital Counter* in the *Add Channel dialog on the right*.

²Calculated channels (*MathChannels*) are only available with BlueDAQ PRO. This function is described in a separate manual.



For the BX8 and BX6BT, the meter must be activated and configured once, see p. 120. Scaling can also be used for meter inputs with *User Scaling* (but not calculated by every method).

In addition to the device or COM port number and input channel, the channel type also determines the default channel name.

BlueDAQ PRO offers additional special channels, which are created by opening the following devices (*device type*):

- **GPS / GNSS** for satellite-based positioning: *Latitude*, *Longitude*, *Altitude*, *Speed* and *UTC time*
- **Math Script**: Math Channels Calculated by Custom Script
- **User Device**: Devices from other manufacturers that send measured values as a text string via a serial interface, see 105.

These special channels have only limited configuration options; only the channel name, unit and color can be changed.

Load and save measurement session

The channel list can be saved with **Save Session**. You can then restore them at any time, even after restarting BlueDAQ, with **Open Session**. This file also contains information about how the integrated devices are opened (COMport number, baud rate, input channel) and how they are displayed (channel name, color) and, in the case of special channels, also the unit and, if necessary, settings via special functions. With **Open Session**, the embedded channels are opened, and the display properties are restored.

By double-clicking on the session file (e.g. in Windows Explorer) BlueDAQ can be started and then this session will be opened automatically.

The session file does not contain the configuration data of the amplifiers (i.e. those that are stored with yellow buttons in the device). Instead, amplifier settings can be saved to a file using **Save Settings** → Save to *file* and restored → **Load from File using** Load Settings.

A backup with all settings files of all integrated amplifiers, including the session file, can be created using the menu bar → **Help** → **Create Settings Archive**. It is a ZIP archive that contains these files.

Master-slave synchronization with multiple amplifiers

If more than one strain gage amplifier device is integrated and the measurement data rates are relatively high or the recording time is rather long, it makes sense that the amplifiers are synchronized. Otherwise, due to the asynchronous data transmission, temporal errors can accumulate (i.e. magnify), so that after a certain time after the start of the measurement, the measured values of the different devices no longer coincide in time.




With master-slave synchronization, the time of transmission of a measurement data frame is adjusted via the serial ports of all devices (i.e. also via USB, Bluetooth, Ethernet).

It is a hardware feature that can be enabled on BSC4D, BX6BT/CPU and BX8 devices (available as an order option on BSC1USBx2). In this case, a line must connect certain digital I/O connections of the devices with each other, i.e. a digital I/O port and (D)GND must be connected to the devices by cable. Exactly one of the devices is configured as the master and this generates a digital synchronization signal, namely a rectangle with the frequency of the set data rate. At one of the edges (usually rising, i.e. low→high) the master also transmits its measurement data frame, and the slaves recognize this edge and also send their measurement data frames.


If the master-slave function is activated for all connected strain gage amplifiers, BlueDAQ will apply a sync sequence when clicking on **Start Measuring**; in which the transmission is temporarily stopped, the data buffers are deleted and the master is then started, so that all devices start sending measurement data at the same time.

The prerequisite is that synchronization is activated in the program options and that all connected devices support master-slave, are properly wired (see above) and configured (see below). In the software settings, under the menu bar → **Options** → **Hardware** -> **Master / Slave synchronization, if available**, must be set to **Synchronization**, which is the case in the default settings.

Master-slave synchronization is configured and verified in the strain gage amplifiers in the following ways : In the **Configuration** with **Actual Channel** tab, select a channel that belongs to the device you want to configure or verify. Then click on Device in the menu bar and select **Advanced Settings...** In this dialog, the master-slave mode is displayed in the **Value Mode** tab:



Tx-Sync. Slave Mode Enabled




Without Tx-Sync.

This indicator is only available on BSC1, BX6 and BX8.

Master or slave mode is activated in the **Digital I/O tab** in the **Advanced device Settings**. To do this, use the **I/O number** to select the digital I/O port to which the synchronization line is to be connected. Usually (and if this cable was purchased pre-assembled from Interface) these are the following:

- BX8: **I/O number** 16 for master and for slave
- BX6: **I/O number** 1, 2 or 3 for master and 4 (TRIG) for slave

- BSC4D: any from 1 to 8 for master and for slave



In this case, it is best to put the slave into its mode first, in order to avoid accidentally connecting two outputs (master) through the connected sync cable, because this would be tantamount to a short circuit. To do this, select **Sync. Slave** with **I/O type** off. Then **Store to device**.

Then configure the master by setting this **I/O type** to **Sync. Master** 's degree.


With the BX8, you may receive an intermediate message warning that all I/Os 13-16 (i.e. those of the group of four to which the selected I/O belongs) will be switched as input or output. This must be confirmed; if these three other

I/Os are intended for an incompatible function, other I/Os may need to be used.

If a slave device does not receive a synchronization signal, e.g. because the cable is not connected or the master is turned off, it does not send any readings, so that **timeout will appear** in the reading display of the **configuration** tab.

Remove channels or devices

In **Configuration** the channel displayed on the tab can be viewed with **Remove Channel** to be removed. If you want to remove one or more hidden channels, you will first have to remove all hidden channels with the menu bar -> **Channel** -> **Unhide All** be brought out. Hidden channels were previously used with **Channel** > **Hide** hidden, e.g. because they are only needed as the input value of a calculation, but should not be displayed, see e.g. S. 42



To remove all channels belonging to a particular device, you can click on Menu Bar->Device->Close. If several devices are open, a dialog will appear in which you select the device to be removed with **Remove on the right** and then confirm with **OK**. Then all channels of this device, whose name (**model**), comport and serial number (**Serial No**) are displayed on the left, will be removed, including hidden channels.

Selection of the measurement data rate

The data **frequency** is the number of measured values (samples) that the amplifiers take and transmit per second and per channel. If several amplifiers are used, it should be set as much as possible in the same way for all devices; otherwise, you may receive a warning message when you click on **Start Measuring**. The measurement data rate of multi-channel amplifiers is always the same for all measurement channels and it is to be understood as a single sample rate, i.e. per channel (i.e. multiplied by the number of input channels results in the sum sample rate).

To change it, activate *a channel belonging to the amplifier with Actual Channel* and click *Data Frequency*, which opens the *Change Data Rate* dialog. After successful modification, the same measurement data rate is displayed for all its channels.

The range of values of the measurement data rate depends on the amplifier model and is displayed in the *Change Data Rate* dialog under *minimum* and *maximum*:

For many device models, the maximum also depends on other settings and configurations. If the serial UART or RS232 interface is enabled, this maximum is strongly dependent on the communication bit rate, for example, s. S.99

It is not possible to set all measurement data rates continuously. It is therefore possible that the data rate closest to the desired value is set; this is especially true for the BSC4D, BX6 and BX8 models, especially at high values. The operating instructions of the devices provide more detailed information on this.

Which measurement data rate is chosen depends on the measurement task. It should always be as low as possible, but sufficiently large if even short changes such as peaks or vibrations are to be recorded.

High measurement data rates (i.e. those above 50/s, depending on the application) and low data rates have the following advantages and disadvantages:

	High data rate	Low data rate
Advantages	Rapid changes are recorded, e.g. peaks, oscillations	Lower noise, i.e. better effective amplitude resolution
	Good frequency representation possible with FFT	Smaller files for data recording
	High temporal resolution	Reduced load on the PC
	In some cases, there is less time delay (latency) between signal change and measured value change ³	Better suppression of disturbances, e.g. electromagnetic
Disadvantages	Higher noise, i.e. poorer amplitude resolution	Rapid changes in the measurement signal are not detected
	Large files during data recording, resulting in slower file processing and more complex evaluation	Frequency representation (FFT) not very meaningful
	Increased utilization of the PC	The portion of latency that depends on the data rate is longer

³There is a constant fraction t_k of this delay time and one dependent on the data rate, so the total latency = $t_k + t(Fdata)$.

Each amplifier has a maximum frequency of measurable signals, i.e. a limited bandwidth, so it always acts as a low-pass filter. In the case of digital amplifiers, this bandwidth is determined, among other things, by the measurement data rate; it is typically about 0.3 to 0.4 x measurement data rate. However, the bandwidth can be even lower, e.g. due to analogue pre-filters. The larger the bandwidth, the higher the noise, i.e. the dynamic, normally distributed portion of the measurement uncertainty increases with the bandwidth.

How much greater the noise is at a higher data rate also depends on the amplifier and the strength of external interference sources. Most amplifiers operate internally at a higher sampling frequency, which they then reduce by averaging or decimating digital filters. To compare the signal-to-noise ratio change when comparing two data frequencies f_1 and f_2 , with $f_1 > f_2$, the following is a rough rule of thumb:

$$R(f_1) \approx R(f_2) \times \sqrt{f_1/f_2}$$

Example: At the measurement data rate $f_1 = 1000/\text{s}$, the self-noise $R(f_1)$ is about 10 times greater than at $f_2 = 10/\text{s}$, because $\sqrt{(1000/10)} = 10$. Self-noise only includes the noise generated by the amplifier itself without external sources of interference.

Analysis of noise and signal-to-noise ratio

In many applications, it is possible to find out the most suitable measurement data rate through test measurements. It is advisable to start with a rather high data rate. As a result, external sources of interference can also be detected, especially if the test measurement takes place at the same location, in the same environment, for example with machines switched on nearby, as during the actual measurement.

For example, you can start with half (or more) of the maximum adjustable data rate.

Then leave the sensor alone for the time being, i.e. avoid changing the useful signal. Now you can determine the signal-to-noise ratio and, if necessary, find interference frequencies.



To do this, start a measurement and select one of the following settings using the Display pull-down selection element :

Selection	Description	Unit	Internal calculation
SNR [dB]	Signal-to-noise ratio: Signal-to-noise ratio Short peaks are smoothed out! It is related to the input measuring range, the average value is subtracted and the result is converted into decibels.	Db	
Resol. Parts pp	Resolution in Parts pp: Relative peak resolution relative to the input measurement range	none	
Max-Min	Absolute peak resolution in the unit of physical quantity.	such as measurand	Maximum - Minimum
RMS/StDev	Root-Mean-Square / Standard Deviation in the Unit of Physical Quantity. In the process, short peaks are smoothed out!	such as measurand	

Range is the measuring range of the amplifier input, as it is usually displayed in the **Configuration** tab. \bar{x} are all measured values of the sample, Max is the maximum value, and Min is the minimum value of the sample. The sample is recorded via $N=100$ values or over one second, i.e. at a measurement data rate $> 100/s$, $N = \text{measurement data rate}$.

The result is displayed in the turquoise green field on the right. By selecting **SNR [dB]** or **Resol. Parts pp**, the noise can be judged independently of the measuring range. Interface

usually specifies the peak value resolution for amplifiers (**Resol. Parts pp**), other manufacturers often only use the signal-to-noise ratio SNR.


If a sensor is already connected and adjusted, **Max-Min** can be used to check peak noise and **RMS/StDev** can be used to check standard deviation, both in physical units.

The following table shows typical noise levels of a BX8. External interference has been eliminated here.

Fdata [Hz]	Input	SNR[dB]	RMS [nV/V]	NoisePP [parts]	NoisePP [nV/V]
10	2 mV/V	119	2,24	100000	20
10	3.5 mV/V	113	7,84	100000	35
10	7 mV/V	115	12,45	100000	35
1000	2 mV/V	103	14,16	24000	83,33
1000	3.5 mV/V	103	24,78	24000	145,83
1000	7 mV/V	103	49,56	24000	291,67
12000	2 mV/V	94	39,91	6500	307,69
12000	3.5 mV/V	94	69,83	6500	538,46
12000	7 mV/V	94	139,67	6500	1076,92

In the specification SNR and RMS, you get better values for the same test measurement, because short peaks are averaged away.


The illustration of the **Recorder Yt** above shows a test shot with a BX8 at a measurement data rate of 6000/s of a sensor with a measuring range of 2500 N. The absolute peak resolution **Max-Min** is therefore 0.89 N. The graph already shows a clear interference signal in the time domain. To find out the cause, a spectral analysis is often very helpful. To do this, click on **Add Graph Window** and first of all the configuration dialog for this additional




graphical display opens. Set **Diagram Type** to **FFT**, click **Add Plot** and then select **the channel with Select Channel for actual plot**. An FFT window can only

display one channel at a time, but you can open up to 6 Graph Windows at a time by running *Add Graph Windows* multiple times.

The FFT spectral display opens:




The displayable frequency range is always measured data rate / 2, in this case 3000Hz. Disturbance peaks can be clearly seen. To identify the frequency of the first one, you can *disable Autoscale X* (right-click on the graph) and edit the frequency range at the bottom right:



Here you can see interference at 50 Hz and odd multiples of it. This is a typical behavior in the case of poor cable laying, lack of shielding or, as in this case, the use of an unsuitable power supply of the amplifier: the mains frequency of 50 Hz varies greatly (the multiples of this are probably generated by the unsuitable power supply, which induces a kind of square wave oscillation).

For comparison, the original power supply of the BX8 is now used:



The peak resolution is now much better with 8000 parts; it would correspond to an absolute resolution of 0.32 N with the above-mentioned sensor. The 50Hz mains frequency still sprinkles in somewhat, but by about 20 dB less (corresponding to an attenuation of 10). It is probably due to the fact that a short sensor cable was used, but without shielding.

Grounding the housing of the amplifier (if it is made of metal) often helps; the BX8 comes with a green grounding wire for this purpose. However, it does not always improve interference suppression. Grounding the sensor is also often helpful, especially if its metal body is isolated from the cable shield, as is usually the case with ME sensors.

It is recommended to eliminate or at least dampen interference at the source; for example, amplifiers and sensors should be placed as far away as possible from strong sources of interference (such as frequency converters for motors).


If this does not help, the measurement data rate can be reduced or - with the BX6 and BX8 - a digital filter can be configured as a band lock, see S. 92.

With the above-mentioned procedure, the success of a measure against disturbances can be directly observed.

Noise Cut

The BSC2 and BX8 devices can be configured to set the readings to exactly =0 when they are within a configurable amplitude range around zero. The noise floor close to zero is thus cut off. If this function is not enabled and readings are consistently exactly =0 even though enough decimal places are displayed, this indicates a malfunction. However, when using the noise-cut mode, it can no longer be detected when measured value =0, which can be disadvantageous.

Noise-Cut is configured under Menu Bar -> **Device** -> **Advanced Settings...** -> **Value Mode** -> **Noise suppression**:




In the case of BX8, the number of the input channel to which the threshold value should apply must be entered under Input Channel; 0 sets the specified threshold value for all channels. With **Noise-cut enabled**, the function is activated for all channels. If it is desired that it should only apply to certain channels, the threshold value was set to 0 for channels where it should be disabled. Under **Noise-cut threshold**, the upper, positive threshold value for the amplitude range of the Noise-Cut function is entered. The range then goes from threshold to threshold, e.g. from -0.175 to 0.175 as shown. At the end, click on **Store to device** at the bottom.

Due to the decimating averaging of numerical live display, it can happen that a displayed measured value is briefly within the noise-cut interval; however, this is only a display effect that does not affect the original measurement data, see p. 32.

Manage device settings data

In most amplifier models⁴, you can also store data sets with configurations. After all, all amplifiers always restore the last valid settings when switched on. In addition, there are user records for alternative settings or backups. This is useful, for example, if you want to connect different sensors to the same channels of a device, or if you want to test different measurement data frequencies or filters, and much more. You don't always have to repeat the individual configuration procedures.




To save these settings records, click Save Settings **in the** Configuration **tab** and then select the record you want to save to. By default, it is labeled User 1 to User 2 or User 6; how many data sets are available depends on the model. There are two for BSC1 and BSC4D, six for all others (except BX6).

⁴With the exception of the BX6 (so far, but also planned with this for future versions)

Alternatively, you can use **Save to File** to save your device settings to a file. This is useful, for example, if you want to use a different amplifier copy of the same model with the same sensor(s), then you can save the settings in a file and then load it into the other device.

To load the settings, click on **Load Settings**.



With **Load from File**, you can restore the settings from a file and with **User 1 to User 6 (2)** **you can restore the settings from the** above-mentioned data sets in the device.

In addition, there is the possibility to **restore the** data that was valid at the time of switching on with **Last Session**. This can be useful if you have accidentally selected unfavorable settings (e.g. **Load User 1** to 6 or **Default**) or wanted to try

something as a test that should not be stored permanently. **Last Session Charging** is only available on the BSC2 and BX8 (because these models do not save the current settings until shortly after switching off, so the power-on data is still available in the non-volatile memory).


In addition, you can **use Default** to reload the manufacturer's settings. These are the factory settings that the amplifier has by default. In the case of normal series of devices, this corresponds to the configuration of the delivery condition (but this does not apply if the manufacturer has configured the device differently at the customer's request, e.g. to calibrate it for a specific sensor).

Factory Settings Loading is available on all amplifier models. The operating instructions or protocol documentation often provide information about the specific factory settings, often also the type plate. The default measurement data rate is usually 10/s.

Basically, Load Settings overwrites the current settings, i.e. they are lost (only with the BSC2 and BX8, you can **undo it with** Last Session).

Assign and name device setting data for the BSC2

With the BSC2 you have the possibility to give your own names to the user records and to set this configuration as associated with a specific sensor or measurement campaign. This can be done by clicking on **Device -> Advanced Device Settings** in the menu bar. and select the Administration tab:




Prior to this, the current device settings should be configured as desired, e.g. input type, zero-point, user *scaling*, user offset, *measurement data rate*, etc.

Then you first select the record number with **Data record No**, where 1 corresponds to the default name "**User 1**", up to No. 6 for "**User 6**". Then enter a suitable name in **Displayed name** (maximum 13 characters long).

Then click on **Assign** to assign the current settings to this data record.

This will change the output as shown on the left.

Lastly, click on **Store Record name to device**:



This assignment is automatically removed when device settings are subsequently changed. This can be prevented by setting write protection, see S. 28

The new name of the record is now also displayed in the **Load Settings and Save Settings** dialog and also in the display on BSC2 models with keyboard menu when entering the corresponding menu item.


As long as the assignment of the settings (to the sensor or measurement) remains the same, because no relevant settings have been changed, the name of the data record is displayed on the display after the manufacturer's name, e.g.: **3: Scale>g**

In **Administration** (see above), **Reset to Default** can be used to undo the naming and assignment.

Restoring Device Settings Files from a Settings Archive

If you click on **Help -> Create Settings Archive**, a ZIP file will be created that contains all relevant files with settings. The settings of all amplifiers that are open during this time are stored in files of this archive, as well as the last opened or saved **Session File** (see p. 14) is included with the original file name in the root directory of the archive.

The device settings files are in the root directory of the archive and have the file name pattern <Device Model><Serial Number>.ucf.



In the example shown, a BX8 and a BSC2 were open. The device settings file of the BX8 is **BX8_16256044.ucf** and that of the BSC2 is **BSC2_rev1_15454833.ucf**. The default name of the session file is **session.ucf**.

The archive also contains the *.dat and *.matrix files of all multi-axis sensors, both software-calculated and those contained in the BX6 and BX8 devices, see p.39. BX8 also stores a file containing the contents of the error memory, here **BX8_16256044Faults.txt**. **info.txt** contains general information about the software version.

With the BX8 you can also open the **Settings Archive** directly to load all six-axis sensor data back into the device. This may be useful after a firmware update. To do this, click the **Recover All Six-Axis Sensors from Settings Archive** button in the menu bar → **Device** → **Advanced Settings** → **Administration** and then select the *.zip file.

Porting the device settings on the BSC8D

In reality, the BSC8D and GSV-1A16 USB amplifiers cannot store their device settings in the device (unlike all other strain gage amplifiers). Instead, the device settings are emulated in files located on the PC in the directory C:\ProgramData\BlueDAQ and in the **Settings Archive** in the subdirectory BlueDAQ. In it, you have the file name <Serial Number>.ucf.

To run a BSC8D with the same settings on another computer, you can copy these settings. To do this, first create the **Settings Archive** and unzip it on the target PC. On this you have to make the system directory C:\ProgramData visible with Windows Explorer, because it is usually hidden. Once you have done this, copy this file settings into the directory C:\ProgramData\BlueDAQ without changing the name. BlueDAQ should not be open. Then start BlueDAQ and open the BSC8D /16 with Add Channel and save the channel list in a session file if desired.

Porting the session file to another PC

The session file contains a list of all integrated channels and other software settings such as additional **Graph-Windows** with their window scales and **Trigger Paste** and **Copy-Paste** Settings (see p.75).

It is a configuration file in text format, divided into sections whose entries are of the form <key name> = <value>. Section names are enclosed in square brackets [name].

Each channel has its own section called [ch<Nr>]. On another PC, all settings can be valid as well, except for the COMport numbers of the connected devices and, if applicable, the window scaling of the **Graph Windows**.

In order to port the session file, the COMport numbers that the amplifiers have on the target PC must be known. To do this, they would have to be connected once and you can then look them up in the Windows Device Manager or open them with **Add Channel** as a test.

The session file can be opened with any text editor, e.g. notepad.exe.

In all sections [ch<Nr>] that belong to an input channel of a device, the values of the entries ComNr must then be changed. Example:

```
[ch1]
device="BX8"
ComNr=17
Input=1
BaudRate=115200
OpenFlags=0
Name="Chan. 17_1"
SerNr = 16256044
Color = 16777215
IsHidden = FALSE


[ch2]
device="BX8"
ComNr=17
Input=2
BaudRate=115200
OpenFlags=0
Name="Chan. 17_2"
SerNr = 16256044
Color = 16711680
IsHidden = FALSE
```

As you can see e.g. in the section [ch1] with ComNr = 17, this BX8 has the COMport number 17 on the old PC. To port the session file to the new PC, change all values of ComNr (e.g. **ComNr = 5**) in all sections that belong to this device instance. Identical device copies have the same serial numbers, i.e. the entries SerNr have the same value.

In the BSC8D/16-USB, the ComNr corresponds to an entry DevNo = <no>, where the number is assigned by the driver. It will be listed in the drop-down list of the **Add Channel** dialog.

Protect device settings from modification

With the BSC2, BSC1, BX6 and BX8 models, you can protect the device settings from unauthorized or accidental changes via hardware write protection. If write protection is set, the attempt to change settings in the device will be rejected, and an error message will appear for the BX6 and BX8.



To set write protection, click on Device -> **Advanced Device Settings** in the menu bar... and then select the **Administration** tab:

Under **Inhibit parameter changing**, you can set write protection with **Device is write-protected** and remove it again with **Writes are allowed**.

This may open a sub-dialog for entering a password. The password to be entered depends on the model, with the BX6 and BX8 it is already selected in the password dialog, so that you only have to confirm with OK:

- BSC2 and BSC1: Immutable password: berlin
- BX6: Immutable Device Password: USC1
- BX8: Changeable Device Password, Default: Beln⁵

If write protection is not set, i.e. changing settings is allowed, the soft-LED *Connected Interface has write-access* lights up bright green. If it does not light up, i.e. is dark green, this may have another cause in addition to the set write protection: In devices with multiple interfaces (BX8 and BSC2 CANopen), the communication interface with which the device was opened may not have write permission because the other interface has write permission. The following applies: In the fieldbus systems CANopen and EtherCAT, the fieldbus system usually always has write permission when it is on and not in the STOP-state.

In the case of serial interfaces USB / UART / RS422 / RS232, the interface with which the device was first opened with an application program such as BlueDAQ has write permission.

Observation and evaluation of live data during the measurement period

The measurement data can be observed during the measurement in several ways:

Numerical: As a large display in the index card **Value Display**, s. S. I I. Here, the measured values are always updated, even if **Start Recording (Recorder Yt)** has not yet been clicked. Other numeric displays include the **Value display** in **Recorder Yt** and in the **Recorder XY** and the single value display in **Configuration**. Basically, numerical displays are updated every 0.2 s (i.e. 5x per second) or less frequently when new measurement data is available less frequently. The latter depends on the measurement data

⁵The BX8 allows you to change the device password, but it is not currently supported by BlueDAQ, so it is unlikely that the device password will be different. However, if this is the case, it must not be forgotten, otherwise the BX8 would have to be sent to the manufacturer for repair.


rate (hardware setting), the software acquisition interval and, if applicable, the **Value displaytype** ab, see below.

Graphically: In **the index card Graph Display** individual graphs are available for each measurement channel, but only for the first 16 channels, see p. 11. These graphs represent the readings over time. The scale of the Y-axis can be changed for each individual graph, as well as the **Autoscale** Condition (see below). The temporal latitude corresponds to that of the **Recorder Yt** under **Time Visible**. Also in the **Graph Display** the measured values are always updated, even if **Start Recording (Recorder Yt)** has not yet been clicked.

In **Recorder Yt** all channels are represented in a graph over time, after the measurement with **Start Recording** begun, s. S. 9

In **Recorder XY** one or more channels are displayed on top of another, i.e. not over time, see p. 56.

With the button **Add Graph Window** Up to six additional windows can be opened that display live data, either as a Yt or XY chart or as an FFT spectrum, see below. 18. The **Graph Window** Windows are also displayed with name, position, type, etc. in the **Sessionfile**, s.S. 14. You can → them with the menu bar **View → Sort Graph Windows** evenly distributed on the screen.



For each graphical display, the scaling of the axes can be done automatically if the **autoscale** function is activated. This can be changed with the right-mouse button context menu by right-clicking in the graph.


With **Autoscale X**, the entire course of the measurement from the start time is displayed in the graph in the Yt recorder. The start time then remains constant on the left edge of the (horizontal) timeline. However, the following should be noted:

- **The total time with which this is possible is limited.** As soon as this has been exceeded, the time at the left full scale of time also continues to run and measurements that are older would be lost. This time is at least about 7 minutes. It can be enlarged with BlueDAQ PRO from version 2.01 onwards, see S. 32.
- With a high measurement data rate (and/or high system load from other programs), BlueDAQ requires a relatively large amount of RAM and processing becomes slower as a result. As a result, the total time with **Autoscale X** is often longer⁶, but it can happen that the program reacts very sluggishly.

Autoscale Y adjusts the full scale values of the Y-axis to match the visible readings. If there is no useful signal, but only noise, one can come to wrong conclusions about the noise amplitude because it is displayed optically enlarged.

⁶The reason is that the Yt signal diagram can hold up to 5120 data packets (v. 2.01) and at high data rates the individual packets become larger. The slower the program becomes, the larger they become, i.e. the packets contain more and more readings.

It can be useful to use the **Autoscale Y** function in a test measurement and direct the sensors to an area where you want to measure and then enlarge that area slightly as full scale values:



For each graphical display, the scale of the measured value axis (usually the Y-axis) can be changed, unless it is set automatically by **autoscale**. This axis scaling only affects the visibility of the graph, it has no effect on the scaling of the measured values by the amplifier.

Left-click on one of the two full scale values, enter the new value, and finish typing with the Enter key. It will be restored the next time the program starts.

Numerical display in recorder Yt and XY


In *the Recorder Yt* and *Recorder XY*, the measured values of all channels are displayed as numbers in addition to the graphical view. The display type can be configured with the Display drop-down menu and you can choose from the following options:

- **Actual Val:** Current reading as it is
- **Maximum:** Maximum value of the current measurement.
- **Minimum:** Minimum value of the current measurement.
- **MAX(abs):** Maximum value of the amount of the current measurement, thus taking negative minimums into account.
- **SNR [dB]:** Standard deviation, based on the measuring range in dB, see p. 18
- **Resol. Parts pp:** Peak value noise related to the measuring range in dB, see p. 18ff.
- **Max-Min:** Range between maximum and minimum value, see p. 18ff.
- **Mean:** Average, averaged over 100 values in the initial configuration and decimated. Alternatively, the time over which you want to average can be configured under Menu Bar->Options->Single Value Display -> Mean. This interval also determines the refresh rate of the mean (so it's not a moving average).
- **Integral:** The measured value is integrated, according to the settings under **Options** (see below)
- **RMS/StDev:** Standard deviation, see p. 18ff.

All of these values are reset when the measurement starts (**Start Measuring**), when the type is zeroed, and when the type is changed. In the display, **Wait...**

The results are determined by **SNR [dB]**, **Resol. Parts pp**, **Max-Min** and **RMS/StDev** above 100 values or over one second if the measurement data rate is greater than 100/s. This interval also determines the refresh rate of the value display.

Exceptionally, *the Integral* display must be selected before starting the measurement. It can be configured, among other things, with regard to the integral boundaries under Menu Bar -> **Options -> Single value Display**. Choose **Configure Value Type = Integral**.



Starting **Type** can be used to specify which criterion should apply to the left integral boundary:

- **None: Consecutive Intervals** means that after reaching the right integral boundary **Interval End**, a new integral is automatically formed. To form the indeterminate, ever-running integral, this setting is combined with **Interval End = Infinite**.
- **Above Threshold:** If the **starting threshold** is exceeded, a new integral is formed (Y-condition of the left integral boundary).

- **Below Threshold:** If the starting threshold falls below the **threshold**, a new integral is formed (Y condition of the left integral boundary).

Interval End / Acquisition Type can be used to define the criterion for the right integral boundary:

- **Infinite:** The integral calculation continues for the whole measurement (indeterminate integral)
- **Above Threshold:** If the **Interval End Threshold** is exceeded, the integral is terminated (Y condition of the right integral bound).
- **Below Threshold:** If the interval end threshold falls below the **interval end threshold**, the integral is terminated (Y condition of the right integral bound).
- **Number of values:** The integral is calculated using the number of measured values specified in Number of Values (time condition of the right integral bound: $\text{time} = \text{number} / \text{measurement data rate}$).


Processing can be used to specify whether only one integral should be formed (**First Event only**) and all subsequent start conditions ignored, or several (**All Events**), so that after reaching the right integral boundary, the first integral limit is again waited for the left integral boundary to be fulfilled. After completing an integral, the last result value for both settings is recorded in the **Single Value Display**, making it easy to read. In the case of the indefinite integral (see above), this setting has no effect. **With Interpolate**, an additional input value is created (interpolated) between two consecutive input values, which can lead to a more accurate result in some applications.

The values displayed in the **Single Value Display** can be copied to the clipboard at the time of measurement or pasted directly into other programs at the touch of a button. To do this, configure the menu bar -> **Options** -> **Copy & Paste** -> **Value Type to Copy/Paste** to **As Shown in Single value Display**, s. S. 75.

The memory behavior of the **Single Value Display** type can be configured under Menu Bar->Options ->Preferences. In the initial state, this is not saved and is set to **Actual Val** when the program starts. If the **Save and restore Single Value Display** checkbox is set, the set type will be restored the next time the program starts.

Configuring the Time Duration of the Acquisition Interval

The time duration of the acquisition interval is the time that the software waits and collects readings until it displays them, so it is also the refresh interval. After an interval has elapsed, a data packet is passed on for processing and graphical display, so its length over time determines the packet size. This, in turn, depends on the storage depth of the graph in the **Recorder Yt** together. It is relevant if you **Autoscale X** (s.S. 28ff.) or if you want to use **Configure Recording -> Save Memory Data** to copy the values stored in the Yt graph into a measurement data file (see p.62). The storage depth is in the **Recorder Yt** set to 5120 packets, in the counts of the index card **Graph Display** there are 768 parcels each. With



BlueDAQ PRO from v. 2.01 it may be possible to change this interval under menu bar -> **Options -> Preferences -> Measured data acquisition Interval**. This setting only applies when using only one amplifier or several, all of which are synchronized with each other via master-slave. It also does not apply to the BSC8D/16.⁷

In the delivery state and in the standard version, the acquisition interval is determined automatically, then **Set Automatically** is selected and the acquisition interval is between 0.1 s and

0.2 s, i.e. it is updated between 5x and 10x per second.

If **Set Automatically** is not set, you can set the acquisition interval under **Data Acquisition Interval** or have it calculated by entering the temporal storage depth of the recorder Yt in **Recorder Yt time length** (in hours).

If you choose the acquisition interval large, the program can become slow and sluggish with a high measurement data rate and many channels. If the product

Acquisition interval x measurement data rate² x number of channels is

greater than 20 million, a warning is issued when the measurement starts.

Regardless of the setting of this acquisition interval, the display interval for numeric displays is always 0.25 s, i.e. a new number is displayed 4 times per second. If the measurement data rate is higher, it is decimated to 4/s by averaging, if it is lower, the display interval corresponds to the measurement data period.

Decimal Places of Numerical Readings

Basically, the number of decimal places depends on the display normalization **User Scaling** and the maximum number of posts. The latter is configurable and is 6 decimal places out of the box. If the number of decimal places exceeds the numerical resolution of the

⁷These two restrictions may be removed for versions > 2.01; the revision history will provide information on this.

measurement data from the amplifier, lower-order decimal places are set to 0. This can be the case with the BSC2 and BSC1, for example, if the ASCII reading output is activated and configured accordingly, see S. 101. In the case of 16-bit amplifiers such as BSC1, BSC4D and BX6 (version 1.x), this can also be true with binary measurement data formats. The natural maximum of significant decimal places is 5 digits for 16-bit devices and 8 digits for 24-bit devices (BSC2, BX8 and BX6 v.2.x).

The maximum number of decimal places displayed can be configured under *Menu Bar -> Options -> Preferences -> Measured data numeric display*; the value range is 4 to 8.

The number of decimal places is usually calculated as follows:

Number of decimal places = number of decimal places - rounding up ($\log_{10}(\text{User Scaling})$)

Examples: Number of decimal places=5, User Scaling = 3.5: 4 decimal places

Number of decimal places = 5, user scaling = 10,000: one decimal place

Number of decimal places = 4, User scaling = 150,000: no decimal place

Number of decimal places = 4, user scaling = 2: 3 decimal places

Number of decimal places=4, User scaling = 1: 4 decimal places

Recording of measurement data and subsequent evaluation


BlueDAQ provides a wide range of options for storing measurement data. The configuration of the data recording is from S. 58 described and the evaluation with the **File Monitor** from S. 67. Among other things, measurement data can be converted into CSV or Excel files, the recording can be started and stopped automatically, and much more.

It is even possible during a data acquisition (i.e. when **Start Recording** is active) at the same time a preliminary result of the *.tdms measurement data file with the **File Monitor** to look at. You will then see the temporal start of the file without the part that is currently being written to. However, it is not possible to take notes (**Annotations**) as described on p. 84 be set or modified, because the file will not be replaced by the **File Monitor** may be stored. Notes are set during the measurement period as set to S. 81 described.

Configuration of data logger devices


The Amplifier Models BX6BT and BSC2MSD-DI offer the possibility to record measurement data in the device on an SD memory card, i.e. measured values can be stored independently of the PC. These functions are described in the user manuals (a separate one for the BX6BT). The logged measurement data files are available in a readable text format, but can also be opened with the File Monitor, see S. 67, converting them to tdms file format. With both amplifier models, the measurement data files can be copied from the SD card without having to remove it from the device, see S. 37. In the case of the BX6BT, it is often useful to ensure that the Measurement application for recording after closing the communication link, which starts from S. 103 described.

First of all, it is important that the built-in real-time clock is set correctly. After a change or drain of the battery or after a long time, the watch may be adjusted. To read the clock and set it, click on **Device -> Advanced Settings** in the menu bar and select the **Administration tab**:



By clicking on **Sync**, the clock will be set as close as possible to the time of the PC. Before that, you can specify with the BX6BT whether you want to set the clock to the local time zone (**Set local time**) or to UTC world time (**Set UTC**). In the view, the time is read from the device every 3 seconds.

To configure the logger function, if you have several amplifications open, first select a channel that belongs to the device you want to configure. Then click on **Device** in the menu bar and select **Advanced Settings**. Select the **Administration** tab and click on **Settings** under **Measuring values Logger**.



Here is the dialog on a BX6BT with an SD card inserted. The radio buttons under **Data Recording** have the following meaning:

- **Disabled:** Recording is turned off
- **Log permanently (if device on):** The measurement data is constantly recorded as long as the device is connected and an SD card is inserted.
- **Single Log by Command (BX6BT only):** A line of measured values is recorded by a device

command given by software. This can be done, for example, by clicking on the **Log One Row** button.

- **Single log by OK Key (BSC2 MSD-DI only):** A line of measured values is written by pressing the OK key.
- **Single Log Periodically (BX6BT only):** The slow recording mode is activated. The time interval between two lines of readings is configurable from 2s to several hours under **Logging Period**. Since the BX6 is put into standby mode in the meantime, this mode is energy-saving, especially for periods of one minute or more, so that the battery lasts a long time.
- **Log while Trigger Input = active (BX6BT only):** It is recorded when the TRIGGER digital input has an active level and the BX6 is on (green LED is on). For this purpose, digital input must be configured accordingly, see S.109

The settings under **Logging Period** affect the recording interval and apply only to the BX6BT. Their appearance and meaning depend on the **data recording** mode.

With **Data Recording = Log permanently** and **Log while Trigger Input = active**, they mean the following:

- **Multiply TX freq by:** This allows the recording rate to be higher than the measurement data rate, which is transmitted via Bluetooth. This is useful if you want a high

recording rate on the SD card and at the same time want to avoid connection problems with Bluetooth that can occur with high data transfer rates. Under **Factor** you can enter the factor between SD recording rate and transfer rate or you can enter the desired recording rate directly under **Logging Frequency**. The correlation is: **Logging Frequency** = Transmission Rate x Factor.

- **Divide frequency by:** This allows the recording rate to be smaller than the measurement data rate, which is transmitted via Bluetooth. Under **Decimator** you can enter the divisor between the transmission rate and the SD recording rate or you can enter the desired recording rate directly under **Logging Frequency**. The correlation is: **Logging Frequency** = Transmission Rate / **Decimator**.

With **Data Recording** = *Single Log periodically*, they mean the following:

- **3..59 Seconds:** The measurement data recording interval is in the range between 3 and 59 seconds. It can be entered under **Seconds**. This setting is only slightly energy-efficient because the amplifier remains on the entire time.
- **Minutes / Hours / Days:** The measurement data recording interval ranges from one minute to several days. The number of days is entered under **Days** (may =0), the hours under **Hours** (0 to 23) and the minutes under **Minutes** (1 to 59). Since the BX6 is put into standby mode in the meantime, this mode is particularly power-saving, so that the battery lasts a long time, the longer the recording interval, the longer.

Under **File Format**, the formatting of the measurement data files can be influenced. Examples of file contents below.

- **Print File Header:** A header is written at the beginning of each file. It contains information about the meaning of the columns, the number of channels, normalization, modes, unit if applicable, and recording rate. This checkbox is set by default. Omitting the header is not highly recommended, because importing the text file with the **File Monitor** may not have a good result.
- **Print Unit:** If this checkbox is set, the BX6BT writes the units of all configured channels in a line in the header; the BSC2MSD-DI writes them after each measured value in a column (currently not deactivable for the BX6BT).
- **Log Max-, Min- and Mean** (BSC2MSD-DI only): If this checkbox is set, the BSC2 determines the maximum, minimum and mean value in addition to the current measured value, so that 4 measured value columns are written. Example BSC2 MSD-DI, language = German:

Normalization: +100,000 Data rate: 10,000 Hz							← Print File Header activates
Date Time	Value	Max	Min	Wed	Unit		← Max-, Min- and Mean activates
23/11/23,19:43:38.25886	+5.913	+5.914	+5.913	+5.914	g		← Print Unit activates

Under **Time Stamp**, the timestamp columns can be formatted. They are written to the first column of the measurement data file.

- **None** (BSC2MSD-DI only): No time or date. This setting is not recommended because the import of the text file with the **File Monitor** may not have a good result regarding the timestamps of the tdms file. This is especially the case if **Print File Header** is disabled at the same time.

- **Time only:** The timestamp contains only the time with fractions of a second, not a date. Example BSC2 MSD-DI, language = German:
 Normalization: +100,000 Data rate: 10,000 Hz ← *Print File Header* activates

Time	Value	Unit
19:20:13.61203	+6.328	g

 ← *Print Unit* activates
- **Date only** (BSC2MSD-DI only): The timestamp contains only the date, not the time. This setting may also not be recommended, see **None**. Example BSC2 MSD-DI, language = German:
 Normalization: +100,000 Data rate: 10,000 Hz ← *Print File Header* activates

Date	Value	Unit
23/11/23	+6.256	g

 ← *Print Unit* activates
- **Both Date & Time:** The timestamp contains both the date and the time. Example BSC2 MSD-DI, language = German:
 Normalization: +100,000 Data rate: 10,000 Hz ← *Print File Header* activates

Date Time	Value	Unit
23/11/23,19:21:59.04858	+6.166	g

 ← *Print Unit* activates

Under **File Size**, you can specify how large the file should be. This is useful so that the files do not become too large, which is particularly relevant for permanent data recording. The input is made as a specification of the maximum number of rows under **Max. Number of Rows** or as a specification of the maximum time over which a file contains measurement data, where the input is made under **Hour**, **Min** (minutes) and **Sec** (seconds). The time and line information are converted into each other when entered, based on the currently set measurement data rate. Only the number of lines is stored in the device. If this is reached during the recording, a new file is created.


Note: The minimum time length should never be less than one second, otherwise it will not be possible to create individually different file names, i.e. the minimum number of lines is equal to the measurement data rate.

The reason for this is that the file names consist of date and time, including the second.

With the BSC2MSD-DI, you can specify under **New Directory** whether a new directory should be created for the measurement data files every day (**Every Day**) or every month (**Every Month**), see the operating instructions.


If the BX6BT **Data Recording** is set to **Single Log by Command**, Single Log File Creation can be used to specify whether the lines of measured values should always be appended to the last written **file** (**Append to previous**) or whether a new file should be created every day (New File Every Day) in which the measured value lines should be written. If **Data Recording** is set to **Log while Trigger Input = active**, you can choose between **Append to previous** and **New File Every Trigger Event**. With the latter, a new file is created every time a recording is started by activating the trigger level, and this has the advantage that the timestamps will also be correct when importing the file into a tdms file. For attached data, the timestamps in the converted tdms file are incorrect.

At the bottom of the window are some soft LEDs and buttons, which are immediately executed in the device on the BX6BT and have the following meaning:



- **Card Inserted:** When this soft LED is lit, an SD card is inserted and mounted.
- **Logging File Open:** When this soft LED is lit, a file is open for writing. Attention: The SD card must not be removed!
- **Currently Logging:** Data is recorded.
- **Open File:** Clicking this button will open a file for writing
- **Close File:** A data recording is stopped, and the file is closed
- **Mount SD:** An SD card that has just been inserted is mounted. Note: If an SD card is inserted when the BX6BT is turned on, it will automatically mount it.
- **Eject SD:** The inserted SD card is deactivated so that it can be removed afterwards
- **Log One Row:** If the *Data Recording* type is set to *Single Log by Command*, a line of readings will be written when this button is clicked
- **Start Logging:** If the *Data Recording* type is set to *Single Log Permanent*, clicking this button will start data recording


In the BSC2MSD-DI, the elements at the bottom have the following meanings:



- **Logging enabled:** This soft LED lights up when data recording is enabled.
- **Charge by USB Power, if possible:** If this checkbox is active, the device tries to draw power via the USB interface. When it is on, these 500mA are not enough to charge the built-in accumulator, but when it is switched off, it is possible. In this state, it acts as a mass storage device on USB.
- **MSD-DI Firmware Version:** Version of the embedded software of the (second) controller for the management of USB, SD card, data recording, power management and logger menu.

Accessing the recorded measurement data of the data loggers

The BSC2MSD can be switched to USB mode via the user menu to be able to use it as a card reader. To do this, the device can also be turned off instead; in both cases, the use of BlueDAQ is not possible at the same time. In USB card reader mode, the SD card is accessed, e.g. with Windows Explorer, see user manual.




For the BX6BT, BlueDAQ provides a file browser for copying files; it can be opened via Menu Bar -> File -> Device File Browser *or* Menu Bar -> Device -> Advanced Settings -> Administration -> File Browser.

In the upper left corner, next to **Last file logged**, the path to the last recorded file is listed. If in the top right corner under **Which file?** **Recently logged**, it can be **downloaded directly** by clicking on Download File.

If **Selected File** is selected, select the directory in the file

view under **Directory / File Names**; it will be formed from M<Year>_Monat>. Double-clicking on it will unfold it, as shown here for M2023_06. Now you can mark the file. Entries in bold in the file view are measurement data directories and files, where Yes is also listed under **Logger Item**. Then click on Download File, select the destination directory on your PC and the download will start, indicated by a progress bar. Copying (downloading) can take a long time for large files. The file size is displayed under Size [kB] and the download time can be estimated: time in seconds = file size [kB] x 0.12.



When it's done, it will ask if you want to convert the downloaded text file to tdms format. If you let Yes do this, the file can be opened with the File Monitor. It is not necessary, because the text file can also be opened directly with the File Monitor.

Additional features

Note: Most of the configuration options shown below are applied to the device to which the channel set with *Actual Channel* (Configuration tab) belongs.


Integration of multi-axis sensors

When using 6A or 6ADF six-axis sensors or 3AR series three-axis sensors, a calibration matrix must be loaded once.⁸ It can be found in the files that came with the sensor. In the case of the BX6 and BX8 amplifiers, the calibration matrix for six-axis sensors is usually stored in the instrument because they can perform the calculation themselves (exceptions and limitations: see table below). Otherwise, the files with the calibration data of the multi-axis sensors must remain stored on the PC, because BlueDAQ needs them at the measurement runtime to calculate the forces and torques. In this case, at least 6 channels per sensor must always be open.

These files with the calibration data have the following naming convention (please do not rename):
<Sensor Serial Number>.dat<Sensor Serial Number>.matrix


Both files must be in the same directory.

First of all, all required input channels must be open and all of them must have the same input **type**, i.e. the same input sensitivity. If this is the case, click on **Special Sensor**, then the following intermediate dialog will open, which you leave as it is and confirm with OK:




⁸The K3A and K3D series do not require a calibration matrix. F6D sensors with an e at the end of the model designation have a built-in BX6 amplifier and the calibration matrix is usually already installed.

Then the dialog for multi-axis sensors appears:




Click on Add Sensor in the top left corner , then a sub window will open:



Click on **Open File/Dir** to load the calibration data for the first time. In the file selection window that opens, select the *.dat file belonging to the sensor.

The multi-axis sensor dialog then looks like this on a standard six-axis sensor:



To be on the safe side, please first compare the serial number on the sensor's nameplate with the one shown under **Sensor Serial No**; they must match.

First, select the first channel of Input Component 1, with Component 1. If your BX6 or -8 amplifier will perform the calculation itself (the *Calculated by device* checkbox is then enabled), components 2 to 6 will be selected automatically. Otherwise, i.e. for software-calculated sensors, you must select all input components manually. The dialog now looks like this:

If desired, the output channels of the calculation can be automatically renamed with *Rename Channels*, so that the channel name denotes the physical size and direction. To then enable six-axis sensor measurement and, if necessary, save the sensor data to the BX6 or BX8, click **OK Enable this sensor**.


If the six-axis data is stored in the device and data already exists there, you will be asked if you want to overwrite an existing record or create a new one. In case of overwriting, you may be able to specify the memory index:

BX6 and -8 can store up to 11 such sensor data sets. You will then be asked for the device password when saving and calculating in the device. As a rule, this is not adjusted; So, you can confirm the pre-selected password with OK. For BX8 it is "Beln"

If the sensor calculation has been activated, you will receive a confirmation

message and the dialog will close.

The status messages in the Configuration and Recorder tabs show the multi-axis sensor being activated:



After loading the six-axis data, a zero adjustment should be performed with the sensor unloaded, by clicking on **Set All Zero** in *Recorder Yt* (see p. 84).

To deactivate the multi-axis calculation, open the **Multi-axis Sensor** dialog again. The green soft-LED **Enabled** is now lit. You can now **disable the sensor with** Disable this sensor.

Learn more about the Multi-Axis Sensor Dialog

Under Sensor Mode, you can see the sensor type or mode. In the case of six-axis sensors, it depends on the type of sensor and the selected calibration data. In the case of three-axis sensors, it is possible to switch between three different calculation modes. There are the following types, or modes:

Sensor Mode	Sensor Models	Computable by BX8	Computable by BX6	Matrix	Remarks
<i>Six-axis</i>	6A, 6ADF	Yes	Yes	6 x 6	Determined by sensor data
<i>Six-axis, 2nd order</i>	6A, 6ADF	Yes	No	2 matrices of 6 x 6 each	Determined by sensor data
<i>Three-axis Fz, Mx, My</i>	3AR	No ⁹	Yes ⁹	3 x 4	Three-axis mode selectable, here force, 2x torque
<i>Three-axis Fx, Fy, Fz</i>	3AR	Yes ⁹	Yes ⁹	3 x 4	Three-axis mode selectable, here 3 forces
<i>Three-axis Fz, sx, sy</i>	3AR	Yes ⁹	Yes ⁹	3 x 4	Three-axis mode selectable, here force, 2x travel
<i>Six-axis, 6x12 Matrix</i>	6A-225	No	No	6 x 12	Determined by sensor data, 12 input channels required

Notes on sensor modes:

- The "*Six-axis, 2nd order*" mode corresponds to the Matrix Plus solution. Here, the second, square matrix is also displayed in an additional index card. When calculated by the BX8, the maximum data frequency is limited to 2000/s.
- For the modes calculated by software, all input components must be selected individually under **Channel assignment** in the **General** tab. As a rule, these are input channels 1-6 for multi-channel devices.
- By the 6x12 Matrix Mode must be additional Components 7 to 12 can be selected by selecting the checkbox **Compo 7 to 12** in **Channel assignment** is activated. Most of the time, these are the first 6 input channels of a second amplifier. In this case, a "master-slave" synchronization of the measurement data transmission of both devices is recommended, for which, however, hardware requirements exist, see p. 14.

⁹The calibration files can be changed by the manufacturer ME in such a way that the calculation by BX6 or BX8 is still possible. However, channels 5 and 6 will then become unusable.


- For the three-axis modes *Three-axis Fx,Fy,Fz* and *Three-axis Fz,sx,sy*, a *lever arm length must be entered on the right under Distance offsets; the input elements are then marked in red.*
- In the case of the three-axis sensor, the input channel 4 has no significance as the output channel. In the 6x12 matrix mode, this applies to input channels 7 to 12. Although these are required as input values for the calculation, they do not have a physical output value assigned to them. According to **Rename Channels**, she has the designation "*dummy*." You can hide these channels in the main window so that they are no longer visible by selecting *this channel with Actual Channel* in the **Configuration tab of the main window and then clicking on Channel -> Hide from the menu bar.**
- For the sensors/modes calculated by software, it is useful to save the entire configuration in a session file. Then the above-mentioned selection process of the sixth-axis data does not have to be carried out again, but after the next program starts you can *simply restore them* with Open Session.
- In the case of the sensors/modes calculated by software, when recording measurement data (see p. 9 and 58) has created an additional TDMS file containing the raw data, i.e. the mV/V values that the sensor outputs directly. The file names of the raw data are in the form <date-time>RAW.tdms, i.e. RAW is appended to the file name of the file with the normal physical measurements. The raw data may help to determine the cause of problems, or you can use a different matrix afterwards.

The screenshot shows the 'Multi-axis Sensor' configuration window. At the top, there's a 'Sensors' section with 'Number of Sensors' set to 1 and 'Number of sensors stored in device' set to 0. Below this, the 'Sensor displayed' section shows 'Model Name' as 'Test_6x12', 'Sensor displayed' as 1, and 'Sensor Serial No' as '09101463'. The 'Sensor Mode' is set to 'Six-axis, 6x12 Matrix'. The 'General' tab is selected, showing 'Channel assignment' for components 7 to 12, each assigned to a specific device (e.g., '9: Dev3_1 (3.1)'). There are also 'Distance offsets' for X, Y, and Z directions, all set to 0 meters. A 'Maximum Values (read only)' section shows force and torque limits for X, Y, and Z axes. At the bottom, there are buttons for 'OK Enable this sensor', 'Disable this sensor', and 'Cancel'.

Channel assignment for sensor with 6x12 matrix

Changing the sensor configuration and using multiple multi-axis sensors

- If you want to load different calibration data for the same sensor, or if you want to store other calibration data in the same BX6/-8, it is recommended to disable the sixth-axis calculation with *Disable this sensor* beforehand if it is active. If the data was stored in the device, it will be retained (unless it is overwritten by reloading by specifying it in the *store in the device memory* dialog).

- If you want to use other calibration data stored in the device, proceed as shown above (after the current sensor has been disabled), but set the checkbox **Use sensor data stored in device** in the Select Sensor intermediate dialog and **then select the desired sensor based on the serial number and the storage space with Select Sensor** from. The input components are then automatically assigned because they belong to the amplifier and cannot be changed.
- 
- In the BX6 or BX8, only one of the stored calibration data arrays is active, always the one that was last activated with **OK Enable this sensor**. The number of the active sensor is also part of the user settings **User 2 to User 6** of the BX8, so that you **can also switch between sensor data with Load Settings if the configuration** has previously been saved with **Save Settings**.
 - If several multi-axis sensors are to be used for a measurement, repeat the above-mentioned charging process without removing sensors first. Accordingly, there must be enough input channels in the measuring system for this purpose. In **the Multi-axis Sensor** dialog you can **select the one you want to display with Sensor displayed** in the upper right corner. The number of active sensors is displayed at the top in **Number of Sensors**. With the BlueDAQ PRO variant, up to 8 multi-axis sensors can be used, with the standard variant up to 4.

Other display and control elements in the *Multi-Axis Sensor* window

General: Distance Offset: Here you can enter distances of a force application point, which are taken into account when calculating the torques. The calibration matrix is usually determined by the manufacturer in such a way that the torques at the sensor origin apply. Often, however, there are still attachments to the measuring platform and you want to measure the moments at this point. The directions of the *distance offsets* up to and including program version 2.00 are opposite to those of the sensor coordinate system; from 2.01 onwards they correspond to the coordinate directions of the sensor in the case of a software-calculated system.

General: Maximum Value: The maximum values of the sensor. Within these limits \pm maximum, the accuracy specifications of the sensor apply. If the maximum values are exceeded, this is indicated by the red **Sensor Overload** button at the top of the main window. This can then be clicked to get more detailed information about the maximum value exceedance.

Zero Signal: Basic detuning values at no-load of the sensor at the time of calibration of the sensor by the manufacturer. With their help, previous zeroing of the sensor (with **Set All Zero**) can be cancelled by clicking on the yellow **Untare** button. You can then see the current upset.

Matrix: The elements/coefficients of the calibration matrix.

Storing location: Storage location of the calibration matrix. If the device (**Device...**), the memory index is also displayed under **Index in memory**.

Enable Distance measuring for 6-axis sensor: With the BX8, instead of the forces F_x and F_y , the distances S_x and S_y can be calculated in meters, which indicate the distance of a force application to the sensor origin; i.e. a force $\neq 0$ must be applied.

Measuring with strain gages

Strain gages (strain gages) *are* small sheets of metal mesh that are glued to a body to measure its surface strain or compression. The elongation is a ratio and is given in $\mu\text{m}/\text{m}$, this (pseudo-) unit is equivalent to microstrain ($\mu\text{Inch}/\text{Inch}$) and others, generally: "Elongation $\times 10^{-6}$ "

In order to adjust the strain gauge so that it measures correctly in $\mu\text{m}/\text{m}$, it is necessary to know the K-factor, which indicates how much the resistance or output voltage changes. In addition, you need to know the type of bridge; Single strain gages are always quarter bridges and require a bridge addition, which is placed either externally or in the amplifier, see its operating instructions. In the case of bridges with transverse contraction, it is also

necessary to know the transverse contraction number of the material to which the strain gauge is glued. It indicates the ratio of longitudinal to transverse elongation.

To adjust, click on *Sensor->Strain gage...* or on *User Scaling* and then select the small tab *Strain gage*.

Use Bridge type to select the type of bridge:

Full (4): Full bridge with all 4 strain gages in the longitudinal direction. No bridge addition necessary.

Half (2): Half bridge with 2 strain gages in the longitudinal direction. Half-bridge extension necessary.

Quarter (1): Single DMS. Quarter bridge extension necessary.

Half (1+ μ): Half bridge with one strain gauge in the longitudinal and one in the transverse direction. Half-bridge extension necessary. Transverse contraction number *Poisson's ratio* must be specified.


Full (2+2 μ): Full bridge with 2 strain gages in longitudinal and two transverse directions. No bridge addition necessary. Transverse contraction number *Poisson's ratio* must be specified.

Under Gage factor, the K-factor is entered, and under *Poisson's ratio*, if applicable, the cross-contraction number. The Input **Range** is displayed correctly on most amplifiers, with the exception of the BSC1.

Then click *Calculate*, and then click *Store to Device*. The new *user scaling* is set and the unit is then $\mu\text{m}/\text{m}$.

Stress measurement with rosette strain gages

When using triple-rosette strain gages (SGS), BlueDAQ can be configured to convert the signals from the strain gages into mechanical stresses and angles of the main stress.




Mechanical stress is a measure of the stress on a body (to which the rosette strain gauge is glued) due to its external load.

Rosette strain gages are used, which have an angle of 45° to each other. These three individual strain gages have to be completed on the hardware side with quarter bridge additions to the full bridge and at least three channels are required. The


BX6BT and BX8 amplifiers meet this requirement, as does the BSC4D after internal modification. The corresponding user manual explains how to connect quarter-bridge strain gages correctly.

To configure this type of voltage measurement, click **on** Special Sensor in the **Configuration tab**, then the following intermediate dialog opens, in which **Calculate principal Stress** is selected:




Alternatively, you can **select** Sensor>Rosette Stress *in the menu bar*.

Then the **Rosette Sensors** dialog opens. In it, **click Add Rosette** to add a stress measurement.



With **Channel assignment**, you then have to select the channels to which the respective input components (**Component Ea, Eb, Ec**), i.e. the individual strain gages a, b and c, are connected. Under **Elastic Modulus**, the modulus of elasticity (modulus of elasticity) of the material to which the strain gages are glued is entered, under **Poisson's ratio**, its transverse contraction number. The picture above shows typical values for pure aluminum as

examples. Under **Rosette Strain gauge** next to **Gage factors a, b and c**, the K-factors of the strain gages used are entered; with **All** same, you only have to do this once, as long as all three are the same. The **Input Sensitivity** of the amplifier is automatically displayed correctly on most strain gage amplifier models. Finally, click OK. The channels are then renamed **Sigma 1** for the main voltage, **Sigma 2** for the shunt voltage and **Phi** for the angle of the main voltage direction to the strain gauge a, also the units are changed to N/mm² and ° respectively:




Sigma1	Sigma2	Phi
12,355 N/mm ²	-10,777 N/mm ²	134,404 °


When using multiple rosette strain gages for multiple measuring points of mechanical stress, this configuration is repeated for each rosette. The channel names are then appended with **_1**, **_2**, and so on. The channel names can then also be changed manually (see p.6), but the units do not. It's a good idea to do this whole configuration with **Save Session** so that they can be used the next time the program is started (see p.56) easily with **Open Session** can be restored.

Switching between stress and strain measurement

When voltage measurement is activated, the status message **Rosette Sensor: Stress enabled** appears. In the meantime, without losing the configuration data of the stress measurement, you can switch to strain measurement. To do this, click on **Special Sensor** again and then select **Display measured strain**



Alternatively, you can also click on Sensor>Rosette Strain in the menu bar. The



units, channel names and status messages change:

To return to the voltage measurement, select *Calculate principal stress or Menu bar>sensor>rosette Stress* in the Select Special Sensor intermediate dialog and confirm the rosette dialog with OK.

Note on saving the rosette configuration: The channel names are stored in the *session* file, but the voltage measurement data is only stored if the voltage measurement is active at the time of saving. The strain configuration results from the *user scale*, which is stored in the amplifier as well as the units.

Sensors with TEDS

Some sensors have a memory module in whose memory individual configuration data for this sensor is stored. These are standardized in the TEDS standard according to IEEE 1451.4 (Transducer Electronic Data Sheet).

Currently, only the BX8 and BX6 amplifiers support sensors with TEDS (BX6 only on channel 1).

When connecting a sensor with TEDS or powering it on with the sensor connected, the BX8 reads the memory and sets scaling (*User Scaling*), unit and input sensitivity automatically so that correct physical readings are displayed, i.e. *User Scaling* cannot and does not have to be set as on S.8 described.

When this is done, the label of the User Scaling *button changes to* Scaling by TEDS:

Range: 3500 Unit: N

In general, the user does not have to do anything else. To explicitly read the memory content or change the TEDS loading options, you can access the TEDS dialog by clicking this button or by clicking on the menu bar -> sensor -> TEDS...

TEDS data and usage

TEDS Sensor Settings

Input Channel: 1 ComNo: 9

Read from TEDS device: Read Write Write to TEDS device: Write Edit All: Edit Read from TEDS file: Read

TEDS usage BasicTEDS data

TEDS Usage Input Ch. 1

☒ Device loads and uses TEDS data

☐ Device doesn't load TEDS data

☐ Apply this to all input channels

☒ Set Unit from TEDS data

☐ Set Input Range from TEDS data

☐ Set Offset from TEDS

☒ Set analog output from TEDS

Resulting Scaling Ch. 1: 3500

Store to GSV-8 device

Sensor Info Refresh

Input	Input Type	Sensor Plugged?	TEDS used	EEPROM connected	TEDS auto-load
1	Bridge 3,5mV/V	Yes	●	●	●
2	Bridge 3,5mV/V	No	●	●	●
3	Bridge 3,5mV/V	No	●	●	●
4	Bridge 3,5mV/V	No	●	●	●
5	Bridge 3,5mV/V	No	●	●	●
6	Bridge 3,5mV/V	No	●	●	●
7	Bridge 3,5mV/V	No	●	●	●
8	Bridge 3,5mV/V	No	●	●	●

OK

The display TEDS usage -> Sensor Info

With BX8, each line shows whether a sensor is connected and whether the TEDS data has been loaded. With BX6, only channel 1 is valid. The entries mean:

- Input Type.** TEDS templates with IDs 33 and 35 (see below) can only be used with bridge inputs, ID 25 only with voltage input.

- **Sensor Plugged?** The BX8 can usually determine whether a bridge sensor is connected, in which case the entry is **Yes**; otherwise **No** or **Unknown** is unknown. The latter is regularly the case with input type = voltage or temperature as well as with the BX6.
- **TEDS used:** This soft LED "glows" bright green when TEDS data has been successfully loaded. In this case, **EEPROM is also** connected.
- **EEPROM connected:** This soft LED "glows" bright green when a TEDS memory device has been connected and detected. This applies even if the content of the data could not be interpreted as known and compliant; in this case, **TEDS used** does not light up. This is regularly the case with empty memory modules.
- **TEDS auto-load:** This soft LED "glows" bright green if the BX8 has been configured to use TEDS data on this channel, see **TEDS usage**.

Configuring TEDS Device Behavior

The strain gage amplifier is configured by the manufacturer's settings in such a way that it tries to load TEDS data when it is switched on (BX8 even when changing sensors); In addition, there are four checkboxes for detailed settings, which only apply if TEDS data is to be loaded for this channel.


- **TEDS Usage Input Ch.** <no> Basic TEDS charging property for the channel selected in the upper left corner under **Input Channel**
- **Set unit from TEDS data:** If set, the unit is also set based on the TEDS data (valid for all channels with TEDS enabled).
- **Set input range from TEDS dat:** If set, the input measurement range / input sensitivity is also set based on the TEDS data (valid for all channels with TEDS enabled).
- **Set offset from TEDS:** If set, the zero point is also set based on the TEDS data (valid for all channels with TEDS enabled). If this is set, zeroing with Set Zero (main window >configuration) is still possible, but after the next power on, the zero point is loaded from the TEDS again.
- **Set analog output from TEDS:** If set, the scaling factors of the analog outputs are set based on the TEDS data so that the maximum physical value corresponds to the analog nominal output value (valid for all channels with TEDS enabled).

If you want to change the basic TEDS charging property, you can use **Apply this to all input channels to** specify whether the selected setting should apply to all input channels. Then click **Store to strain gage amplifier device**.

With the light blue **button Refresh** you can update the displays after changing settings or reconnecting a TEDS module.

Reading and viewing TEDS content

After clicking on **Read from** TEDS device, the contents are displayed in the **Basic TEDS data** and **TEDS 33 data** (or TEDS 33 data) **tabs**. TEDS 35 data or TEDS 25 data). The different templates correspond to different data formats for different categories of sensors. The **basic TEDS data** is organized in the same way for all templates, they contain an ID for the sensor manufacturer, the template ID and the serial number as well as the entries **ModelNo**,




Version Letter *and* Version Number, *which the manufacturer can set as desired*.

In the case of sensors from ME-Meßsysteme, the sensor serial number is in **Manufacturer Serial number**.

The BX6 and BX8 support Template ID 33 for Wheatstone bridge sensors and ID 35 for strain gages, while the BX8 also supports ID 25 for accelerometers.

The template ID-specific data content is displayed in the right-hand tab; In the following, only ID 33 for bridge sensors is described.

If you have opened the TEDS window via the menu bar -> Sensor -> TEDS, some entries with the BX8 are displayed with a green background; these are those that experienced users can modify for certain reasons - e.g. during a recalibration - in order to then write the data back to memory, but this is only possible with the BX8 (see below). The white ones are immutable properties of the sensor, which are usually not changed.



The entries in detail:

- **Physical Measurand:** The physical measurand of the sensor to which this calibration also applies. This also determines the unity. Based on this value, the unit of the strain gage amplifier is set, if configured accordingly.
- **Minimum physical value:** X-coordinate "Pmin" of the lower point of the two-point shape of the sensor characteristic, see drawing below
- **Maximum physical value:** X-coordinate "Pmax" of the upper point of the two-point shape of the sensor characteristic, see drawing below
- **Select Precision:** Numerical representation of the coordinate points (Pmin/max, Emin/max). 32 bits are recommended.
- **Minimum electrical value:** Y-coordinate "Emin" of the lower point of the two-point shape of the sensor characteristic curve in mV/V, see drawing below
- **Maximum electrical value:** Y-coordinate "Emax" of the upper point of the two-point shape of the sensor characteristic curve in mV/V, see drawing below
- **Bridge Type:** Sensor Bridge Type (Full, Half, Quarter)
- **Sensor impedance.** Sensor internal resistance in ohms
- **Response time:** Settling time of the sensor in case of rapid changes (jumps) of the measured variable, in seconds
- **Excitation amplitude nominal:** Recommended sensor power in volts
- **Excitation amplitude minimum:** Minimum sensor power in volts
- **Excitation amplitude maximum:** Maximum sensor power in volts


- **Calibration Date**: Date of last sensor calibration
- **Calibration Initials**: Initials of the person who calibrated
- **Calibration period**: Recommended time to recalibration, in days
- **Measurand location ID**: User-specific identification number of the measuring point

Editing and writing TEDS data

The BX8 can also be used to write memory devices (so-called 1-wire EEPROMs). The following types are supported: 24B33, MAX31826, 28E07,¹⁰ 243110

In order to be able to write, the TEDS dialog must be activated via menu bar -> *sensor* -> *TEDS...* , then (except for an empty module) you must first read *with Read from TEDS device*.

The green entries in the index cards with the TEDS data can be changed directly and then written by clicking on *Write to TEDS device* . The device password of the BX8 (default: Beln)



Example of a sensor characteristic. The red coordinates correspond to the TEDS data shown; The negative yellows are alternatively possible.

must be entered or confirmed.

To describe a previously empty block or to modify and write the white entries and those in the **Basic TEDS data**, experienced users proceed as follows:

1. Click on **Edit All** , then enter the unlock password MESysTEDS42 . Flashcards of all three supported templates 33, 35 and 25 open.

¹⁰Only from hardware version 4.2

2. Edit data, making sure that only the data in the template = index card used is changed. The template itself, i.e. the sensor category, is selected in **Basic TEDS data -> TemplateID** . If the memory module was previously empty, all entries must be checked and, if necessary, set.
3. Click Write data to TEDS device, then enter device password.

It is also possible to write TEDS data to a file using Write TEDS data to file *and read such a file again using* Read TEDS data from file.

Adjusting Sensors with a Known Load

General sensors that do not fall under the previously mentioned categories of multi-axis sensors with calibration matrix, sensors with TEDS or rosettes strain gages for voltage measurement are usually adjusted according to the data mentioned on the test or calibration report, as shown on S. 8 shown.

If you no longer have this data at hand, or if the sensor may have changed its transmission characteristics due to aging or harsh environmental conditions, you can adjust it using an interactive process. This may also be possible when using strain gages, namely when a mechanical quantity such as force, pressure or torque leads to a significant and reproducible elongation at the strain gages.

For the adjustment process, it is necessary that a precisely known load can be applied to the sensor. It is recommended to choose this load in such a way that it either corresponds approximately to the maximum value of the range in which you actually want to measure or so that it is in the range of approx. 30% to 100% of the nominal measuring range of the sensor.

It is also necessary that the load (more precisely: the load to be measured) can be removed from the sensor. First, do this and observe the reading. If it deviates significantly from zero, it is recommended to set it to zero with Set Zero before starting the procedure.

Change Display Scaling for Input No. 2

Adjust Sensor

Sensor data | Calibration | Strain gage

Calibration Load: 196,2

Measured value: 0

Execute Calibration

Amplifier settings

Input Range: 2 mV/V

Input Type: Bridge 2mV/V

Scaling

Calculate → 2000 N

☐ Apply to all inputs of this device

Store to Device: OK / Set

Close: Cancel


Then you can start the procedure, either by *menu bar -> sensor -> Calibrate...* or by clicking on **User Scaling** and selecting the small Calibration tab :

In the example shown on the left, a force sensor with a nominal range of 2 kN is to be adjusted with a weight of 20 kg. However, it is meant to be measured in newtons. To do this, multiply the mass in kg by the gravitational acceleration factor g , the mean value of


which is 9.81 m/s^2 . The result of the calibration load in the unit to be measured is entered in **Calibration Load** .

The input sensitivity **Input Range** on the right is displayed correctly on most amplifiers.


Then click on **Execute Calibration** . You will first be asked to confirm that the sensor is load-free:



Confirm this with **Yes**. Subsequently, some readings are taken; Meanwhile, a bar display appears:




Then you will be asked to apply the load:




Do that. If this causes the sensor to oscillate slightly, wait a moment until it is still and then click OK.

Then some measurements are taken again until this message appears:



The recalculated User Scaling *value is displayed under* Scaling:



Now click OK to save the new scaling value in the device.

Startup

BlueDAQ can also be started by double-clicking on a session file that was previously saved with Save Session.¹¹ Then this session will be loaded. It is also possible to open a *.tdms measurement data file by double-clicking, then BlueDAQ is started and this file is opened with the **File Monitor**. However, if BlueDAQ is already open, this method cannot be used.

You can also start BlueDAQ with a program shortcut and call parameters, so that actions are executed automatically. This can be created in Windows in the startup menu, so that the program opens automatically when the PC starts. This is useful, for example, if measured values are to be recorded continuously, so that after a power failure or an automatic restart, this recording is started again.

Up to 3 call parameters are possible.

First parameter: There are three options for this:

1. "-l" When the program starts, the last downloaded or saved session is automatically opened, see below.
2. First Call Parameter = Complete Path to Session File (*.ucf): This device session file is loaded
3. First call parameter = Complete path to measurement data file (*.tdms): This measurement data file is opened with the File Monitor

Re 1.: If the first call parameter is "-l", up to two additional parameters can optionally be specified.

Second parameter:

"-rYt": After the session has been loaded, a recording with the Yt recorder is automatically started, see S. 9. The recording configuration defined with Configure Recording applies, see S. 58.


"-rXY": After the session has been loaded, a recording with the XY recorder is automatically started, see S. 56. Either the recording configuration defined with Configure Recording (see S. 58.) or threshold-based triggering, if it was previously enabled. Furthermore, the last selected channel applies to the X-axis

Third parameter: recording time in seconds. At the end of this time, the program will be closed. This is useful, for example, to prevent the measurement data file from becoming very large, possibly even filling up the drive.

XY Recorder

In the **Recorder XY** tab, one or more readings can be displayed over a different channel. Therefore, at least two channels must be open. In contrast to the **recorder Yt**, the measured values are not displayed according to $y = f(t)$ over time, but over another channel $y = f(x)$. The channel projected to the X-axis is selected when entering this tab.


¹¹After the initial installation, Windows may ask once if you want to open the file with BlueDAQ. If this is confirmed, Windows saves this file <-> program association.



Essentially, the XY recorder provides similar functions to the Yt recorder.

In addition, it offers a threshold-dependent display or recording. If this is active, only individual values (i.e. points that are connected to each other) are displayed, and only if the value of the channel projected on the X-axis exceeds the previously defined thresholds.


The thresholds must therefore be set in advance; to do this, please click on **Trigger Thresholds**. Then a window will open in which you can set the threshold values, which you can do manually by entering them directly (activate *manually*) or you can have the threshold values generated automatically (automatically) by entering the start, end value and increment (*From*, *To* and *Increment*).



Up to 11 threshold values are displayed here, if there are more, you can change the first one on the left with the index element on the far left (marked here in black). There are no greyed-out entries.

Then start the measurement (if you haven't already) and click on the Activate checkbox, which will then change to **Activated**.


Note: The *Configure Recording* defined settings (see p. 58) apply with trigger thresholds enabled. not.??????????? What is this „not“?



Example: XY Recorder for Force-Displacement Measurement

Software Options for XY Recorder

The question of choosing the channel of the X-axis can be suppressed, so that the same X-channel is used every time you switch to the recorder XY index card. You can do this by removing *the checkbox for Ask for selection of X-channel under Menu bar -> Options -> Preferences -> When changing to XY-diagram.*



The other checkbox in this field describes the behavior when comparing the trigger threshold of the XY recorder under XY **Trigger threshold compare**. At measurement data frequencies >5 Hz, when Fastly, without Average is not enabled, an average of approximately 200 ms is formed in the output configuration and the average is compared to the current threshold. If this checkbox is set, this is done without averaging each individual measured value.

Configuring the recording of measurement data

Clicking on the **Configure Recording** button in the Recorder Yt *or* Recorder XY **tab** opens a window in which the recording can be prepared and configured. This is only possible as long as the recording is not (yet) running, i.e. its configuration cannot be changed while the recording is running. The measurement data is stored in an efficient binary file format, the tdms format. In addition to the measurement data, it also contains metadata, so-called metadata. **Properties**. These files can be viewed and exported with the File Monitor.

Automatically start and stop recording

Various conditions for starting or stopping can be defined in the Trigger *Recording tab in the Configure Recording* dialog. The contents of this tab may change depending on the settings you choose, so it is recommended to follow the order of operation from top to bottom. First of all, the top radio button under **Start Recording** and/or **Finish Recording** must be set to **Automatically**.

Launch

The Start Trigger Type **start condition** can be the exceeding of the measured value of a given channel with a definable threshold value or (only for the BSC4D, BX6 and BX8 amplifier models) a digital level of a line connected to the digital input of the strain gage amplifier. In this case, the type of digital input is usually set to **GP input** (under the menu bar → **Device** → **Advanced Settings** → **Digital I/O**); however, this is not necessary, i.e. other I/O types may also be selected in the device settings.

- **Value exceeds threshold:** The recording is started when the measured value is > threshold value and the previous measured value was ≤ threshold value, i.e. when the threshold value is exceeded
- **Value drops below threshold:** The recording is started when the measured value is < threshold value and the previous measured value was ≥ threshold value, i.e. when the threshold value is not exceeded
- **Value change delta threshold:** The recording is started when the difference in amount of a measured value with its predecessor is greater than or equal to the threshold value, i.e. if $|\text{Reading}(k) - \text{Reading}(k-1)| \geq \text{threshold value}$.
- **Digital I/O:** Recording starts when there is a digital level change. The level edge is defined with the **Level Change Edge** switch and the number of the digital connection (line) is selected with the **Digital I/O** selection element .

For the threshold-dependent start condition, the threshold value must be entered under **Threshold Value**, and the Trigger Channel **selector must be used** to enter the channel whose measured value is to be compared with the threshold value.

If you enter a number > 0 under **Number of Pre-Trigger values** , measured values with the defined number will be recorded even before the start condition occurs. You can also set the **checkbox Auto-Create Annotation at Trigger**, so that when the trigger condition is reached, a note (*annotation*) is automatically created at this point, depending on the type, one of the texts "**Start Rec: Threshold exceeded**", "**Start Rec: Fallen below Threshold**", "**Start Rec: D-threshold exceeded**", "**Start Rec: Digital-In Rising**" and "**Start Rec: Digital-In Falling**".¹²

Under **Event Number** you can specify whether the start condition for admission is tested once or several times. If **Record single event (file)** is selected, it will no longer be checked after the automatically started recording due to the defined trigger condition. In the case of **Record several events (files)**, the trigger operation is checked again after the automatically

¹²The **Pre-Trigger Values function** is only available with BlueDAQ PRO

started recording has ended, so that several automatically started measurement data files can be generated.

Termination Condition

To automatically stop recording, you *can choose from two basic categories* under End Condition Type:

- **Time / Number of values:** After an adjustable time or after reaching a number of measured values, the recording is stopped
- **Signal Trigger:** A threshold condition or digital I/O level stops recording

Time / Number of values can be used to select one of the following termination conditions under End condition time/number:

- **Number of values:** Once the number has been reached, the recording will be stopped. To the right of it, enter the number:

- **Relative Time:** After reaching this time, counted from the start of the recording, it is finished. To the right of it, enter the time under HH (hours), MM (minutes), and SS (seconds):

- **Absolute Time (Daily file):** At the specified time, the recording is stopped and then recorded to a new file every day. The **When finished: Generate new file** checkbox is automatically checked. To the right of it, enter the time under HH (hours), MM (minutes), and SS (seconds).
- **Absolute Date, Time:** At the specified date and time, the recording stops. A new file cannot be created automatically, so the checkbox **When finished: Generate new file** is disabled. To set the date and time, click on the calendar icon on the right and select the date in the following dialog at the bottom and enter the time in the format <hour>:<minute>:<second> at the top, confirm with OK.

Signal Trigger *allows you to* select one of the following termination conditions *under End Trigger Type*:

- **Value exceeds threshold:** The recording is terminated when the measured value is > threshold value and the previous measured value was ≤ threshold value, i.e. when the threshold value is exceeded
- **Value drops below threshold:** The recording is stopped when the measured value is < threshold value and the previous measured value was ≥ threshold value, i.e. when the threshold value is below
- **Value change delta threshold:** The recording stops when the difference in amount of a measured value with its predecessor is greater than or equal to the threshold value, i.e. if $|\text{Reading}(k) - \text{Reading}(k-1)| \geq \text{threshold value}$.
- **Digital I/O:** Recording stops when a digital level change occurs. The level edge is defined with the Level Change Edge switch and the number of the digital connection (line) is selected with the Digital I/O selection element.

For a threshold-dependent termination condition, the threshold value must be entered under Threshold Value, and the channel whose measured value is to be compared to the threshold value must be entered with the Trigger Channel selection element.

Configure Recording

Save Memory Data | **Trigger Recording** | **Data Reduction** | **Auto Export** | **Advanced**

Start Recording

☐ Manually
☒ Automatically

Start Trigger Type

☒ Value exceeds threshold
☐ Value drops below threshold
☐ Value change delta threshold
☐ Digital I/O

Number of Pre-Trigger values

Threshold Value
 N/mm²

Trigger Channel

Event number

☒ Record single event (file)
☐ Record several events (files)

Finish Recording

☐ Manually
☒ Automatically

End Condition Type

☐ Time / Number of values
☒ Signal Trigger

End Trigger Type

☐ Value exceeds threshold
☒ Value drops below threshold
☐ Value change delta threshold
☐ Digital I/O

Threshold value
 N/mm²

Number of Post-Trigger values

Trigger Channel

☒ Auto-Create Annotation at Trigger

Format Measuring File Name <%d_%m_%y-%H_%M_%S> <-Default

Resulting file name example 02_05_23-15_18_16.tdms


If you *enter a number > 0 under* Number of Post-Trigger values, measured values with the defined number will be recorded even after the termination condition has occurred. You can also set the *checkbox Auto-Create Annotation at Trigger*, so that when the trigger condition is reached, a note (*annotation*) is automatically created at this point, depending on

the type, one of the texts "*Stop Rec: Threshold exceeded*", "*Stop Rec: Fallen below Threshold*", "*Stop Rec: D-threshold exceeded*", "*Stop Rec: Digital-In Rising*" and "*Stop Rec: Digital-In Falling*".¹³

For the termination conditions *Number of values* and *Relative Time*, the checkbox *When finished: Generate new file* can be activated at the bottom. This means that when the recording is finished, it is automatically recorded back to a new file and the selected termination condition is tested again.

Using Automatic Recording

After the recording configuration is closed with OK, it is saved for the next program start. To activate the automatic start of recording, the measurement must be started in the recorder Yt (or XY) by clicking on *Start measuring*. A message will appear:



The **Start** Recording button flashes while waiting for the Start Trigger condition. Once this is reached, the recording will start and the Start Recording button will switch to:



If multiple files are to be recorded, the status message "*Number of recorded files ready: I Waiting for Trigger...*"

These *.tdms measurement data files are stored in the last selected directory. To set or change this, it is recommended to start a recording manually once (i.e. with **Start Recording = Manually**), because only then a file selection window appears.

Additional Configuration Options for Data Recording

Save Memory Data *tab*:

If a measurement has been taken in *the Recorder Yt* with **Start Measuring** without it being recorded, some data can be saved afterwards. This index card has nothing to do with the actual recording configuration. It can only be accessed by clicking on **Configure Recording** in *Recorder Yt*.

Data Reduction *tab*:

Especially with a high measurement data rate or many channels, the measurement data files can become quite large. With data reduction, this size can be reduced and, if necessary, short peaks can be recorded at the same time.


¹³The *Post-Trigger Values function* is only available with BlueDAQ PRO

Recording Interval: Set to One value per time interval *to enable data reduction*, set to Record every value *to disable*.

Time interval: This is where the length of the data period is defined. It must be greater than the reciprocal of the measurement data rate of the integrated amplifiers (data frequency).

Decimating Average: If this radio button *is set to Mean values inside interval*, the arithmetic average is calculated on all measured values within the specified data interval. At the beginning of a new data interval, it is restarted (decimating averaging).

Create Additional Channels with Maximum/Minimum Values: If *Create Maximum / Minimum values* is activated here, BlueDAQ creates additional channels in the measurement data file (one for each original channel for maximum and minimum), which specify the maximum value and the minimum value in the data interval. These are determined anew at the beginning of a new data interval. Together with **Decimating Average**, average and peak values can be recorded at a relatively high measurement data rate. In the File Monitor, the channels of the maximum and minimum values are displayed in dashed lines, and the channel names are appended with "_Max" and "_Min" respectively.



Auto Export tab:

The measurement data files have a specific binary format, the *.tdms format, which can only be read by a few programs (e.g. NI Diadem) except BlueDAQ. With Auto Export, a tdms file can be automatically converted to another format, e.g. generally readable text formats, at the measurement runtime when the recording is finished. **Enable Auto-Export** must be enabled. Alternatively, tdms files that have already been recorded can also *be converted in* the File Monitor.

Select Destination file type: Specifies the file format of the exported file.

Text file (tab separator): A table file is created in text format. The readings of the channels and the time/date stamp are separated by the tab character. A

header is generated. The file extension is *.txt. If this type is selected, you can alternatively select the *format of the measurement data files that the BX6BT can write to an SD card by activating BX6* Logger Format.

CSV file (select separator): This format is *very similar to the text* file, but you can use **Cell Separator** to specify the separator for the cells and the file extension is *.csv. This format can be opened with many popular spreadsheet programs, such as LibreOffice Calc.

Excel Spreadsheet: An Excel spreadsheet is generated. The export can take a long time with large files / high measurement data rate and then also affect the system performance (in which case the csv format is more recommended).

Influx DataBase: A measurement data file in Influx format is generated. If this type is selected, the **Measurement Name** *should* be specified. You can filter out missing or (e.g. due to disturbances) extremely implausible measured values with **Eliminate missing and excess values**. An influx file can be uploaded to a measurement data database; At ME-Systems, a small additional background program is available on request, which does this.

Timestamp in UTC: For some file types, the timestamps converted to Universal Time can be entered into the exported file.

Append to selected destination file: If this checkbox is enabled, the exported measurement data will be attached to an existing file. This should already exist and be of the same file type. If you set this checkbox, please use the yellow file browser button to the right of **Destination Path of exported file(s)** to select the file to which you want to attach.

Advanced tab:

Various special setting options are summarized here.

Record Hidden Channels: If channels have been hidden with the menu bar -> **Channels -> Hide** or if hidden channels are defined in the open **session**, you can activate the checkbox to specify that they should be included.

Additional File: At the end of the recording, a second measurement data file is generated, which contains readings of all channels filtered by a maximum or minimum value condition. Filter condition and number of values can be defined. This function is **activated with the** checkbox **Create second file with filtered values**.

Filter Criterion: Specifies whether to filter by a maximum or minimum value. The entire original file is searched based on the criterion.

Number of Values around trigger / Number of values in filtered file: Number of readings per channel in the filtered file.

Channel to apply criterion: Channel to which the Max./Min filter condition is applied.

Timestamp Calculation: With the generated *.tdms file format, timestamps are not stored with every line of measured values. Instead, the start time and a time

increment dt are stored, and the timestamps are formed from it for display or export to another file format. For this reason, only time-continuous (equidistant) measurements can be recorded. This section can specify how BlueDAQ should calculate the time increment dt at the end of the recording. Note: If data reduction is enabled, i.e. *One value per time interval* is enabled in Data Reduction, these entries are grayed out because the time increment is defined by the data reduction setting.

Auto-Select dt mode: If this checkbox is activated (default), BlueDAQ decides for itself which calculation mode is to be used for dt based on predefined criteria. If there are amplifiers whose measurement data rate is considered to be insufficiently accurate, the **Calculate dt from Final time** mode is used. If all amplifiers are very precise in time and the data frequencies of all strain gage amplifiers are set in the same way (when using multiple devices), the measurement data rate of the amplifier(s) is used for the calculation, i.e. the **use device data rate mode**.

Select dt mode: If Auto-Select dt mode is not enabled, this can be used to specify the calculation method for dt.

Calculate dt from Final time: Calculates dt based on the start time, the end time, and the number of readings, i.e.: $dt = (\text{end time} - \text{start time}) / (\text{count of metrics} - 1)$.

Use device data rate: This calculates dt based on the data frequency set in the amplifier, i.e. $dt = 1/\text{data frequency}$

User defined dt: This can be used by the user to set dt (this may result in an incorrect or fictitious end time). If this method is selected, an input field **Enter Data Period** appears, in which the time increment dt must be entered in seconds.

Resulting dt: When using the **Use device data rate** or **User defined dt** methods, the resulting time increment is specified here.

Replace Missing values: In case of connection stability issues, this option replaces missing readings from a device (determined by timeout counting) with a very high marker value of 1E+300. If **Eliminate missing and excess values is enabled** under **Auto Export**, these values will be omitted when exporting to the **Influx DB** format. Do not use this option under normal conditions, especially when triggered recording is activated by threshold or with software-calculated special sensors!

Formatting the file name

In the Format Measuring File Name **input mask** at the bottom of the window, the name of the measurement data files can be formatted. It then applies to the tdms files and possibly also to exported other formats and consists of the date and time of the start time of the file in the initial configuration (default). This is indicated by the format string **<%d_%m_%y-%H_%M_%S>**. You can enter almost any text before or after the time/date format string, i.e. before < or after >. The special characters % [] \ / : * ? " < > | are to be avoided. In the case of **files that are automatically started by Trigger Recording**, [No] can also be appended, which automatically appends high-counting numbers to the file names. With

the Default button on the right, the entire format string can be reset to the initial configuration. Within the formatting codes, including < and >, almost any text and character may be used, except [] \ / : * ? " < > | and the % character, which initiates a formatting code. These are:

Code	Meaning
%a	Abbreviated day of the week (e.g. Mon)
%A	Full weekday name (e.g. Monday)
%b	Abbreviated month name (e.g. Jan)
%B	Complete month name (e.g. January)
%c	locale-specific default date/time formatting
%d	Day of the month (01-31)
view item	Hour (24-hour format) (00-23)
%l	Hour (12-hour format) (00-12)
%j	Day number of the year (001-366)
%m	Month number (01-12)
%M	Minute (00-59)
%p	AM or PM Entry
%S	Second (00-59)
%U	Week number of the year (00-53), where the first Sunday is the first day of the first week
%w	Day of the week as a decimal number (0-6), where 0 represents Sunday
%W	Week number of the year (00-53), where the first Monday is the first day of the first week
%x	locale-specific date
%.1x	long date format
%.2x	abbreviated long date format
%X	locale-specific time
%y	Year within the century (00-99)
%Y	Year, including century (e.g. 2023)
%z	Difference between local time and UTC (HH:MM:SS)
%Z	Time zone name or abbreviation (depending on the operating system's local settings)

Example 1: **Format Measuring File Name:**

My measurement<Am%d-%m-%y at%H-%M-%S> o'clock[No]

yields the file name:

"My measurement on 15-05-23 at 11-41-15 Uhr_01.tdms"


Under *Resulting file name example*, an example of the file name is displayed.

Note: The generated names of the measurement data files must not appear more than once in the same directory. In the case of default formatting, this is ensured by the fact that the file name contains the time with seconds (since several files cannot be recorded within one second anyway). A time format is recommended or, if recording starts automatically, the function tag [No], which generates sequential numbers.


Using the File Monitor

By clicking on **File Monitor** in the *Configuration* tab opens a window that opens a *.tdms file. Alternatively, a measurement data file in text format can be opened, which was generated by one of the data logger devices BSC2MSD-DI or BX6Bt. In this case, the *.txt file is converted to a *.tdms file before opening and the user is asked for the location of the generated tdms file. The TDMS tools offer further possibilities, see S. 129

The measurement data can then be viewed, checked and exported. When opening and changing the tab, the following warning message may appear for large files:




It means that only 200000 consecutive readings of the file have been opened. You can change this by setting the number of values to be opened under Settings or by selecting **Load All Values**:



The opening data set options can be set separately for the *Values (table)* = table of values and *Analogue values (graph)* = graphical view.

If you choose **Load all values**, it may take a long time to open.



At the bottom of the status bar, the number of loaded values is indicated by **Loaded values**.

Under **File content**, the tree view on the left, select the channels to be displayed. If **Measuring values** is selected, all channels are displayed. To display multiple channels, select them by holding down the Ctrl key at the same time.

Channel names and colors are the same as those used in the measurement.

Properties displays the file's metadata, see Appendix. Some settings of the measurement with which the file was created have been stored here.

Values (table) is a numerical table of values.

TDMS-File monitor

File content: 16_05_23-13_50_30.tdms

Measuring values: Dev3_1, Dev3_2, Dev3_3, Dev3_4, Dev3_5, Dev3_6, Dev3_7, Dev3_8

Properties | Values (table) | Analogue values (graph) | Press F12 or F11 (append) to copy values at

Date/Time	Measuring values Dev3_2	Measuring values Dev3_4	Measuring values Dev3_6	Measuring values Dev3_8
16.05.2023 13:50:38,45731	1812,727892	3,809508	3,880245	3,829498
16.05.2023 13:50:38,55731	1826,291066	3,824598	3,877682	3,816160
16.05.2023 13:50:38,65731	1838,746044	3,836191	3,877036	3,805143
16.05.2023 13:50:38,75731	1849,919776	3,844895	3,877086	3,787616
16.05.2023 13:50:38,85731	1860,670305	3,856502	3,872333	3,770414
16.05.2023 13:50:38,95731	1871,373796	3,862993	3,867060	3,752027
16.05.2023 13:50:39,05731	1880,608815	3,870695	3,860024	3,732109
16.05.2023 13:50:39,15731	1889,204953	3,874814	3,851664	3,712129
16.05.2023 13:50:39,25731	1898,314847	3,877140	3,840508	3,687902
16.05.2023 13:50:39,35731	1906,822560	3,877985	3,827447	3,663640
16.05.2023 13:50:39,45731	1911,537611	3,880855	3,818433	3,637897
16.05.2023 13:50:39,55731	1918,481537	3,877408	3,803588	3,613590
16.05.2023 13:50:39,65731	1922,244115	3,877601	3,786564	3,582795
16.05.2023 13:50:39,75731	1926,805470	3,872142	3,767978	3,552314
16.05.2023 13:50:39,85731	1930,868783	3,865277	3,751731	3,521560
16.05.2023 13:50:39,95731	1935,269592	3,861679	3,731973	3,489833
16.05.2023 13:50:40,05731	1936,808985	3,850917	3,709582	3,456958
16.05.2023 13:50:40,15731	1938,568682	3,842690	3,685600	3,419509
16.05.2023 13:50:40,25731	1940,016342	3,830553	3,661486	3,385420
16.05.2023 13:50:40,35731	1939,331664	3,817621	3,636809	3,346384
16.05.2023 13:50:40,45731	1939,476795	3,802815	3,611600	3,310527
16.05.2023 13:50:40,55731	1937,313643	3,785934	3,582681	3,270587
16.05.2023 13:50:40,65731	1935,605650	3,767000	3,554791	3,229152

Settings... Loaded values 0 ... 1049 Export Cancel


Analogue values (graph) is the graphical view. There are more options here.

At the top right are three small buttons for tools with the following basic meanings:

Left button: Move cursor (see below)

Middle Button: Zoom Options


Right button: Move image section by dragging with the mouse button




After selecting the zoom option, the zoom section can be selected by dragging with the mouse button (holding down the left button). Alternatively, the vertical mouse wheel can be used to zoom. The zoom option at the bottom left means: Everything is visible. Alternatively, this can be achieved by

right-clicking in the graph and selecting Autoscale X / Y or turning it off and on again (if already selected) or turning the mouse wheel down.

Using the cursor




To display one or more cursors, the cursor menu must first be displayed. To do this, right-click in the graph and select **Visible Items->Cursor legen**.



At the bottom right, the cursor legend appears.

Right-click on it and select **Create Cursor->Single-Plot**. With the *single-plot* cursor you have the most possibilities. The cursor is associated with one of the displayed channels. The coordinates are displayed, with the X coordinate in Yt diagrams corresponding to the time and Y to the

reading of that channel.



To change the channel assignment, right-click on the cursor number, here cursor **0** in the cursor legend and select **Snap to**. A channel list appears, but only the top entries can be used, i.e. those whose names belong to visible channels.


The coordinates are also displayed in the status bar at the bottom, the time here with higher resolution for measurements

with high data frequency.



The cursor appears as a yellow line cross in the graph. In order to be able to move it, the corresponding tool must be selected from the three small buttons above (see above). In addition, the vertical yellow line of the cursor must be visible in the zoom section. If this is not the case, you can display everything as shown above and zoom back in if necessary.

You can create a second cursor with Create Cursor as shown above, and then you have more options. Firstly, the coordinate differences are displayed in the status bar, and secondly, the function keys can be used to copy a temporal range of measured values as text to the clipboard, instead of just one value per channel.




In the image above, you can see how you could determine the period of a signal, for example. Two cursors are generated, both of which are assigned to the same channel (=plot) (here "Dev3_2"). You can also move the active cursor, which is highlighted in yellow in the legend, with the arrow keys, e.g. so that dY in the status bar becomes as small as possible. then you can read the period with dt ; here 32.3 seconds.



Copying and Exporting Metrics

Exporting to other file formats


The entire file, i.e. all temporal readings, can **be converted to another format** by clicking on the Export button.



The file types and options are the same as those at **Configure Recording** -> Auto Export tab: Called. In addition, you can use the radio buttons under **Export** whether all channels should be exported (**All Channels**) or only the ones marked on the left in the construction view (**Selected Channels**). After clicking OK, a file selection dialog opens. If you enter a suitable, already existing file, the measurement data will be attached; otherwise, a new file will be created with headers and/or column headers. The first column always contains a timestamp with the date and time.

As with automatic export, notes (annotations) are inserted in the last column **for the target file types** Text file and **CSV file**, and **at the corresponding point** in time for plot-bound **annotations**.

Further export options are offered by the right-mouse button context menu of the graphical view (mouse pointer in the graphic, right mouse button >export):




This means that only the data visible in the graph will be exported.

- **Export Data To Clipboard** copies the data as text to the clipboard in the following format (here only one channel and two lines):

```
-Khan. 17_3      Time - Chan. 17_3
14:31:37,106 25.05.2023      -0,789969
14:31:37,106 25.05.2023      -0,791009
```

A separate timestamp column is created for each channel. Timestamps and readings are separated by tab; Date and time with spaces.


- *Export Data To Excel* opens Excel (if available on your PC) and inserts the data, creating a timestamp column for each channel. The file can then be edited and saved with Excel if necessary.
- *Export Simplified Image* provides the option to export the graph as an image. You can select the format and enter whether the image should be copied to the clipboard or saved as a file. The background of the image is white, the plot color remains unchanged, see image below.




Copy to clipboard

In principle, data stored on the clipboard can only be pasted into suitable other programs, i.e. data in text format into text or spreadsheet programs and images into image processing programs.

The above-mentioned possibilities are those of the right-mouse button context menu of the graphs: Right mouse button>export>export Data To Clipboard to copy the visible area as table text and ->Export>Export Simplified Image->Export to Clipboard to copy the image to the clipboard, which then looks like this, for example:



Similarly, an image can also be copied to the clipboard by right-clicking>Copy Data. In this case, the image corresponds more to the view of the graph in *the File Monitor* window, i.e. the background is black, e.g.:



You can also Individual measured values or copy selected areas to the clipboard as text. To do this, you need one or two Cursor, as described in Using the cursor must first be generated. Then you can do the following by pressing the function keys F11 or F12:

- F12: Copying the readings of all channels marked on the left in the tree view at the cursor position
- F11: Append the measured values of all selected channels at the cursor position to the Clipboard table text data
- Hold Ctrl and F11: Copy all temporal readings of all selected channels as table text between two cursors. To do this, two cursors must have been created.¹⁴
- Hold the Ctrl key and F12: Append all temporal readings of all selected channels as table text between two cursors to table text data,¹⁴ which is already on the clipboard.

These copy functions with F11/F12 only copy the measured values without a timestamp. The readings are separated by tab characters.

¹⁴Copying the area between two cursors is only available with BlueDAQ PRO

Copy and paste at measurement time

Even while a measurement is running, measured values can be copied to the clipboard in order to be able to paste them into other programs (e.g. word or table processing).

With BlueDAQ PRO it is also possible to insert a configurable string (text) with measured values directly into other programs, either by pressing a function key or automatically by exceeding threshold values.

Copying Metrics to the Clipboard

If at least one measurement channel is open and BlueDAQ has the input focus, pressing the F12 function key will copy text from measured values to the clipboard. If the clipboard already contains text, pressing F11 to the clipboard appends text from measured values. This works regardless of whether a measurement has been started in the recorder Yt/XY or not. The formatting of the measured value text cannot be changed in the standard variant (default format) and is as follows for multiple measurement channels:

<Measured Value Channel 1><TAB><Measured Value Channel 2><TAB><Measured Value Channel N>

Example with 6 channels:

-0,004810 0,230499 0,083257 -0,098635 0,094652 -0,870234

If F11 is used to append measured values, a line break is inserted before the measured value text, e.g.

Text to clipboard

-0,004293 0,210927 0,108514 -0,122475 0,083306 -0,860497


This allows you to create several lines of measured values by placing the first one on the clipboard with F12 and then adding more with F11, e.g.:

-0,004248 0,198070 0,101477 -0,120024 0,089766 -0,856605
1,996082 0,214995 0,107485 -0,129403 0,104570 -0,860058

Inserting a measured value text into other programs using the F key¹⁵

If another program has the input focus, a text string with measured values can be inserted into it by pressing a function key. This feature can be configured under Menu Bar>Options>Copy & Paste:

¹⁵This feature is only available with BlueDAQ PRO



For example, with the configuration shown here, when pressing F2 in another program, the following text is inserted:

My values: 1,996199

0,184941 0,098549 -0,111647 0,104588 -0.882169 First: 0.033925

Pasting into another program must first be enabled by using the menu bar>Action->Enable Value Paste by F<no> or pressing F10. It is not relevant whether a measurement started with *Start Measuring*. If Paste to external enabled is enabled, "*Paste to external enabled*" will appear in the status bars of the main window.

Specifically, the controls in *Options>Copy & Paste* mean:

- *If* this checkbox is checked, the Paste function will be activated immediately and when the program is restarted. "*Paste to external enabled*" will then appear in the status bars of the main window.
- *Include All Channels* When enabled, all existing channels are inserted into the formatting string *Output Format*. Otherwise, the channels inserted there can be selected individually with Channels to Paste.
- *Include Units* If this checkbox is set, each metric is appended to its configured unit, with a space between the value and the unit.
- *Include Timestamp* If this checkbox is set, a timestamp with a date is inserted at the beginning of the measured value text (default). Its format depends on the Windows language setting (locale) and is as follows: TT for German . MM.YYYY HH.MM.SS,bbbb e.g. 8/8/2023 6:43:46.09986 PM
- *Decimal Separator = Period* If this checkbox is set, a period will be used as a decimal separator in any case, even in German Windows; otherwise - depending on the Windows language setting - a comma may be used.

- **Copy by F11/F12: Settings**
 - **Auto-format F11/F12 string** If this checkbox is not set, the measured value text, which is copied to the clipboard with F11/F12 when focusing on BlueDAQ, will be formatted in the same way as defined here. Otherwise, i.e. if the checkbox is set, the Copying Metrics to the Clipboard default formatting.
 - **Regular Newline with F11** If this checkbox is set, if **Auto-Format F11/F12 string** is not set, a line break will always be inserted first when pressing F11.
- **Function key for pasting** This should be the function key that is used to insert the measured value text into the other program. **Note: It is highly recommended to select a function key here that does not trigger any or no relevant function in the other program in which you want to insert**. The user manual of that program can be useful for this purpose, or you can try it out first. Otherwise, both functionalities are likely to be triggered, which can lead to problems (possibly malfunction or even crash of this other program).
- **Value Type to Copy/Paste** Here you can choose whether to insert the measured values of the main display or those **of the single value display** of the **recorder Yt**.
 - **Actual Values** The main display of "normal" current metrics is inserted as they appear in the **Value Display** and **Configuration** tab
 - **As Shown in Single Value Display** The numerical display of the **Single Value Display** in **Recorder Yt** can be switched between different display types, see Recorder Yt. If this radio button is selected, the converted values displayed here will be used for insertion.
- **Channels to Paste** If **Include All Channels** is disabled, measurement channels can be added to the measurement text to be inserted by checking the corresponding checkbox. In the middle is the channel name and on the right is the channel number. Hidden channels cannot be selected. When selecting a channel checkbox, the placeholder for the measurement value of this channel **{channel name}** appears in the formatting string **Output Format** and from the first value the default separator \T is inserted between measured values. **Output Format** can be edited manually at the end and ultimately applies to the generation of the text to be inserted.

The Formatting String *Output Format*


In the formatting string, any text can be written between the placeholders for variable entries, i.e. measured values **{channel name}** and timestamp **{date time}**, which then appear in the output text. In these texts, the special characters

\T for a tab indentation (TAB) and

\N for a line break can also be used anywhere.

It is also possible to change the channel order. However, the channel names must be spelled exactly correctly.

For example, this configuration:



with the formatting string:

My values: {DateTime}\TNo.1: {Chan. 17_1}\T{Chan. 17_4}\T{Chan. 17_6}\NThat's all

Insert the following text (measured values & timestamps are variable, of course):

My values: 08.08.2023 18:49:31,09163 No.1: 1.995757 mV/V -0.117022 mV/V -0.857558 mV/V

That's all

If you change the channel order to, for example:

My values: {DateTime}\TNo.4: {Chan. 17_4}\T{Chan. 17_6}\T{Chan. 17_1}


The following text is generated:

My values: 08.08.2023 18:57:55,31113 No.4: -0.094565 mV/V -0.869309 mV/V 1.995695 mV/V

Insertion of a measured value text into other programs via trigger¹⁶

Measured value texts of this type can also be automatically inserted into another program by exceeding or falling below configurable threshold values (instead of pressing a function key). This can be used, for example, to output measurement value strings at pre-configurable reference points or waymarks or similar. It can *be configured in* Menu Bar>Options Trigger & Paste:

¹⁶This feature is only available with BlueDAQ PRO




If the following four conditions are met, a metric text is inserted into a different program:

- The measurement was *started in* the recorder Yt
- The Trigger Paste function was activated with the function key F8 or menu bar>Action->Enable Trigger Paste
- The other program to insert into has the input focus
- The threshold condition is met, i.e. the measured value of the *trigger channel* has exceeded or fallen below the current threshold

Those controls *in Options-> Trigger & Paste that have the same name as in Options-> Copy & Paste* also have the same function with respect to the measurement value strings exported via trigger condition. Furthermore, there are the following:

Edit Thresholds:

When clicked, a window opens with which the threshold values can be defined.



In it mean:

- The small number at the top left (here in the picture =0) is the index of the first threshold value displayed. It is important to use them (e.g. with the small arrow keys to the left of them) if the number of threshold values is >11; otherwise, it should be =0 to see all thresholds.
- The numbers to the right (top) are the thresholds. These can always be changed manually. A greyed-out entry means "not present"; you can also delete a threshold value by right-clicking on it and selecting **Delete Element**. The threshold values should be selected in a regular order, which should match **Threshold Mode** (in the **Options** window), see below.
- With **Create trigger thresholds = Automatically**, the threshold values can also be generated automatically with even distances. To do this, the first threshold value is entered under **From**, the distance under **Increment** and the last threshold value under **To**. You can have them created either only ascending (**Choosing directions = Ascending** only) or ascending and **descending**. If you have configured this, the threshold values are created by clicking on **Auto-Create (Calculate)**.
- To set the final button, click **OK, Close**

Other controls in **Options > Trigger & Paste**:

- **Trigger Channel**: Selects the channel whose readings are to be compared with the thresholds.
- **Threshold Mode**: Specifies whether the thresholds are in ascending and/or descending order and whether the trigger event should be triggered when a threshold value is exceeded or undercut:
 - **Ascending only**: The threshold values are in ascending order and are triggered when a threshold value is exceeded (i.e. when the measured value becomes > threshold value)


- *Ascending, then descending:* The first thresholds are in ascending order and are triggered when a threshold value is exceeded, the last thresholds are in descending order and are triggered when a threshold value falls below
- *Descending only:* The threshold values are in descending order and are triggered when a threshold value falls below a threshold value (i.e. when the measured value becomes < threshold value)
- *Execution* This can be used to specify whether the threshold-related output of measured value strings should continue to occur after a threshold set has already been completely traversed (*multiple times*) or not (*only once*).
- *Create Annotation for Recording:* If this checkbox is set, *annotations* are set for the trigger events, i.e. notes that give short texts to the recorded tdms files at these points, which are displayed in the File Monitor, namely "*Threshold No <nummer> exceeded*" or "*Value below threshold No. <Num>*" (threshold value below).

Annotations in Measurement Files


It is possible to add text to recorded *.tdms measurement value files, e.g. to store information about the type or conditions of the measurement with the measured value curves. These texts are displayed in *the File Monitor* and can also be exported to text formats. They can be set during the measurement or afterwards in the *File Monitor*.

Setting Notes While Recording a Measurement

After a measurement value recording has been started, e.g. with *Start Recording*, notes can be set by right-clicking in the graph of the recorder *Yt* (or *recorder XY*) and then selecting *Annotation* in the context menu. dials.




Then the *annotation* window opens.



The test cursor is automatically placed in the top text input line, so that you can enter the new text right away. The note can *be assigned to a specific channel or unassigned* (Free) using **Assigned Channel**. You can also edit previously set texts here.


It is also possible to enter texts before the recording has started, they will then be added to an upcoming recording. The assigned time is then the start of the recording.



The checkbox **Delete Annotations for next Recording after this recording has finished** is then valid for the next but one recording, as none is currently running. So, in any case, the note will be added to the upcoming recording; if this checkbox is set, it will then be deleted so that the next recording no longer contains it; if it is not set, the *annotations* are added to each recording. This behavior can also be set under Menu Bar -> **Options** -> **Preferences** ->

At **Start Measuring** using the Delete Annotations *checkbox* , which has the same function. If it is set, all notes that were added to the last recording will be deleted when a new recording is made.


In the File Monitor, the notes are only displayed with Yt data¹⁷:



A text assigned to a channel is marked with an arrow on this plot, while a free text is not. The arrow also points to the time at which **Annotation...** has been clicked.



The cursor pointer can be used to move the position of the text or the time/arrow:




Once you have done this, when you close the File Monitor, you will be asked if you want to save the file, because this information (text and time position) is also saved.

If the tdms file is exported to a text format (**Text File** or **CSV File**), the notes in it will be inserted in the last column, at the time they were set. **When exporting to Excel, InfluxDB, or BX6 format, the notes are not exported.**


¹⁷If they were set in the XY Recorder, they are present but cannot be displayed. If you go to Settings... Show XY Data as Yt Diagram enabled, they will be displayed. They are also exported when exported to a text format.

Setting Notes in the File Monitor



You can also *add new notes to the File Monitor* by right-clicking on the graph and selecting *Create Annotation* from the context menu .

The text is then entered in the following window under *Annotation Name* :



The note can *be assigned to a specific channel* (Snap to One Plot) *or defined as unassigned* (Free) using *Lock Style*. The assigned channel is selected with *Locked Plot*.

When you close the *File Monitor*, you will be asked if you want to save so that the new notes are saved as well.

Offset and Zero Point

The *Set Zero* button in *the Configuration* tab causes the amplifier to set the raw input value to zero. In doing so, he determines a summand "raw offset", which he adds to the raw measured values.

In the case of multi-axis sensors and voltage measurement with rosette strain gages, all associated input channels must be set to zero so that the calculation of the physical quantities remains correct. As a result, this button is grayed out for channels that belong to multi-axis sensors. Instead, use *Set All Zero* in the Recorder Yt *or* Recorder XY *tab*.


In the case of the BSC2, BX6 and BX8 amplifiers, a user offset can also be used, which the amplifier adds after multiplying by the scaling factor (*user scaling*). Measurement processing can be mathematically expressed as follows:

$$\text{Measured Value} = (\text{Raw Reading} + \text{Raw Offset}) \times \text{Sensor Scale} + \text{User Offset}$$

For standard sensors, the sensor scaling corresponds to a multiplication by the *User Scaling*, for multi-axis sensors it is a more complex calculation (see p. 39 or S.46).

This means that user *offset* can also be used for multi-axis sensors for individual channels. It is displayed in the *Configuration tab* under *User Offset / Tare*.

If you click on this number, you will be taken to the dialog for setting the user offset:




You can use it to enter a new offset *directly in New User Offset* and save it with **OK / Set** or have a new value calculated. To do this, enter the desired measurement value in **Desired Measuring Value** (or leave 0 here) and then click on **Calculate**. Some measured values are automatically taken and the calculated value then appears in **New User Offset**. Save to device *with* **OK / Set**.

Limitations of Zeroing


For PT1000 and Type K temperature sensors, zeroing with **Set Zero** in the initial state is not permitted, and the same applies to the single-ended voltage input.

If you click on **Set Zero**, this message appears:



In the case of voltage inputs, you often want to measure the absolute voltage, like a voltmeter, and a change in zero point would falsify this. Even when measuring temperature, zeroing would falsify the measurement, unless the sensor has a temperature of 0°C.

To remove these restrictions, click on Options in the menu bar and select the **Hardware tab**:




To allow zeroing for voltage inputs, leave **Prohibit for temperature inputs** in the upper left corner *and clear the check box* for **Prohibit for single-ended voltage input**. In the case of BSC4D, the check box for **Allow for single-ended with BSC4D** *must* also be checked. In this case (BSC4D) the password **berlin** must be entered. Confirm with **OK** at the end.

To also allow zeroing for temperature inputs, you have to select **zero Always allow under Allow Set**.

This configuration - like all settings in the **Options** menu - is not stored in the amplifier, but in the software settings.

Restricting Zeroing for Single Channels

The BX8 also allows you to configure the zeroing behavior for bridge Multi-dim sensor??? Check in source! the device settings.¹⁸ This can be set in the Input Type dialog under Setting Zero Behavior:



Sebastian wetz
2023-10-21 03:17:00

Multi-dim sensor??? Check in source!
Setting Zero Behavior:

The following options are possible:

- **Set Zero allowed, Relative Measuring**
- **Set Zero prohibited, uses calibrated zero-point. Absolute measuring:** Zeroing is prevented and absolute ("true") voltage or bridge detuning is measured. The raw offset used (see above) is a manufacturer's calibration value that only compensates for internal offset errors of the amplifier, not external ones. The currently set RohOffset may be lost.
- **Set Zero prohibited, uses actual / primary zero-point:** Zeroing is prevented and the currently set raw offset is left unchanged.

Memory behavior of the zero point on the BX6




With the BX6, it is possible to specify under the menu bar → **Device** → **Advanced Settings** → **Administration** whether the zero point should be stored non-volatily. This is the case in the delivery state (and fixed for all other starin gage amplifiers), i.e. after a zeroing with **Set Zero / Set All Zero**, the zero point is restored after switching the device off and on (**Store value non-volatile**). If you turn off saving (**Don't Store (volatile)**), the zero point is lost after turning it off and on. This setting can be useful if the zero adjustment is triggered very often, e.g. by a machine or a system, for example as a lump sum before each measurement process. This is because the flash memory of the zero point (and all other operating parameters) wears out and disabling the memory prevents the maximum amount of memory from being exceeded.

Auto-Zero

The BSC2 and BX8 devices can be configured to perform a zero adjustment on their own under certain conditions, namely when the reading remains within a range around zero for a

¹⁸Firmware version 1.54 or higher

certain amount of time. This time interval and range can be set in the menu bar → *the device* → *Advanced Settings* → *Value Mode* → *Auto-Zero*.



This function can be useful, for example, to suppress thermal drift of a sensor; in this case, the threshold would be set close to zero and care would be taken when measuring that the load is removed frequently and then for a sufficiently long time. When measuring a continuous load that never goes to zero, the Auto-Zero function is less suitable; the BSC2


provides a special drift compensation algorithm for this application, see below.

In the BSC2, the Auto-Zero threshold is the same as the lower threshold switch No. 1, i.e. a zero adjustment is performed after the specified time when threshold switch 1 is inactive.

The time interval of BSC2 and BX8 is stored internally as a count that counts measured values, i.e. after a change in the measurement data rate, it may have to be reset.

After changing the settings, click **Store to device** at the bottom .

With the BX8, the auto-zero conditions can be linked between channels. These advanced settings open after clicking on **Drift Compensation More...**



At the top are settings that apply to all channels, while those at the bottom are for the *input channel selected* with Channel.

- **Auto-Zero enabled:** This allows the entire function to be enabled and disabled globally.

- **If Condition(s) met: Time Interval to Set Zero:** Displays or sets the time interval after which the zeroing will occur if the other conditions are met. Internally, it is stored as a counter value, see above.

- **Channel Handling:** Here you can choose whether the threshold condition is checked independently for each channel or for all channels together:
 - **Independent from each-other** means that the time interval for each channel is counted independently and individually, as long as its reading is within its respective threshold range, as long as the channel is configured accordingly.
 - **Grouped: Conditions ANDed** means that if all channels with Apply Threshold Condition for this Channel enabled remain below their individual threshold, the time interval will continue to be counted.

The measured values are set to zero when the time interval has expired and **Perform Auto-Zero for this channel** is activated for this channel.

- **Channel:** Selects the channel for which the following settings apply unless **Apply the same settings for all channels** is enabled.
- **Perform Auto-Zero for this Channel:** Auto-zero this channel when the other conditions are met.
- **Apply Threshold Condition for this Channel:** If **Grouped: Conditions ANDed** is also active, this can be used to select whether the threshold condition for time interval counting is checked for this channel, see above.
- **Value Range, where Auto-Zero is applied after time interval is reached:** Here, the threshold range is set around zero, where the value *must be in From* < 0 and in $To > 0$, and it is: $From = -To$. It is best to enter only the positive one in *To*, *From* will then be set automatically.
- **Apply the same settings for all Channels:** If enabled, the channel-specific settings apply equally to all input channels.

In the end, changes are saved with **store to device**.


Analog and digital filters

Filters act in the frequency range of the measurement signal, i.e. they only allow a certain frequency range to pass through and the other ranges are attenuated (attenuated). All strain gage amplifiers originally act as low-pass filters, i.e. they process measurement signals of constant magnitudes with $f=0$ up to a certain cut-off frequency f_g . The cut-off frequency is the signal frequency at which the amplitude is already attenuated by -3dB, i.e. by a factor of 0.707. In the case of a low-pass, the attenuation increases further above this cut-off frequency. In the case of digital amplifiers, this results from the measurement data rate (see p. 16), the analogue pre-filter and, if necessary, an additional digital filter, see p. 90. The lowest of these two or three low-pass cut-off frequencies is effective for the bandwidth of the measurement signal.

Analog Filters

All digital strain gage amplifiers have an analog pre-filter, which is located in front of the AD converter in the signal processing chain. Usually, its cut-off frequency is half of the maximum measurement data rate or less.

The settings of the analog filter can be changed on the BSC2 and BX8 under the menu bar → **Device** → **Advanced Settings** → **Filter** → **Which Filter = Analog**:



In the BSC2 and BX8, the analogue cut-off frequency can be switched in three stages. In the initial configuration, **Set automatically, according to data rate is** set and then it is set automatically based on the measurement data rate:

Model (additional condition)	Measurement data rate	Analog Filter: Cut-off Frequency
BSC2 (without FIR filter, see below)	Less than or equal to 7.14/s	3.5 Hz
	From 96 to 625/s	260 Hz
	Greater than or equal to 625/s	1700 Hz

Model (additional condition)	Measurement data rate	Analog Filter: Cut-off Frequency
BSC2 (with FIR filter, see below)	Less than or equal to 15/s	3.5 Hz
	From 15 to 1071/s	260 Hz
	Greater than or equal to 1071/s	1700 Hz
BX8	Less than or equal to 80/s	28 Hz
	From 96 up to and including 3000/s	850 Hz
	Above 3000/s	11400 Hz

The cut-off frequency is displayed under **Lower Cut-off frequency [Hz]**. If **Set automatically, according to data rate** is not set, the cut-off frequency can be selected manually with Cut-off frequency.

Since the BSC2 and BX8 are both equipped with Sigma-Delta AD converters, the original input sampling frequency is in the Mhz range and the analog pre-filter therefore also acts as an anti-aliasing filter for each of the three setting options.

Digital Filters

Digital filters are implemented in the device's software, i.e. they process digital (discrete-time and discrete-value) signals. Basically, there are two different types of strain gage amplifier devices: FIR and IIR filters. In the case of digital filters, the cut-off frequencies depend on the measurement data rate; it is always less than half of the measurement data rate and actually acts as a divisor (i.e. a factor <1) to the measurement data rate. Therefore, if the data rate changes, the cut-off frequency changes accordingly. BlueDAQ displays the measurement data rate in the configuration window.

FIR Filter

A FIR (Finite Impulse Response) filter processes only one sequence of input readings, this sequence consists of the current and past, unfiltered readings. It is always stable, i.e. the output signal does not contain any artifacts, regardless of the filter settings and the input signal, so it corresponds to the input signal or the input signal with a smaller amplitude. However, like all filters, it requires a certain time delay, the filter runtime.

An important parameter is the filter order, which determines how steep the transfer function is in the attenuation range. The higher the order, the steeper it is, i.e. frequencies above the cut-off frequency are more attenuated; however, the runtime is also longer at higher order, see pictures below.


The BSC2, BSC1 and BX8 devices offer FIR low-pass filters, they are configured under the menu bar → **Device** → **Advanced Settings** → **Filter** → **Which Filter = Digital FIR**. At the bottom left, the filter can be **enabled or disabled** with **Use Filter**.

BSC2: Two different switchable FIR filters can be switched on, one of the second order with the -3dB cut-off frequency = measurement data rate * 0.18. Its transfer function is smooth, with no overshoot in the jump response and it has a runtime of only 3 readings.

Also, a 5th order with cut-off frequency = data rate * 0.23. Its transmission function is much steeper in the damping range, but with about 6% overshoot in the jump response; in addition, the runtime is 6 readings.


BSC1: The BSC1 only offers the 2nd order FIR filter with the same characteristics as the BSC2.

BX8: With the BX8, the FIR low-pass filter can be set individually for each channel, with the desired cut-off frequency being entered under **Cut-off frequency [Hz]**. The filter order can be selected manually under **Filter Order** or set automatically if the **Set Automatically** checkbox next to it is set. The value range ranges from 4 to 14 in steps of two (i.e. only even orders are possible). If the filter order is selected automatically, the filter is optimized for runtime, i.e. the lowest possible order is selected. The nominal attenuation in the restricted range, i.e. above the cut-off frequency, is fixed at 60dB.



FIR with $f_g = f_a / 10$:

Order=8 automatically selected. Attenuation -60dB at $2/3 \times f_a$ reached.



FIR with $f_g = f_a / 10$,

attenuation -60dB at max. order=14 already achieved at $f_a/4$.

IIR Filter

IIR filters can be configured individually for each channel of the BX6 and BX8. An Infinite Impulse Response (IIR) filter handles both a sequence of input values and one of output values from previous filter runs. As a result, a better filter characteristic in the frequency range can often be achieved at a lower order. IIR filters can be unstable, but BlueDAQ's calculation algorithm avoids unstable results. Under certain circumstances, one of the following error message texts is displayed:

"DLL.Dfilter: Digital filter calculation failed to converge"

"DLL.Dfilter: Resulting coefficients discarded, because they may limit measuring precision (gain too big)"

The filter order is set to four. With the IIR filter, *you can choose between four different filter types (characteristics) with Filter Type, which differ in whether low or high frequencies or certain frequency ranges are transmitted or attenuated.*

- **Low Pass:** Low frequencies below the cut-off frequency are allowed through, above they are attenuated. Application example: Interference or vibration suppression for specific input channels.
- **High Pass:** Frequencies above the cut-off frequency are allowed through, below which frequencies are attenuated. This also suppresses a constant size ($f=0$). Application example: Vibration measurement or detection of temporal changes (transients).
- **Band Pass:** Frequencies below the lower cut-off frequency (lower cut-off frequency) and *above the upper cut-off frequency* (upper cut-off frequency) are attenuated and frequencies that fall between these two *cut-off* frequencies are allowed through. Application example: Measurement of vibrations in a certain frequency range.

- **Band Stop:** Frequencies between the lower cut-off frequency and *the upper* cut-off frequency are attenuated. Application example: Suppression of a certain interference frequency or vibration.



Filter configuration and simulation with BX6 and BX8

Typically, the controls in the menu bar are → **Device** → **Advanced Settings** → **Filter** in order from top to bottom. If you want the configuration to be different for the input channels or if you only want to apply to one channel, you first select it with **Input Channel** from. If filters are already configured, this will be displayed under **Configured filter(s)**, namely: **None** (never configured) **IIR**, **FIR** or **FIR and IIR** (both). With **Which Filter** With the BX8, you can choose between **IIR** and **FIR**. With **Filter Type** you select the characteristic of the IIR filter (**Low Pass**, **High Pass**, **Band Pass** or **Band Stop**, see above). If the filter has only a cut-off frequency (**Low Pass / High Pass**) it shall be **Cut-off Frequency** displayed or operated. If it has a lower and an upper one, it will be **Lower Cut-off frequency** (lower) and **Upper Cut-off frequency** (upper). In the case of the FIR filter, the filter order can be changed under Filter Order (see S. 90).


By clicking on the **Frequency Response**→**Show button**, the filter is simulated in the frequency domain. The frequency in the range $f=0$ to $f=F_a/2$ is plotted on the right side of the image on the X-axis and the attenuation in dB (decibels) is plotted on the Y-axis, so that 0dB means: frequency is transmitted. The **Step Response**→**Show button** simulates the filter in the time domain. A jump is given to the filter, whose amplitude jumps from 0 to 1 at time $t=0$, and the output signal of the filter, the jump response, is displayed on the right side of the graph. On the X-axis, the time is plotted in seconds, and on the Y-axis, the amplitude curve is plotted as a factor, where 1 is the input amplitude at $t>0$. This allows the runtime and overshoot to be determined. The filter simulator depicts the true computational core with the original algorithm of the BX6 and BX8 in the time domain. Show *coefficients can be used to display the filter coefficients, i.e. the result of the filter determination.*

With **Store to Device**, the displayed filter configuration is stored in the device. If the checkbox **Apply to all input** channels is set, it will be set for all input channels. If **Use Filter is set to Enabled**, *the filter will be activated in the device; if Apply to all input channels is set at the same time, the filter will be activated for all input channels with configured filters and with Use Filter = Disabled it will be disabled.*


It is highly recommended to perform the filter simulation with *frequency response and* step response, because the filter is calculated here and you can detect any discrepancies early. The following are examples of simulation results of all filter types of IIR filters in the BX6.



At $f=0$ (direct signal) the attenuation is maximum, after the oscillation time of the jump response (right) the output signal is again =0.



IIR bandpass from $F_a/20$ to $F_a \cdot 0.35$. The jump response is similar to that of the high pass.



IIR band lock for attenuation of 50 Hz (mains hum).

Communication Interfaces and Measurement Data Frames

A communication interface, also known as an interface, consists of one or more electrical signals that transmit information. For strain gage amplifier devices, the serial interface can run on different hardware ports, e.g. USB, UART, RS232, RS422, Ethernet or Bluetooth Classic/SPP. In **Add Channel** dialog, the correct communication interface is selected based on the selected device type (**Device Type**) is automatically selected; with the exception of the BX6, which is **Communication Interface** between **Serial/USB/BT** and **CAN** can be chosen. For CAN you need an adapter, s.S. 98.

Bitrate/Baud Rate, On/Off

The serial ports of all strain gage amplifier devices have the basic configuration of 8 data bits, no parity and 1 stop bit (8N1).¹⁹ The communication bitrate must be selected correctly in **the Add Channel** dialog on most devices. This does not apply to the USB interface of the

¹⁹Except for rare special types such as BSC2HD with parity


BX8 and the BSC2 and to the Bluetooth Classic Interface (e.g. BX6BT). For these devices, the Bits/s setting in **Add Channel** is irrelevant on these interfaces. This also applies to BX8 over Ethernet, because a converter device, e.g. Moxa, is connected in between, in which the bitrate must be correctly configured.

If the device type is selected, *the* default bitrate is suggested; however, if it is set differently in the device, it must be selected accordingly with bits/s. It is best to use the small arrow keys, because the control element contains a list of the bit rates (= baud rates) present in this device.


The bit rate of serial interfaces is one of the main factors that limit the maximum adjustable measurement data rate (see p. 16 and 102); However, this only applies if it is relevant. The BX8 and some BSC2 and BX6 models have multiple communication interfaces, and the lowest relevant bitrate of an enabled interface limits the maximum data rate the most. In the case of the BX8, this can be the bitrate of a UART, RS422 or CAN interface.

However, very high bitrates cannot be transmitted with certain hardware interfaces; e.g. the maximum default bitrate for RS232-V24 is often only 115200 bits/s; even a very long interface cable has a restrictive effect here.

Bit rate and on/off status of interfaces are controlled under Menu Bar -> **Device** -> **Advanced Settings** -> **Interface**. Which interfaces can be operated depends on the device design; the **Interface** tab may not be present. Only BSC2, BX6 and BX8 can be used to change bit rates; the BSC2 must have a configuration jumper set for this purpose; see BSC2 Owner's Manual.



Changes to interface settings will only take effect after the device has been rebooted. After clicking on **Store to Device**, this will be noted in the text **Info**:



With the BX8, UART, RS422 and the CAN interface can be switched off with the **Enabled On/Off** checkbox, if they are available. It makes sense to do this when it is not needed, because the maximum adjustable measurement data rate is then larger. Each device has at least one interface that cannot be switched off, in the case of BX8 this is USB.

BX8 with Ethernet uses the UART interface for the Ethernet converter device; the bitrate must therefore be set in the same way for both devices (BX8 and Ethernet converter). With BlueDAQ, this can only be done on the BX8 side; The Ethernet (TCP-IP) device server Moxa Nport5110A is configured via Ethernet.

The RS422 interface is differential, i.e. the transmit and receive signal uses two lines each, five in total. As a result, significantly higher bit rates and longer cables can be achieved.

The following bitrates are supported; the default value is set to bold:

BSC2 and BSC1, depending on the version UART, RS232, USB, RS422: 4800, 9600, 19200, 38,400, 57,600, 115,200, 230,400, 250,000, 460,800, 625,000, 921,600, 1,250,000.

BX6: depending on version, UART, Ethernet, USB: 19,200, 38,400, 57,600, 115,200, 230,400, 460,800, 921,600.

BX6 CAN interface: 25,000, 50,000, 100,000, 125,000, 250,000, 500,000, 1000,000

BX8 UART 3.3V, Ethernet: 19,200, 38,400, 57,600, 115,200, 230,400, 460,800


BX8 RS422: 19,200, 38,400, 57,600, 115,200, 230,400, 460,800, 921,600, 1,250,000, 1,458,333, 1,750,000, 2,500,000, 3,500,000

BX8 CANopen: 50,000, 100,000, 125,000, 250,000, 500,000, 1,000,000

GPS/GNSS and *user device*²⁰, serial, USB: 2400, 4800, 9600, 19,200, 38,400, 57,600, 115,200, 230,400, 460,800, 921,600. The bitrate is selected in the **Add Channel** dialog, BlueDAQ cannot change it on these devices.

Permanent measurement data transmission

When delivered, all amplifiers automatically transmit measured values at the set measurement data rate. The BSC2, BSC1, BX6 and BX8 can be equipped with independent measurement data transmission under the menu bar → **Device** → **Advanced Settings** → **Value Mode** → **Value frame Transmission**.



Even if it is switched off, BlueDAQ usually still displays measured values because it temporarily starts the transmission when the device is opened, i.e. it then performs Start Transmission across the board.

The setting of permanent data transmission, which is stored permanently, therefore applies mainly after the device has been switched on. It is operated under *Permanent value transmission non-volatile state*. If the top selection Values transmitted permanently is *active*, *the device will send readings after powering on, but if* Values NOT transmitted permanently is active, it will not. If a device stops sending readings immediately after deactivation, the *Configuration tab of the main window will display timeout instead of the measured value after a certain period of time*. This can be temporarily remedied by clicking the *Start Transmission*

button under *Value frame transmission -> Volatile state*. The soft-LED *Actually transmitting values* will then light up again.

Disabling permanent data transmission is useful for the following applications, for example:

- BX6BT with high measurement data rate >200/s to facilitate Bluetooth connection. If necessary, the **Set Frequency** dialog will activate this accordingly.
- Measurement data transmission triggered by digital input, see p.109
- Other software, e.g. that reads measured values only on request (via the Get Value command)

CAN and CANopen settings

In addition to the bitrate, one or more CAN IDs can be changed for the CAN interface. CAN is a bus system to which several devices, so-called nodes, can be connected. Strain gage amplifiers with CAN also have several services, e.g. sending measurement data, receiving commands and sending command responses. Devices and services are differentiated on the CAN bus by the CAN IDs; each CAN-ID may therefore only occur once on the same bus. With the CANopen application protocol (BSC2 and BX8), only the device ID (node ID) *can* be

²⁰These types of devices are only available with BlueDAQ PRO.

changed, the CAN IDs of the services result from this in a way that is specified by the CANopen standard.

BlueDAQ supports CAN converter hardware from the manufacturer PEAK Systems, namely the PCAN USB model as standard. Alternatively, you can use the menu bar>options>hardware>CAN adapter type to switch to the PCAN PCI model, etc.

The settings for CAN-ID and bitrate can be accessed via the menu bar -> **Device** -> **Advanced Settings** -> **interface**. For CANopen devices, the node ID is displayed and changed here. The following IDs can be set for the BX6-CAN:

- **Command ID:** ID for command request. It must be different from the **Response ID** and the **Value ID**.
- **Response ID:** ID for responses to commands. It must be different from the **command ID**.
- **Value-ID:** This ID is used to send measurement data. It must be different from the **command ID**.
- **Multicast ID:** This ID is reserved and is not currently in use.

On most BX6 models, the CAN interface settings are accessible even if the hardware version does not offer a CAN interface. They are then to be ignored, the **On / Off state** should then always be off.

CRC on BX6 and BX8

With the checkbox Menu Bar -> Device -> Advanced Settings -> Interface -> **CRC for all Serial Frames**, a checksum calculation can be activated for all serial ports on the BX6 and BX8. As a result, the device provides the measurement data frames with a CRC-16 checksum and BlueDAQ then also uses the CRC-8 checksum provided for command requests, the command responses are then sent with it as well.

A checksum can be useful if the serial protocol does not run via a USB, Ethernet or Bluetooth interface, but is sent directly (e.g. RS232, RS422, UART), especially if electromagnetic interference is present. The checksum extends the measurement data frame by 2 bytes, so that the maximum measurement data rate may be slightly lower. More detailed information on the indication and calculation of the checksum can be found in the protocol documentation. Data frames where the CRC check fails are discarded. If CRC errors occur (e.g. due to strong interference), measured value distortion of the data streams occurs (i.e. it is extremely unlikely).

Data Frame: Channel Count and Data Type


The BSC2, BSC1, BX6 and BX8 amplifiers offer various settings regarding the type of data transmitted via the digital interface. BlueDAQ can evaluate all configurable data types; if necessary, it automatically converts the incoming measurement data using **user scaling**.

Sebastian wetz
2023-12-21 01:38:00
but no
really without an error message?
Testing with EMC speed cameras!

However, a change in the data type may be useful or necessary if other programs are to be used that only know a certain data type or if the measurement data rate is to be increased, because the measurement data type can also limit this maximum.

The measurement data type can be changed under the menu bar → **Device** → **Advanced Settings** → **Value Mode** → **Frame / Value Type**. The details of the measurement data frames and the decoding of the measurement data are described in the instrument user manuals and for the BX6 and BX8 in the protocol description.


Measurement data type for BSC2 and BSC1



It can be chosen between two different binary data formats and text data format.

- 16-Bit value, 3-Byte frame:** Adjustable on BSC2 and 3. The measurement data frame consists of only 3 bytes, the first is a constant prefix, followed by 2 bytes with binary-coded readings. This setting allows for the highest measurement data rates. 16. In the BSC2, the lowest byte of the 24-bit values is omitted, so that this setting is only recommended with rather high measurement data rates, where the effective resolution is reduced anyway due to the higher noise. For the BSC1, this is the default data type.
- 16-bit value, 4-byte frame:** BSC1 only: The measurement data frame consists of 4 bytes, the first is a constant prefix, then comes a flag value that contains the state of the threshold switch, then the binary-coded 16-bit measured value. The 4-byte frame allows for safer frame synchronization when using other software, because the masked second byte can be taken as a preamble, making missynchronization much less likely.
- 24-bit value, 5-byte frame:** BSC2 only: The measurement data frame consists of 5 bytes, the first is a constant prefix, then comes a flag value containing the state of the threshold switches, then the binary-coded 24-bit measured value. The 5-byte frame allows for more secure frame synchronization when using other software, because the masked second byte can be taken as a preamble, making missynchronization much less likely. For the BSC2, this is the default data type.
- ASCII Text:** Adjustable for BSC2 and 3. The measurement data frame is an ASCII-compliant text, with the first byte always representing the sign + or – and the frame ending with the control characters CarriageReturn and LineFeed (0x0D0A). This is a widely compatible format and it is easiest to evaluate (with most programming languages) with self-written programs; however, the maximum measurement data rate is the lowest because it takes up to 18 bytes to transmit a measured value.

Formatting of the measured value text display



With the BSC2 and BSC1, the number of digits of the measured value in the text frame can be configured in a sub-dialog that opens when you click on the menu bar → **Device** → **Advanced Settings** → **Value Mode** → **Format Value** Clicks. In the case of BSC2 models with an LCD display, this also changes the display of the measured values. The number of possible decimal places (decimal places) still depends on the display normalization (**User Scaling=Display scaling**). The maximum number of significant digits

under **Number of Digits** is =8 for the 24-bit amplifier and BSC1 =5 for the 16-bit device. At the bottom of the configuration dialog, examples of the measured value text are displayed based on the number of digits selected above, optionally for the display (**LCD**) or the serial port (**Serial Port**). This can also be used to count the number of bytes per frame, where +2 for the suffix must be added to determine the maximum measurement data rate (Byte Count, s.S. 102).

This device setting **Number of Digits** is independent of the software (see p. 32), however, if it is lower than that of the software when the ASCII measurement frame is enabled, zeros are appended, i.e. it then requires the lowest display step.

Measurement data type for BX6 and BX8


You can choose between integer data format and floating-point representation. The set measurement data type applies to all existing interfaces except EtherCAT and CANopen.

- **16-bit Integer values:** Integer binary format in which each measurement in the data frame is represented by 2 bytes. This setting allows for the highest measurement data rates. 16.
- **24-bit Integer values:** BX8 only: Integer binary format in which each measured value in the data frame is represented with 3 bytes.
- **Float values:** Floating-point representation, in which each measurement in the data frame is represented with 4 bytes and gives fully scaled readings, provided that the sensor associated with the corresponding channel is correctly configured. This setting is for displaying physically scaled measured values for certain sensor types such as multi-axis sensor (s.p. 39) and temperature sensor required. It corresponds to the default setting.

Number of channels in the measurement data frame

With the BSC8D, only the channels that have been opened with **Add Channel** are transmitted. For the BX6 and BX8, this number can be configured under the menu bar → **Device** → **Advanced Settings** → **Value Mode** → **Number of Channels in Frame**. For these three types of devices, it influences the maximum adjustable measurement data rate: the fewer channels, the higher it is (however, the absolute maximum of the measurement data rate,

e.g. 48000/s for BX8 standard, cannot be exceeded). With the BSC4D, the number of channels is immutable =4.



With the BX6 and BX8, only input channels can be opened in the **Add Channel** dialog that are also transmitted in the measurement data frame. If the number of channels is reduced, open channels are automatically removed and are no longer present; if this number is increased, the new channels can then *be opened manually* using Add Channel.

The minimum number for BX8 = 2, so that only input channels 1 and 2 are available; for older BX6 devices only the number of channels 1, 2, 3 or 6 can be set. The entry must be completed with **Store to device**. With the BX8, the number of channels between the UART and USB interface is managed independently of each other and is operated for the respective active interface, i.e. USB is used to set the number of channels of the USB frame, and UART/RS422 is used to set the number of channels of the

UART and RS422 interface.

If there are one or two counters or frequency counter channels (see p. 120), the maximum number of channels increases accordingly.

BX6 and BX8 behave differently in terms of data acquisition in connection with this setting. The BX8 always captures all 8 channels²¹, regardless of *number of channels in frame*; the BX6, on the other hand, only captures configured channels.

Data Frame and Measurement Data Rate

The communication bitrate (baud, in bits/s) and the number of bytes per measurement data frame (number of bytes) determine the maximum measurement data rate. This may be limited by other settings, and there is also an absolute maximum for each device model, which is indicated in the data sheet or the user manual and cannot be exceeded. If there are multiple interfaces, such as the BX8, the lowest Fdata,max of all enabled interfaces is considered the maximum.

Serial communication is used for all devices and interfaces where the communication bitrate is relevant (see S. 95), the maximum measurement data rate theoretically is as follows:

$$F_{data,max} = \text{baud} / (\text{number of bytes} \times 10)$$

The value must be rounded down, and it may be lower depending on the device. This may be due to the fact that only certain values can be set for measurement data rates. BlueDAQ displays the range of values in *the Configuration Tab -> Data Frequency* dialog, so you can first change the settings of the measurement data frame and then read the maximum there.

BX6 and BX8 have the same serial data protocol in which the structure of the measurement data frames is specified. The following applies:

$$\text{ByteNumber} = N \times DT + 4$$

²¹In the case of high-speed special equipment, there are 4 channels

or, if the CRC checksum is enabled:

$$\text{ByteNumber} = N \times \text{DT} + 6$$

This includes:


N: Number of channels in the measurement data frame

DT: Number of bytes per reading, i.e. =2 for 16-bit integer, =3 for 24-bit integer, and =4 for float reading.

Example: 6 channels, float, without CRC: byte count=28; Fdata,max= 822/s at baud=230400 bits/s (e.g. BX6).

Bluetooth settings on the BX6BT

The dialog for device behavior and communication settings of the Bluetooth interface of the BX6BT can be accessed via the menu bar → **Device** → **Advanced Settings** → **interface** → **Bluetooth Settings**, i.e. you click on the Open Dialogue button. When entering this menu, the measurement data transmission is stopped, i.e. while it is open, the *timeout* message appears under **Measuring Value** in the main window **Configuration**.



The **Bluetooth mode** must be Classic in order to open the BX6BT with BlueDAQ; this "SPP" device profile emulates a serial port. The *Low Energy* mode is not compatible with BlueDAQ. It follows the BLE/Gatt standard and there are separate instructions for this. It can be used to communicate with the BX6BT with smartphones and a BLE/Gatt app, for example, and to read out measured values, among other things. To switch, set *it to Low Energy* and then click **Store to**

device. After you close BlueDAQ or use the menu bar -> Device -> Close... has removed all channels of this device, the low-energy mode is activated. With a Gatt browser program / app you can switch back to Classic Mode to be able to access the device via BlueDAQ again; The instructions [ba-bx6bt-gattservices_en.pdf](#) describe how to do this.

Under **Maximum Power for BT Low Energy** can reduce the maximum transmit power for the Low Energy mode; by default it is set to Maximum = 7dBm. With less transmitting power, the battery can last a little longer, however, the range is reduced, less than -3dBm is not recommended.

Device behavior when Bluetooth connection is closed

In addition to the hardware measurement application (BX6CPU), the BX6BT contains a second microcontroller, which can also switch the BX6CPU on and off. When the Bluetooth connection is open, i.e. when the blue device LED is on, the measurement application is always switched on, which is indicated by the glowing green device LED (both in Classic and Low Energy mode). The device status when the Bluetooth connection is closed (blue LED off) can be viewed under **On / Off state of measuring amp when BT connection is closed** can

be configured. This is useful for recording measurement data on the SD card in stand-alone mode, see p.33. When the measurement application is switched off, the device is in standby mode and consumes very little power, so the battery lasts for a very long time. Specifically, the options are:

- **Device remains on:** The measurement application remains on at all times.
- **Device switches off:** The measurement application is switched off after the connection is closed and remains off. (Condition of delivery)
- **Periodical Logger:** The measurement application is briefly switched on by a hardware clock (RTC) at a definable time interval ≥ 1 minute in order to record a line of measured values, see p.33, *Single Log Periodically*.
- **On/Off by Key:** The measurement application can be switched on and off with a button connected to a specific digital line (BT-DIO3). With the BX6BT M8 model variant, this is already available as standard, see user manual.²²
- **On/Off by Switch:** The measurement application can be switched on and off with a switch connected to a specific digital line (BT-DIO3).²³

Other BT Settings Displays and Controls

- **BT Device Name:** The Bluetooth name of the device in BT-Classic mode. Changing this name is possible, but not recommended for end users .
- **BGscript Version:** The firmware version of the second microcontroller (BT controller).
- **Digital Out 1 / 2:** This allows the digital outputs "IO_1" or "IO_2" of the BT controller to be switched to high as a test. The condition is fleeting. These digital outputs are not to be confused with "SW1-3" = "DIO1-3" = "Threshold output", which are controlled via the measurement application, see p.109.
- **Digital Out 4 (LED):** This allows the user LED of the BT controller to be switched on as a test. The condition is fleeting.
- **Battery Voltage:** The voltage of the battery. If it is less than 3.7V, it should be charged!
- **Read All again:** Read all settings again.


Transfer of the maximum or minimum value

With the BSC2, BSC1, BX6 and BX8, the measured value frame can be reconfigured so that instead of current measured values, only maximum or minimum values are transmitted, i.e. positive or negative peak values. If you use this device mode, the current measured value is no longer displayed. To see both, you can switch a numerical display via software, as on S. 30 shown. With Menu bar -> *Device* -> *Advanced Settings* -> *Value Mode* -> *Maximum / Minimum values* on the other hand, the configuration of the device will be changed. This can be particularly useful when using other software or if the BSC2 wants to show the maximum on the device display.

²²Available from BGscript version 1.00

²³Available and fully functional as of BGscript version 1.02

To transmit maximum values, *Value transmission* is set to *Transmit maximum values*. In the case of the BX8, the *Acquire maximum and minimum box must also* be set so that the max and min values are recorded. You can then also set the transmission with *transmit minimum values* to minimum values.



With the BSC2 and BX8 there is the possibility to transfer maximum amounts. This means that the maximum of the measured values is transmitted with the "omitted sign". To do this, activate the checkbox *Maximum values are maximum values of absolute values MAX(|vals|)* and at the same time selects *Transmit maximum values*. The devices then calculate the amount of the measured values and determine the maximum value, which is always positive.

With the BSC2 there is also the *value transmission* mode *Transmit max. / min values*. This is similar to the maximum amount value, but the sign is not omitted, but transferred as well. Example:

Measured value first =0, then new max value 10. Now a new minimum value of -12 is created. With *transmit max. / min values*, the BSC2 now transmits -12, with maximum values of absolute values *it would transmit 12*.

All devices generally transmit the maximum or minimum values with the set measurement data rate, i.e. if there is no new maximum or minimum, the previous one is repeated.

However, the BSC2 also offers a maximum event mode. If the *Transmit value on new maximum event checkbox* is set, only new maximum values will be transferred. As a result, it regularly happens that the BSC2 does not transmit any measured values, i.e. the measurement data stream is irregular and BlueDAQ then displays timeout more often *in the* measured value display in the *configuration* tab.


Definable measured value text for integration of other devices

With BlueDAQ PRO it may also be possible to display the measured values of other measuring devices, under the following conditions:

- The device transmits via a serial port (real or virtual) with the default setting of 8 data bits, no parity and 1 stop bit (8N1).
- One of the following bitrates is supported: 2400, 4800, 9600, 19,200, 38,400, 57,600, 115,200, 230,400, 460,800, 921,600.
- The device sends text with measured value frames as an ASCII or UTF-8 string, i.e. it is 8 bits per character.

- It sends the measured value frames automatically and automatically, i.e. they do not have to be requested.
- The layout of the measured value frame remains constant, i.e. its basic structure does not change during the measurement runtime.
- The decimal separator in the measured value is a period, not a comma.
- Each measurement frame is terminated by carriage return and line feed, i.e. by the control characters LF,CR (0x0D0A).

To open such a device, select *the UserDefined device type in the Add Channel dialog under Device Type*. The dialog for configuring the measured value text opens automatically if necessary; if it doesn't, click on *Value String/DEFINE*.



It offers the following setting options:

Frame Prefix Mode: A prefix is a character that always comes first in each measurement frame; there are three choices:

Has Character Prefix: There is a prefix and it is entered in Define Prefix Character as a character, e.g. \$ or % or A.

Has Binary Prefix: There is a prefix and it is entered into Define Binary Prefix (hex) as a 2-digit hexadecimal number, e.g. 0A or B4 or 80.

No Prefix, 1st char is - or digit: There is no prefix and the metric frame starts with a reading, i.e. the first character is - + or one of the digits from 0 to 9.

Number of values in String/Frame specifies how many metrics/channels the metric frame contains. Each metric can then be mapped to a channel in BlueDAQ, but this doesn't have to be done for every metric in the frame. So this number should be correct, regardless of whether you want to display all values or not. If Open all input channels is activated in the Add Channel dialog, the first reading in the frame will be assigned to the first channel of this device, the second to the second, and so on. If you want to change the displayed channel order, you have to click Add Channel in the desired order for each channel to be opened, deactivate Open all input channels and select the channel, i.e. its position in the measurement data frame with channel/pos. choose.

If the metric frame contains more than one metric/channel, a character must be defined to separate the values within the frame. With Value Separator, you can select the following:

comma ,
 semicolon ;
 Pipe |
 Space space
 Tab tab
 Other other

If other is selected, enter the separator under Separator Char .


If, in addition to numbers and separators, the measurement value string contains other texts or characters that are different from the separator (see example 3), you can activate the *Filter-Out Non-Numeric checkbox*. BlueDAQ then analyzes the measurement strings in more detail and filters out unnecessary parts; however, this requires computing time, so that the performance of the PC may be weaker.

The definition of **User-defined Device** will be used in the **Session** i.e. it is recommended if everything works, **Save/Load Session** s.S. 14.


Examples:

1. In the User Defined Device *screenshot shown above*, the frame has the prefix % and only one metric. This would correspond to the following string:
%-123.789<CR><LF>

2. A measured value text looks something like this
:-2.699876,+0.97575,0.000001,6899.076,6,0,1<CR><LF>
Then you configure **User Defined Device** as follows:



3. A measured value text looks something like this
:ST,NT,+ 1.3 <CR><LF>
Then configure **User Defined Device** as follows:




Automatic resumption in case of loss of communication connection

It can happen that the data stream of the measurement data breaks off; The cause can be, for example, an interrupted Bluetooth radio connection or an accidentally removed communication line. BlueDAQ notices this and displays timeout after 5 seconds in the *configuration* tab :

Measuring Value **timeout!**

If the measurement data rate is less than 2/s, then this time is not 5s, but $10 / \text{measurement data rate s}$. The further reaction of the program depends on the configuration and whether a measurement was started with **Start Measuring** or not. For the status of the started measurement, BlueDAQ will try to reconnect automatically. This behavior can be configured under **Menu Bar -> Options -> Hardware -> If connection to device is lost::**




In the initial configuration, the automatic resumption Try to reconnect is automatically **enabled**, it can be disabled with **No auto-reconnect**.

If it is activated and the measurement is started, the following happens if a strain gage amplifier BSC2, -3, -4, -6 -8 does not transmit any measurement data for at least 4.5 seconds:

1. The disconnection is checked with a read command. If it is successful, only the command **Start Transmission** in order to try to revive the permanent transmission of measurement data (see p. 98). If it is not successful, the interface connection is closed first. This is necessary in order to be able to open them again afterwards. If more than one strain gage amplifier is open, this will be done with all of them and, if necessary, a list of strain gage amplifiers with connection problems will be created.
2. Now an attempt is made to reopen the strain gage amplifier with connection problems. If this is successful, the measurement is continued, if not, this is tried again and again at regular intervals of about 1 second. If measurement data is recorded during this time (**start recording**), the missing data can subsequently result in inaccurate time stamps.

If the automatic resumption of the connection is disabled under **option>hardware** , the user will receive the following message after 5 seconds without measurement data and the measurement starts:



The user can then click on Stop, so the measurement and, if necessary, the data acquisition will be stopped. You can then use the menu bar -> **Device -> Close** or Remove Channel **to close and reopen the connection manually** (Add Channel / Device -> Open). Or you can click on Continue in this message and the program will continue to wait for measurement data without any other actions.

Digital inputs/outputs and threshold switches


The BSC2 and BSC1 models offer configurable threshold switches, and the BSC4D, BX6 and BX8 offer freely configurable digital inputs and outputs that can also be configured as threshold switches. A threshold switch is a digital output that is switched on or off when the measured value is above or below a threshold value.

The settings dialog for the digital inputs and outputs can be accessed with the menu bar -> **Device -> Advanced Settings -> Digital I/O**

On the BSC4D, BX6 and BX8, several soft LEDs are displayed on the right under *DIO levels*, which "glow" bright green when the digital I/O is high, i.e. when 5V or 3.3V is present; when low =0V is present, they are dark green. The number of soft LEDs displayed corresponds to the number of digital I/Os: 12 for the BSC4D, 5 for the BX6 and 16 for the BX8. Only for the *I/O types QEI input, Sync. Master and Sync. Slave* (see below) the states are not displayed or are not reliably valid because they change too quickly.

Actual Level is a soft switch that displays the state of the I/O that is currently selected with *I/O number*. In the case of the *I/O type GP output*, the level of the digital output can be changed with this, see below. The *Actual Level* and *DIO levels* controls are well suited to test the function of the digital inputs and outputs.

If the configuration is changed, it can be applied to all digital connections if the *Apply to all DIOs* checkbox is set (provided it is allowed for everyone). As the last step of a change for each I/O *store to device to be configured*, click.



It is useful to first *select the digital line whose configuration you want to view or change with the I/O number*, as some functions are fixed to specific lines. The BSC1 has only one threshold switch, here *I/O number* cannot be changed. The BSC2 has two threshold switches, which can be selected with it.

Under **Terminal name / Pin-No**, the name or pin number of the line is displayed, as it is mentioned in the user manual, for example. The **I/O type** shows the function of the line; this is also described in more detail in the text output **Function**. In case of a configuration change, it should be set after selecting the **I/O number**. The following functions are available:

GP Input: Digital input for general use, e.g. triggered measurement data acquisition as from S. 59 described.

QEI Input (BX8 only): Digital input is assigned for counter function, here Read-Only, i.e. this type cannot be set here and cannot be changed if it is set. Instead, the counter input can be changed in the Counter/Frequency dialog, see S.

Tare Single: Digital input to perform zeroing on a single input channel, *which can be selected with* input channel to set zero.

Tara All: Digital input to perform zero matching of all input channels

Reset Digital Out: (BX6 & BX8 only) digital input that puts all digital IOs configured as output into the power-on state that *can be defined with* Default output level.

Reset Max/Min: (BX6 & BX8 only) Digital input that can be used to reset the maximum and minimum value determination. In the case of the BX8, this only makes sense if it *is activated* in the Value Mode **tab** under Acquire maximum and minimum.

Trigger Send value (BSC4D & BX8 only): Digital input with which the transmission of one or more measured values via the USB and UART interface is triggered, provided that the permanent measurement data transmission is deactivated (see p.98). The type of reading and other details are displayed on the BX8 with **Triggered value sending Mode** set; with the following choices:

Actual Values: Triggering the sending of a measurement frame with current readings via the interface(s) to the inactive-to-active edge of the digital input.

Maximum Values: At the inactive-to-active edge on the digital input, the maximum value determination (all input channels) is started and at the active-to-inactive edge, a frame with these maximum values is sent to the interface(s).

Minimum Values: At inactive-to-active edge on the digital input, the minimum value determination (all input channels) is started and at active-to-inactive edge, a frame with these minimum values is sent to the interface(s).

Mean values: At the inactive-to-active edge on the digital input, a decimating averaging of all input channels is started and at the active-to-inactive edge, a frame with these mean values is sent to the interface(s).

Send while active: While the input level is active, frames of measured values with current readings are sent through the interface(s) at the set data rate.

GP Output: Digital output for general use (general-purpose); the state can be set with other programs or with the software switch **Actual Level**.

Threshold Switch: The digital output serves as a threshold switch, see S for details.

111

Sync. Master: The amplifier generates a square wave signal at this digital output, which is used to synchronize the transmission of measured values on devices that are used as Trigger Sync. slave, see S.14.

Sync. Slave: Digital input to which a square wave signal should be applied, which is used to synchronize the transmission of the measurement data, see p.14.


Trigger File Log (BX6BT only): Digital input on which the recording of measurement data files on SD card can be triggered, so that measurement data is logged while the active level is applied, s.S.33.

Threshold switch

The threshold encoder compares the measured value with two configurable threshold values, an upper (**ON-Threshold**, or an upper threshold). **Upper Threshold**) and a lower (**OFF-Threshold** and **Lower Threshold**). Depending on the result of the comparison and depending on the mode, the digital output is enabled, deactivated or the previous state is left unchanged. With **Threshold switch Mode**, you can choose from up to four different modes. Depending on the device model, not all of them are available, i.e. entries may be grayed out.

Hysteresis switch (normal): The threshold transmitter with hysteresis distinguishes three cases and behaves as follows:


- If the reading "MW" (or maximum or minimum value) is greater than the upper threshold value "SWo" (**ON Threshold**), the output is activated, i.e. if $MW > SWo$:
out,new=active
- If the reading (or maximum or minimum value) is less than the lower threshold value "SWu" (**OFF Threshold**), the output is disabled, i.e. if $MW < SWu$:
out,new=inactive
- If the measured value (or maximum or minimum value) is between the two thresholds, i.e. in the hysteresis range, the digital output remains unchanged, i.e. if $MW < SWo \parallel MW > SWu$: out,new=out,old. This avoids, for example, the output quickly switching back and forth when the reading is rushing around the threshold value.



Threshold switch with hysteresis

Window Comparator: (BSC2, BSC1, BX6 and BX8) The threshold sensor works as a window comparator, i.e. two cases are distinguished:


- If the reading (or maximum or minimum value) is greater than the **upper** threshold or less than the lower **threshold**, the output is disabled, i.e. if $MW > SW_o \parallel MW < SW_u$: out,new=inactive
- If the measured value (or maximum or minimum value) is between the two thresholds, i.e. within the "window", the output is activated, i.e. if $MW < SW_o \&\& MW > SW_u$: out,new=active.



Window Comparator

Bipolar hysteresis switch: (BSC2, BX6 and BX8) Bipolar threshold sensor with hysteresis: This mode is similar to the **hysteresis switch (normal)**, but the functionality is additionally "mirrored" in the negative range, i.e. it behaves as follows:

- If the reading (or maximum or minimum value) is greater than the upper threshold (**ON Threshold**) or less than the negated upper threshold, the output is activated, i.e. if $MW > SW_o \parallel MW < (-SW_o)$: out,new=active
- If the reading (or maximum or minimum value) is less than the **OFF** threshold or greater than the negated lower threshold, the output is disabled, i.e. if $MW < SW_u \parallel MW > (-SW_u)$: out,new=inactive




Bipolar Hysteresis

Threshold Switch

- If the reading (or maximum or minimum value) between the two thresholds is in the positive or negative range, i.e. in one of the two hysteresis ranges, the digital output remains unchanged. I.e. if $(MW < SWo \ \&\& \ MW > SWu) \ || \ (MW > (-SWo) \ \&\& \ MW < (-SWu))$: out,new=out,old.

Bipolar window comparator: (BX6 and BX8) Bipolar window comparator: This mode is similar to the window comparator, *but the functionality is additionally "mirrored" in the negative area, i.e. it behaves as follows:*

- If the reading (or maximum or minimum value) is greater than the **upper threshold** or **less than the lower** threshold or **less than** the negated upper threshold or greater than the negated lower threshold, the output is disabled, i.e. if $MW > SWo \ || \ MW < SWu \ || \ MW < (-SWo) \ || \ MW > (-SWu)$: out,new=inactive.
- If the reading (or maximum or minimum value) between the two thresholds is in positive or negative range, i.e. within one of the two "windows", the output is activated, i.e. if $(MW < SWo \ \&\& \ MW > SWu) \ || \ (MW > (-SWo) \ \&\& \ MW < (-SWu))$: out,new=active.



The Threshold compared with selector *can be used to select whether the actual value, maximum value, or minimum value* should be compared with the thresholds. If maximum or minimum value is selected, you have to make sure that the BX8 ticks the checkbox *Acquire maximum and minimum is set under the menu bar -> Device -> Advanced Settings > Value Mode → Maximum / Minimum values, so that the BX8 actually carries out the maximum and minimum value determination.*

The threshold values themselves are divided into **ON-Threshold** and **OFF-Threshold** values. **Upper Threshold** for the upper threshold and in **Off-Threshold** or **Lower threshold** is entered in the unit in which the input channel to be compared is configured. With the BSC4D there are only 8 threshold pairs available, which are assigned with **threshold number**, they are also assigned to the input channels, see below.

With **Input channel to react on** In the case of the BX6 and BX8, the input channel is selected for the measurement/max/min value to be compared with the two threshold values. In the BX8, numbers 1 to 8 are analog input channels and 9 and 10 are counter channels. This selection is possible for the BX8 regardless of whether the channel is selected in the setting of the number of channels in the data frame (s.p.101) is present or not; However, counters should only be selected if they are configured. In the case of the BX6, on the other hand, the channel to be compared must also be present in the frame; here are 1 to 6 analog input channels and No. 7 is the counter channel on the BX6BT.

In the BSC4D, the input channel that is compared to the threshold values is selected with the **threshold number**, where Nos. 1 and 2 are assigned to the input channel 1, Nos. 3 and 4 to channel 2, Nos. 5 and 6 to channel 3, and Nos. 7 and 8 to the input channel 4.

Active/Inactive Level, Inversion

In the description of the functions of the Digital IOs, the terms "active" and "inactive" are used. In the case of the BSC2, BSC1, BSC4D and the BX6 and BX8 in the delivery state (**Not inverted**) they mean the following:

Active: High, i.e. 5V (or BX6: 3.3V) Inactive: Low, i.e. 0V

With the BX6 and BX8, this mapping can be reversed, i.e. inverted, for most digital I/O types with *line inverted*. If this radio button is set to *Inverted*, it means: Active: Low, i.e. 0V

Inactive: High, i.e. 5V (or BX6: 3.3V)

The following I/O types can be inverted: Tara


Single, Tara All, Reset Digital Out, Reset Max/Min, Trigger Send value, Threshold Switch, Trigger File Log.

Default Digital Output Level

In the case of the BX6 and BX8, digital IOs configured to one of the output types can be specified which level should be applied after the device has been switched on, if the output has not yet been set elsewhere, e.g. by the threshold switch or, in the case of *GP output*, by the user. This is set under *Default output level*. The inversion setting with *Line inverted* is irrelevant, i.e. the *default output level* is either *Low (0V)* or *High (5V/3.3V)*.

Analog output on the BX8

The BX8 offers eight configurable analog outputs, which can be configured under Menu Bar -> *Device* -> *Advanced Settings* -> *Analog Out*.



With *Output Channel*, you first select one of the 8 analog outputs whose configuration you want to view or change.

Analog output type is the type of analog output that specifies the output current or voltage and the range of values. The following types are available:

Voltage 0 .. 10V: Voltage output, unipolar from 0 to 10V.

Zero point: 0V (if user offset =0)

Saturation: negative: -0.5V, positive: 10.5V

Voltage -10 .. +10V: Voltage output, bipolar from -10 to 10V.

Zero point: 0V (if user offset =0)

Saturation: negative: -10.5V, positive: 10.5V

Default type of manufacturer setting

Voltage 0 .. 5V: Voltage output, unipolar from 0 to 5V.

Zero point: 0V (if user offset =0)

Saturation: negative: -0.25V, positive: 5.25V

Voltage -5 .. 5V: Voltage output, bipolar from -5 to 5V.

Zero point: 0V (when user offset =0)

Saturation: negative: -5.25V, positive: 5.25V

Current 4.. 20mA: Current output, unipolar from 4 to 20mA Zero point: 4 mA (when user offset =0)

Saturation: negative: 3.2mA positive: 20.8 mA

Current 0 .. 20mA: Current output, unipolar from 0 to 20mA Zero point: 0 mA (when user offset =0)

Saturation: negative: 0 mA positive: 21 mA

The zero point at the analog output can be changed by *user offset*, so that even unipolar types can be measured bipolarly, i.e. positive and negative numerical or measured values can be displayed analogously. The *user offset* can be entered either as a percentage of the output range (%) or in volts (V) or mA, for this unit must be selected with the pull-down menu next to it.

For example, if the analog output type is **voltage 0 .. 10V** and *user offset* is set to 50% or 5V, the ranges change as follows:

Voltage 0 .. 10V: Voltage output, bipolar from 0 to 10V. Zero point: 5V
(when user offset =50%)

Saturation: negative: -0.5V, positive: 10.5V

In order for the negative full gain to be displayed by 0V and the positive by 10V, the *user scaling factor* must be =0.5. *User offset* and *user scaling factor* only affect the analog output and are not to be confused with *user scaling* and *user offset*, which are operated in the main window (*Configuration tab*).

These results can be read after each change of the inputs by the output in *Transfer characteristic* (Transfer function). In this case, the positive and negative full control value of the *User Scale* or, if the six-axis sensor is activated, its maximum value. The *User scale* In the case of general sensors, this usually does not correspond to the nominal value of the connected sensor, see p. 8. With the above example, the following can result:

The positive full output of 1590.91 results in **10V at the output**.

To be able to measure bipolar, set the user **offset** to 50% or 5V, the **user scaling factor** is then automatically set to 0.5:

The digital value =0 (**Zero value at input**) now results in 5V at the output, **the negative full gain results in 0V at the output**.

In this example, the **input value Value at input** of 1590.91 N is obtained from a 1000 N force sensor with the following data:


Often you want the nominal value of the sensor to correspond to the full gain on the analog output and not the input full drive. In this case, that would be:

$$1000 \text{ N} \Rightarrow 10\text{V} - 1000 \text{ N} \Rightarrow 0\text{V}$$

So you convert the **user scaling factor** manually:

$$\text{New user scaling factor} = (\text{full level/sensor rating}) \times \text{old user scaling factor}$$

$$\text{Here: } (1590.91/1000) \times 0.5 = 0.795455$$



Analog Output Mode


By default, the analog output follows the sensor signal of the corresponding input channel, i.e. input 1 -> output 1, etc. However, this assignment can *be changed by* analog output mode.

You can do this in the following ways:

Active, follows analog input: The analog output follows the reading of the corresponding input channel; Default mode of the manufacturer's settings.

Active, follows Counter Input: The analog output follows the measured value of the counter or frequency measurement. This setting is only possible on output channels 7 and 8 and the counter/frequency measurement itself should be configured as from S. 120 described. Output channel 7 corresponds to the first counter channel and output channel 8 to the second; If only one meter channel is configured, output no. 7 is used.

Input independent, write direct only: The analog output is separated from the input and can only be set by the software's write command. This is useful, among other things, for testing the output. To do this, first select this mode and then click on **Store to device**. Afterwards you can go to Output **Voltage** or **Output Current**, use the slider or numeric number input to set the voltage or current, and then click **Write Value / Set**. Then this value should be output, regardless of user *offset* and *user scaling factor*.



Active, Software Input: The analog output is separated from the input and is described by BlueDAQ at the measurement runtime. This setting is only available with BlueDAQ PRO and is explained in more detail below.

Channel off: The analog output is disabled.

Analog output of software channels

With BlueDAQ PRO it is possible to output any channel continuously to the analog output. This is particularly useful when it comes to software-calculated channels, e.g. math channels or software-calculated multi-axis sensors (see p. 39). Math channels are channels that display the results of a user-defined computational rule (**MathScript**) issue; they are described in detail in a separate manual.

If this **analog output mode** is selected, you have to **use the Software Input Channel** selection element to select the source channel, i.e. it must already be integrated at the time of configuration. Only displayed channels can be selected, not hidden ones (i.e. not those that **have been hidden with menu bar -> Channel -> Hide**).

If you then **Store to device** clicks, in the BX8 the **Input independent, write direct only** mode and the information about the analog output via software is stored by BlueDAQ in its configuration file. It makes sense to store the entire channel configuration in a **Session** file, see S. 14

The analog output settings **User offset** and **User scaling factor** are also taken into account for the calculation of the software-generated analog output, but **Transfer characteristic cannot** display any meaningful values with them (see above).

The analogue output only takes place during the measurement runtime, i.e. after clicking on **Start Measuring**.

The update rate of the software analog output follows the measurement data rate if it is less than 1000/s. Otherwise, it tries to output a value every millisecond. However, the refresh rate may be limited by the load and performance of the PC. Also, the temporal equidistance of the samples of the output DAC is not necessarily given, i.e. it can happen that a little more time passes between two updates than usual.

Counter and frequency measurement with BX6BT and BX8

With the BX6BT and the BX8 you have the possibility to evaluate the signal from digital pulse generators and to configure one (or in the case of the BX8 two) additional measurement channels. The pulse generator can be an incremental encoder with A/B track or a simple optical or magnetic switch. Depending on the sensor, arrangement and device configuration, variables such as position, angle of rotation or displacement as well as speed, frequency or speed can be measured. Detailed descriptions are available for both devices in the form of separate operating instructions, the connection assignment can be found in the general operating instructions. The configuration dialog is opened via Menu Bar -> *Device* ->

Advanced Settings -> *Value Mode* by clicking on *Counter/Frequency/Speed Open Dialogue*. In the lower area you can control *User Scale*, *User Offset* and the *Unit* unit ; these settings

correspond to those in *the* main configuration window. In addition to *Measurable Value Range*, the measurable range of values from (*From*) to (*To*) is displayed, which is also updated based on user input.

With the BX8, up to two sensors with pulse output can be connected, which can then be connected with *Counter No.* If only one is used, it must be number 1. *Function* describes the basic function:

Disabled: The meter input is turned off and the meter channel does not exist.


Counter / Position / Angle: The counter input is configured as a counter, i.e. pulses or pulse sequences are counted as integers. More details below.

Frequency/Speed: The counter is used to measure frequency. This setting is suitable for measuring speed, frequency or speed, for example. More details below.


Both Counter and Frequency (BX8 only): From meter input 1, both the meter reading and the frequency are calculated and output in two additional channels. The operation/ display *User Scale*, *User Offset*, the *unit* *unit* and the *display of the value range is switched with* Show/Store values for.

Under *Hardware* and *Input Mode*, settings are defined, which can be selected on the basis of the connected heart rate sensor, among other things. The Input *Mode* determines the type of pulse evaluation, they may depend on the type of pulse evaluation. with other modes *Function* and *Method*, see there.


Non-QEI: A=freq, B=dir: The QEI encoder evaluation is disabled, a square wave signal is expected at input A. Input B determines the counting direction (or the sign in the case of frequency measurement): High = left open: Forward. Low = Set to ground: Backwards. This mode can be applied to all measurement types and methods.




QEI input x1: In the case of a complete quadrature cycle (see figure), a count is carried forward or backward by 1; the counting direction results from the forward or lagging of the A- to the B signal: A-pulse first: forward, B first: backward. This mode has the highest coverage of false signal suppression.



QEI input x2: For a complete quadrature cycle (see figure) it is counted forward or backward by 2 and for a half cycle by 1. The counting direction always results from the forward or lagging of the A- compared to the B-signal.



QEI input x4: For a complete quadrature cycle (see picture) it is counted forward or backward by 4 and for 1/4 cycle by 1.




Under **Hardware** you can set the BX8 as follows:

Use Pull-Up: If this checkbox is set, there are pull-up resistors at the QEI/meter inputs. This setting is necessary if the connected pulse sensor only switches between the states 'open' = high impedance and 'closed' = connected to GND (so-called open-drain output). In this way, encoders with an operating voltage different from 5V may also be used. If, on the other hand, it is a 5V push-pull output, you can omit use pull-up.

Input filter: The evaluation hardware offers an input filter that can suppress very short interference pulses; however, the maximum frequency of the inputs is reduced to 200kHz in all modes and the measurement accuracy for period duration measurement is also somewhat degraded (see ba-bx8-incremental-encoder.pdf).

Meter Measurement

For measurements as counters, the Function selection is **set** to **Counter / Position / Angle**. This setting is suitable, for example, for measuring position, angle of rotation or displacement. It can be counted forward and backward, see description of the **Input Mode**, which are all available here. User Scale and User Offset are used to convert the meter reading to the quantity of interest, so the final result can also be non-integer. The counter can be set to 0 with **Set Zero**, just like any analog reading. The following options are available:



Store value at power-off: When the device is switched off, the current meter value is saved and restored the next time it is switched on. This is useful, for example, for absolute displacement measurements; however, care must then be taken to ensure that the displacement sensor is never moved when the device is switched off.

Saturate to numeric limits: The count is saturated when the maximum is exceeded and the minimum is not reached; This saturation value depends on the set integer measured value data type (see p.101) and is 10 million for the float type. When the counting direction is reversed and it returns to the representable value range, the saturation state is automatically reset. BX8: When saturation is off, the counter overflows, i.e. from high positive or negative values to zero, and when the internal 32-bit counter overflows, from high positives to negative values and vice versa. BX6: When the saturation is off, the counter overflows, i.e. from high positive to negative values in the forward direction and vice versa in the reverse direction.

Use Home / Index input: In addition to the necessary connections A, B and GND, the QE1 decoder offers an additional input Home/Index. With this option it is used and if the input is then active, the counter value is set to a predefined value, which you enter under **Home / Index start value**. In many cases, 0 is used, so a pulse at the home/index input resets the counter.

Home/Index inverted (BX8 only): If **Use Home / Index input** is set, you can use it to set the active level: Checkbox set: Active=Low; not set: Active=High. On the BX6, the Home/Index input is inverted by default.

Frequency / RPM / Speed by Count

Here, the difference between 2 meter readings within a measurement data period is evaluated. The frequency to be measured must therefore be higher than the measurement data rate.

The different **input modes** are all available. The counting frequency measurement mode is suitable for measuring rather high frequencies at a relatively low data rate, e.g. those supplied by an encoder with many pulses per revolution. **Method** under **Frequency / Speed** is set to **Counting Pulses in this mode**. In this mode, the basic unit, i.e. the evaluation of the measured values with **user scale** = 1, is Hz, i.e. /s.

Gate time

In order for the frequency (or speed/speed) to be displayed correctly, the raw meter value must have changed as often as possible within a data period, i.e. the difference in amount of a new meter value to the previous one must be ≥ 1 .

The measurement data rate is the same for all channels, i.e. it also applies to the evaluation of the meter. In order to be able to measure relatively low speeds/frequencies at rather high data rates, it is possible to increase the data period for frequency measurement. This is done with the help of an (integer) data period multiplier, the **gate-time counter**. **The gate time, which consists of the gate time counter and the measurement data rate, is also displayed and operable, which indicates the gate time in seconds.**

The minimum frequency that can be measured is thus calculated as:

$$f_{\min} = \text{Data Rate} / \text{Gate-Time-Counter [Hz]}$$

Frequency / speed / velocity by period duration measurement

Here, the period duration of arbitrary square wave signals is measured directly. This mode is particularly suitable for speed measurement where only a few pulses (e.g. 1 pulse per revolution) are generated per revolution, e.g. by a magnetic switch moving relative to a magnet on the rotation circuit.

BX8: The quadrature encoder mode is irrelevant here; it always evaluates the time between one edge at input A and the next at input B. If the QEI evaluation is off (**Non-QEI: A=freq, B=dir**), the period duration of a square wave signal is measured at input A and B determines the direction of rotation. In this measurement mode, the accuracy and range of values of the measurement are independent of the measurement data rate and the QEI decoder mode.

BX6BT: In this case, the BX6BT switches on an oscillator with $f=1\text{MHz}$ at input A and the measurement input is input I ("index"). The input mode is therefore set to **Non-QEI: A=freq, B=dir**, i.e. the rotary encoder A/B input is not available. **Input A must be left open, otherwise the device could be damaged!**

Input B determines the sign of the measured value or the direction of rotation; If it is left open (=high), it is always positive.

The measurement data rate in this period duration mode must be significantly greater than the maximum frequency to be measured, and at least 3 times higher than this.

In both devices, the gate-time counter has a different meaning in this mode: it determines the time after which the measured value is set to zero when there are no more pulses at the measurement input. At the same time, this requires the measurable minimum.

Even in the period duration mode, the basic unit, i.e. the evaluation of the measured values with *user scale* =1, is Hz, i.e. /s.

BX8: Frequency / Speed Measurement with Auto-Period Mode

When the **Method measurement method** is set to auto-period mode, the BX8 automatically decides whether to use the counting method or the period duration measurement based on the measured frequency. If the counter value is less than 2000 per period of the measurement data rate, the period duration measurement is used, otherwise the counting method. The threshold value, for example, is 20 kHz at the default measurement data rate of 10 frames/s. In this way, the measurement uncertainty can be kept below 0.05% v.s. over the entire measuring range.

Gate time is not used in this mode, nor does QEI input mode have any effect.


Examples of setting User Scale to fit specific encoders:

Example 1: With a rotary encoder, the speed is to be measured in revolutions per minute (unit rpm). The encoder delivers 360 complete quadrature cycles per revolution. The input mode is **QEI input x1**. Then **User Scale** is set to the following value: $60 \text{ rpm} / 360 = 1/6 = 0.1666667 \text{ rpm}$.

Example 2: With the same encoder, you want to display RPM = rpm, but the input mode is **QEI input x4**. Then you set **User Scale** to the following value: $60 \text{ rpm} / (360 * 4) = 1/24 = 0.041666667 \text{ rpm}$.

Example 3: With a magnetic linear encoder and BX8, position in mm and speed in m/s should be displayed at the same time. It delivers 4 complete quadrature cycles per mm. For example, you can configure it like this:

The first measurement channel is the **Counter**, **User Scaling** = $1/(4 * 4)$, the second is **Speed**, **User Scaling** = $1/(4 * 4 * 1000)$



When the counter/frequency measurement is configured, a new channel is created in the device, which can be opened as on S. 13 described.

Learn more about device administration

In the following, previously uncovered settings and information are described, which *can be accessed in the menu bar* → Device → Advanced Settings → Administration.

Fault memory of the BX8

The BX8 has an error memory, which mainly stores faults caused by an incorrect connection or a faulty sensor. Up to 81 errors are saved. They can be viewed by clicking on **Fault Memory / Open Dialogue** :

No/age	Fault type no / Kind of fault	Occurred at working hours [H:MM]	Flags (Hex)
1	2: Sensor maximum exceedance	4231: 9	8
2	2: Sensor maximum exceedance	4227:16	8
3	2: Sensor maximum exceedance	4225: 4	8
4	1: Sensor input saturation	4222:26	1
5	2: Sensor maximum exceedance	4207:20	8
6	2: Sensor maximum exceedance	4207:18	8
7	2: Sensor maximum exceedance	4207:14	8
8	2: Sensor maximum exceedance	4207: 9	8

Details
663:54 before now, a multidimensional sensor maximum exceedance occurred. at physical channels: 4,

Clicking on them will highlight the entries and show *details of this error* at the bottom under Details. **No/age** is the number of the entry, starting with the most recent. Under **Occurred at working hours**, the operating time (the time of the operating hours counter, s.S.) at which the error occurred, is displayed in the format Hours:Minutes. **Fault type no / Kind of fault** specifies the type of fault and can contain the following entries:

1: Sensor input saturation: One sensor

input was saturated, i.e. the measuring range was exceeded. Under **Details**, input channel(s) identifies the input **channel(s)** where the error occurred. Possible causes:

- Defective sensor
- Overloaded sensor
- Defective sensor cable
- Incorrect sensor connection
- **Input type** selected incorrectly, i.e. input measuring range too small

2: Sensor maximum exceedance: A multi-axis sensor exceeded the maximum stored for that sensor. Under **Details** is used with **physical channel(s)** the input channel(s) where the error occurred. It may have the same causes as (1), in addition, incorrect sensor calibration data may have been loaded, see p. 39

3: Sensor or sensor connection broken: An incorrect common-mode voltage at Ud+ or Ud- was detected at a bridge input. Under **Details**, input channel(s) is **used to indicate the input channel(s)** where the error occurred, and the line Ud+ / Ud- is also mentioned. Possible causes:

- Defective sensor
- Incorrect sensor connection
- Defective sensor cable: short circuit or line open

4: Analog output: wrong connection: Fault at the connection of an analog output. Possible cause is an open current output or an overheated output driver, e.g. due to a short circuit of a voltage output. An unconnected current output (**open current output**) is interpreted as an error, the output channel is mentioned under **details (... at channel...)**

5: Digital output: Wrong connection: Short **circuit** on a digital output (DIO no), which is mentioned in **details**. The cause can also be that an output has been connected to a DIO configured as an output (**level collision**)

Flags (hex) are information about channel or I/O numbers that are defined differently for each error number and documented in the log description.

With *Save to File*, the error memory content can be exported to a text file, which has the name FaultMemory.log by default. It contains a header that specifies, among other things, the current operating hours (**device working hours**) and a line for each entry. For example, the error memory shown above yields the following file header and the first line:

Fault memory saved from BX8 Ser.No: 16256044 Date: Wed, Jan 24, 2024 Time: 19:59 Device working hours: 4895:5

No/age	Fault type no / Kind of fault	Occurred at working hours [H:MM]	Flags (Hex)	Details
1	2: Sensor maximum exceedance	4231: 9 8	663:56	before now, a multidimensional sensor maximum exceedance occurred. at physical channels: 4

With *Erase Fault Memory*, the error memory can be erased by asking for the device password. **The deletion cannot be undone!**


By clicking on *Refresh*, errors that may have occurred can be reloaded. The BX8 stores new errors in a time interval of at least two minutes.

The log file of the error store is also part of the *Settings ArchiveS*. 25.

Hour meter of the BX8 and BX6BT

The BX8 and BX6BT have hour meter that counts the time the device is turned on. They appear in the *Administrator* tab under **Device working hours**. There are two counters: an absolute one that cannot be reset (**Total device working hours**) and one that can be set to 0

by the user, e.g. to check the duration of a specific measurement campaign. It is called **User device working hours** and is set to 0 by clicking on *Reset user device working hours / Clear*.



BSC2 Menu Language




For BSC2 amplifiers with keyboard and LCD menu, you can **set the language of the device menu** under Menu language of device (**English** or **German** = German).

Drift compensation with BSC2

Most sensors drift due to temperature changes. For some, this is well compensated, for others, such as strain indicators and individual strain gages, this is not always possible. For such cases, the BSC2 offers a drift compensation algorithm that compares the transient of the measured value (i.e. its temporal change/derivation) with a predefined threshold. Readings that change more slowly than this transient threshold are not output by the BSC2, but are stored internally. Measured values that change faster than this transient threshold are output, and the difference to the stored ("drifted") measured value is formed.

It is therefore crucial for the applicability of this drift compensation that the measured values of interest (the useful signal) immediately follow a rather rapid change.


You can access the Drift Compensation configuration dialog by clicking on the **Drift Compensation button** at the bottom right of the menu bar -> **Device** -> **Advanced Settings** -> **Value Mode**.



Configuration for drift compensation,

measurement data rate here 5/s

The transient threshold is given under **Threshold for Value Transient** in Slope in <unit> per 200ms **for a constant time interval of 200ms**. If the measurement data rate is less than 5/s, the transient is also specified under **Slope per Data Period** ($<1/\text{Measurement Data Rate}>$) ms per measurement data period, because this is then less than 200ms. In the picture on the left e.g. for 3/s.



Multiplying the **slope per 200ms** by 5 gives the change per second.

You activate drift compensation with **Drift Compensation enabled**. The measured value is then only output after a valid useful signal change, i.e. if the measured value changed faster than the transient threshold value. In addition, you can define a waiting period within which even rapid changes (e.g. vibrations) are ignored after a valid measured value. This is displayed under **Wait Time** in seconds; **Wait Counter** is a counter of this time at 200ms intervals. After detecting a valid reading, this time is waited until the current transient is compared with the transient threshold as described above.

Low measurement data frequencies <50/s are recommended for the use of drift compensation.


A typical application is an elongation indicator on a metallic pillar supporting a crane. The load lifted and dropped by the crane is to be measured. The pillar is subject to temperature fluctuations, which are noticeable as drift in the signal of the strain indicator. The pick-up and release of the load is much faster than the temperature drift, as long as the load does not fall below a certain minimum. First, test measurements without drift compensation are made in order to determine the useful signal transients and the optimal measurement data rate (s.p. 16, but you don't need a very high rate when testing here; approx. 10 Hz) and records them. In this example, the test measurements should include the recording and specification of minimum and maximum loads and, if necessary, different travel speeds. From the recording of the measurement, one can then determine the transient threshold

value and, if necessary, the waiting time (the latter e.g. from the time of oscillation due to the load change) in order to configure the drift compensation. Subsequently, further tests with compensation activated are recommended. Drift compensation can increase the measurement uncertainty somewhat.

Other Software Preferences

Here, previously uncovered settings are explained under Menu Bar -> **Options** -> Preferences **and** -> Default Settings.


In the initial configuration, when the measurement is started, the user is asked if he wants to record it. This question can be suppressed by activating the checkbox **Don't ask anymore and always perform selected action** for this message :



Depending on whether **Yes** for Record or **No** for Not Record is clicked, this will apply to any future click on **Start Measuring**. This behavior can also be configured in Menu Bar -> **Options** -> Preferences -> At Start Measuring:


If the Ask for recording the measuring data **checkbox** is **not** set, the question about recording is not asked at **Start Measuring**. Then you can go to **If not, do you always want to record the data?** Specify whether **Start Measuring** always records automatically (**Yes**) or not (**No**).

By the Closing the program the user is asked if he wants to save a session file if something has changed that is relevant to the session file (e.g. channels have been added or removed), see S. 14.



You can suppress this question by activating the checkbox **Don't ask anymore and always perform selected action** in this message . Depending on whether **Yes** for Save or **No** for Don't Save is clicked, this applies to any future program exit, but in any case it will only be saved if relevant information has been

changed. With automatic session saving, a file selection box opens at completion, in which the last session file is pre-selected. This behavior can also be **configured** in Menu Bar -> Options -> Preferences -> **When closing the program**:



If the checkbox **Ask for saving the session, if session data has changed** is **not** set, the question of saving when the program is terminated will not be asked. Then you can go to **If not, do you always want to save the session?** Specify whether to save after each relevant change (**Yes**) or never automatically (**No**).


If several strain gage amplifiers are integrated and they have different measurement data frequencies (which is not recommended), the user will be warned if the difference is greater than 5 when clicking on the Recorder Yt or XY tab:



If you activate the checkbox *Don't show this warning again*, this warning will no longer be displayed. This can also be configured with a checkbox under Menu Bar -> **Options** -> **Preferences** with *Warn if device data rates are different*.

Other settings in **Options->Preferences** concerning the XY recorder (p. 58), the **Single Value Display** (p. 30), the number of decimal places of measured values displayed (p. 32) and the time interval of reading measurement data from the amplifiers (p. 32).

Under Menu Bar -> **Options** -> **Default Settings** you can reset to the basic settings of the software.




If you click **Yt / XY recorder: Reset Graph Scaling**, currently (up to and including version 2.1) only the scales of both axes of the XY recorder and the Y-axis of the Yt recorder are reset. When you enter the corresponding index card, this comes into effect.

If you click **Reset all program settings to default values**, all software settings will be reset to the state they were in after installing BlueDAQ.

To do this, a query must be confirmed (**Are you sure to reset the program settings?**) and you will then be informed that the reset will only take effect after a restart of the program. The reset does not affect the settings of the amplifier hardware, but it cannot be undone.

Tools for Measurement Data Files TDMS Tools

The standard format for measurement data files, *.tdms, has been mentioned several times, e.g. S. 33. The -> File -> TDMS Tools menu bar opens a selection of different tools that can be used to perform special tasks and repairs on measurement data files.



With **Try to Fix File / Repair** you can try to repair a broken tdms measurement data file. There is no guarantee that this will succeed and it is also possible that parts of the data will be lost, but the rest will become readable again. Such a defective file can occur, for example, if the PC crashes during a

recording or if there was a power failure or BlueDAQ has been closed irregularly (e.g. by the Windows Task Manager). When trying to open such a file using the File Monitor, an error message appears.

After clicking on **Try to Fix File / Repair**, select the broken tdms file, it will then be saved under a different name, namely appending **_fixed** to the original file name.

Make **Compatible / Fix Group Name** makes a *.tdms file created by another program compatible with BlueDAQ so that it can be opened with the File Monitor. In tdms files, the channels are always assigned to groups and BlueDAQ expects a group named **Measuring values**. After clicking on **Make Compatible / Fix Group Name**, select the file you want to change. The first group of the file is renamed after confirmation by the user and its channels can then be viewed in the File Monitor, as long as they are regular measurement data. Attention: BlueDAQ does not rename this file up to and including version 2.1, but only changes it. Therefore, it is recommended that you manually rename the file before using **Fix Group Name**. As of version 2.2, **_changed** will be appended to the original filename.

Defragmentation/Defragment is used to defragment tdms files. This can be useful for very large files, because they can have some redundant entries, such as properties.

Assembling Master-Slave Files from BX6BT

The BX6BT supports the S. 14 hardware synchronization described. The recording of measurement data on the SD card (see p. 33) cannot, however, be synchronized in a trivial way for various reasons. The recording can and should be started via a hardware switch by configuring the digital input not used for master-slave (see p. 109 Type: **Trigger File Log**) and is wired, but the timing of when the recording will actually begin is somewhat uncertain.


However, the BX6BT supports a mechanism to mark two lines about 0.2 to 0.4 seconds after the start of recording a file in the master and slave devices at the same time. The master writes an M at the end of this line and the slave an S.

For example:


```
22/04/01,17:43:27.46500    -0.00423 2.10000 2.10000 -2.10000 -2.10000 -2.10000 19964.02930 M
22/04/01,17:42:27.18348    -0.00410 2.10000 2.10000 -2.10000 -2.10000 -2.10000 32014.39063 S
```

In this example, the two RTC clocks had a time difference of about 1 minute. You can minimize the time difference a bit by changing the RTCs of both BX6BT by clicking on Sync. as from S. 33 described, but they will still diverge somewhat.

To merge these two files, first click on **Merge and import Master/Slave txt files / Concatenate** in the **TDMS File Tools** and the following dialog will open:



With Add File, *you select* the files that belong together one after the other. One should be that of a master, which you can see by the X in the Master column. Then click on **Merge files** and select the destination directory for the measured value file in text format, which then contains all channels of both devices in adjacent columns and is time-composed. If necessary, measured values are omitted at the beginning and at the end in order to equalize the number of measurement lines. Then you can choose whether you want to convert this file to another one in tdms format. The channels of the master form the first columns, those of the slaves the others, whose channel names _1 and possibly _2 and so on are appended:




Troubleshooting

The following describes common problems, error messages, and possible solutions. Further tips can be found on the Me website, e.g. in the Knowledge base.

I. The device cannot be opened with Add Channel

In order to be able to open a device successfully, three pieces of information should be known and entered correctly:

- The device model, e.g. BSC2, BX8, BX6 serial or BX6CAN. Some smart sensors have a built-in digital amplifier, e.g. a BX6 CAN. The nameplate, data sheet or operating instructions should provide information.
- The COMport number. In many cases, there are only a few entries in the pull-down menu **COMport Number** of the **Add Channel** dialog and you can easily find the right one. Entries in



angle brackets, as shown here, are probably not correct. In rarer cases, the COMport number is known, but not in the list. Then you can enter them in the small number input element to the right of the pull-down menu. To find out an unknown COMport number, you can look in Windows Device Manager: click on the Windows icon in the Start bar, type Dev or type Device Manager in the search box on the taskbar and then open it.

It can contain entries such as "USB Serial Port", strain gage amplifiers with USB, or "BX-8 Communication", a BX8. "Serial-over-Bluetooth connection" or similar is the COMport of a Bluetooth device. To do this, however, it must already be coupled. If there is no serial over BT entry in the device manager, you have to pair the device. To do this, the power supply must be connected and it must be nearby, and the PC also needs a Bluetooth adapter. Then you can proceed as follows: here, select the Windows version at the top and proceed as under "How to pair a [...] other device". If that doesn't work or the strain gage amplifier can't be found: Windows 11 needs to set Device Discovery to Advanced be provided. To do this, select "Show more devices" in the Bluetooth settings. The assigned COMport number can also be seen under "More Bluetooth options", where "Outgoing" is the correct port.

- The baud rate (bit rate). For most serial ports, it must be selected correctly, see S. 95

If the device fails to be opened, an error message often appears. Here is the breakdown of the most common messages:

- **Error 2 occurred ... or:**
Error 536870914 occurred at ... Possible reason(s): OS reported Error 2: Port or file not found.
Windows returns this error message (File not found), most of the time the COMport number is wrong see above.
- **Error 5 occurred ... or:**
Error 536870917: Windows returns this error message (Access denied), usually the COMport is already open by another program.
- **Error 121 occurred ...** Windows returns this error message. If it's a Bluetooth device, the battery could be low or not plugged in. Error messages with the same text but different error numbers <2000 can also occur with a BT-COMport.

- *Error 805306456 occurred ... Possible reason(s): MEGSV86xx.DLL: Command response from device timed out.* The BX6/BX8 API returns this error message. Or: *MEGSV4.dll Error: No answer from strain gage amplifier* Or: *Error 805306612 ... Possible reason(s): MEGSV.DLL: Com port could be opened, but no strain gage amplifier answered.* The BSC2/BSC13 API returns this error message. The COMport could be opened, but no strain gage amplifier answered. Possible causes:
 - The strain gage amplifier is not properly powered
 - A USB converter cable (if used) is defective or incorrectly connected on the UART or strain gage amplifier side
 - An RS232 cable (if used) is defective or incorrectly connected
 - The baud rate is incorrect, see above and S. 95
 - The baud rate is correct but is not supported by the USB converter (if used) or other interface converters or converters or are not configured accordingly (e.g. Moxa for Ethernet).
 - There is a different strain gage amplifier model connected to the COMport than the one set under Device Type, or a completely different device or no device at all is connected
 - BX8 over UART: The UART interface used in the BX8 is switched off, see S. 95

2. There are no readings


This problem also occurs if only one of the strain gage amplifiers is not transmitting any readings. BlueDAQ expects a measurement data stream from all open strain gage amplifiers. Often, *timeout is displayed* in the measured value display of the **Configuration** tab. displayed inses:

- The device is configured as a synchronization slave, see p. 14. If the strain gage amplifier is to be operated as a stand-alone device without a master, it should be None of the Digital IOs as **Sync Slave** be configured; If necessary, this should be **GPinut** s. S. 109
If it is to be operated together with a master, it must be properly configured and connected to the slave with a sync line.
- The permanent transmission of measurement data is switched off, see S. 98
- The set measurement data rate is too high, see S. 16
- Communication has been interrupted in the meantime. Tips on how to do this on S. 108. The cause can be, for example, a disconnected interface cable or a poor BT radio connection.

3. The measured values run slowly and jerkily in the graphical display

This is usually just a display problem, i.e. data is only lost in extreme cases and the timestamps are correct. Possible causes:

- The measurement data rate is set unusually low (e.g. 1/s), see p. 16. The BSC2 or BSC1 may be set to slow mode. To change, simply increase the measurement data rate.
- Driver setting unfavorable. With the following strain gage amplifiers with USB: BSC2TSD-DI, BSC1USB, BSC4DUSB or BX6Dev, you can shorten the waiting time of the buffer of the FTDI interface driver. To do this, open the Device Manager (see 1.) and right-click on the corresponding COMport entry and select "Properties", then Connection Settings and click "Advanced". Then set the waiting time to 1ms in the following dialog, confirm everything with OK and restart the PC if necessary.



- The PC is very busy. To find out which program is slowing down your PC, you can hold down the Ctrl and Alt keys at the same time, then press Delete and then select the Windows Task Manager. In it, open the Processes tab and sort by CPU so that the top one shows the highest CPU load. Consider closing this process. If it is BlueDAQchannel that requires the high CPU load and perhaps also a lot of RAM, this can be normal with many measurement channels and high measurement data rates. MathChannels, in particular, can require a lot of power (depending on the computational overhead). What can help:
 - Avoid opening the **Graph Display** tab, especially if there are more than 3 channels open. The many individual counts in this require more power than the **Yt recorder**. The Configuration tab requires the least amount of power.
 - Do not resize a window during the measurement. Window scaling requires performance, which is delayed and low-prioritized, but still temporarily takes away performance from the measurement task.
 - For **MathScript**: If possible, reduce the complexity of the script, e.g. summarize constants and reduce the number of operations. The **MathScript** parser does not perform any optimizations.
 - Remove channels you don't need (**Remove Channel**) or hide, see p. S. 16
 - Reduce the measurement data rate, see S. 16

4. When using multiple strain gage amplifiers, the readings are divergent in time.

Solution: Set the measurement data rate of all devices as equally as possible and, if possible, use the master-slave synchronization, see p. 14

5. Deleting data from a graphical chart

The **recorder Yt** stores a history, i.e. "behind" the left edge there is still measurement data stored in the graph. This has a constant depth of data packets. If **Autoscale X is** selected, it can happen that data falls out after a certain time; something similar can also happen in **Recorder XY** at high measurement data frequencies or very long recording times. The following can help:

- Increasing the acquisition interval, see S. 32
- Recording of the measured values (**start recording**) and subsequent evaluation instead of live evaluation
- In **Recorder XY**: Use of the trigger function, if possible, see S. 56

6. Attempting to change a configuration setting in strain gage amplifiers fails

If you get an error message when trying to change a device setting (yellow control) or if you don't read it as expected when you read it again, but it is unchanged, this can have various causes. For the BX6 and BX8, one of the following error messages is usually displayed; however, the causes and solutions described may also apply to the BSC2 and BSC1:

- **Error 939524213 occurred ... Possible reason(s): Device: Access from this port denied (other port seems to have write access):** Another interface has the Writing rights and the one with which the device has just been opened must not change any operating parameters. This other interface can be another serial one (e.g. UART on BX8) or CANopen at BSC2 and BX8-CAN or BX8 EtherCAT. With CANopen, you can switch off the CAN interface as a remedy (see p. 98 or use a CANopen master program to put the device in the stopped state. With EtherCAT, you can restart the BX8 with the EtherCAT interface disconnected or put it in the INIT state; in both cases, the green LED on the device must be off.
- **Error 939524209 occurred ... Possible reason(s): Device: Access denied, because write functions are blocked:** The general Write protection is enabled. This state can also be activated in BSC2 and BSC1, see p. 28
- **Error 939524183 ... Possible reason(s): Device: Parameter too big in relation to other parameters / Settings:** The parameter is too large, possibly in relation to other parameters. Often when setting the measurement data rate.
- **Error 939524180 ... Possible reason(s): Device: Parameter absolutely too big:** The parameter is absolutely too big.
- **Error 939524181 ... Possible reason(s): Device: Parameter absolutely too small:** The parameter is absolutely too small.


- *Error 939524188... Possible reason(s): Device: Parameter improper with respect to device settings:* The parameter is inappropriate due to other device settings.


7. Readings are not within the expected range

If a reading has a significant deviation at a known test load on the sensor or does not show zero at no-load, it can have many causes.

First of all, you should work at zero load *Set Zero* or *Set All Zero* execute (see p. 84) and then apply a test load. If the result deviates significantly from the expected value, the following can be checked:

- Is the correct calibration matrix configured for multi-axis sensors? s. S. 39
- Is a common sensor configured correctly? s. S. 8
- If the measured value is in saturation, i.e. it does not increase even when the load is increased, then the input measuring range may be too small, see p. 7. In this case, you typically see an error message when using BX6 or BX8 **Sensor Fault!** which appears at the top.

 If you click on it, a saturation error Input *raw measuring value saturated* is displayed, e.g.



8. The readings are unstable

There is slow instability, which is called drift. The readings then typically travel in one direction. The most common cause is temperature changes, and the amplifier and sensor also drift after being switched on. Therefore, you should wait about 20 minutes to an hour after switching on until the sensor and amplifier have reached their operating temperature.

If the sensor is temperature drifting and the BSC2 is used, drift compensation may be used, see p. 126.

Rapid instability is most often caused by the noise of the amplifier or disturbances, namely electrical EM disturbances or unwanted mechanical vibrations. This can be remedied, for example, by better shielding of the cables, better power supply or lower measurement data rate, see S. 16.

9. Problems with data evaluation with TDMS files

If information about the acquisition of the measurement data is unknown, such as the display scaling or the measurement data rate, it can be found by typing in the *File Monitor* into the index card *Properties* Changes. To do this, select the group on the left side of the tree view *Measuring Values* or the channel. In Appendix B on p. 139 are the *Properties* listed.

If a TDMS file cannot be opened, an error message appears, or the measurement data is or appears to be incomplete, the data set to S. 129 repair tools described above.

Appendix A: Hotkeys

If BlueDAQ has the keyboard focus, you can trigger functions with the following keyboard combinations:

Keyboard shortcut	Path of the menu bar	Meaning
Ctrl o	File->Open Session	<i>Open Session</i>
Ctrl s	File->Save Session	<i>Save Session</i>
Ctrl t	File->Open File Monitor	<i>Open File Monitor</i>
F1	File->Start Recording Yt	Start recording with <i>Recorder Yt</i>
F2	File->Start Recording XY	Start Recording with <i>Recorder XY</i>
F3	File->Stop Recording	Stop Recording
Ctrl q	File->Quit	Close program
Ctrl n	View->Configuration	Switch to <i>Configuration</i> Flashcard
Ctrl y	View-> Yt Recorder	Switch to <i>Recorder Yt</i> Flashcard
Ctrl x	View-> XY Recorder	Switch to <i>Recorder XY</i> Flashcard
Ctrl d	View->Value Display	Switch to <i>Value Display</i> Flashcard
Ctrl +	View->Add Graph Window...	Open a new graphical window
F4	Action->Start Measuring Yt	Start Measurement in Time Graph
F5	Action->Start Measuring XY	Start Measurement in XY Diagram
F6	Action->Stop Measuring	Stop Measurement
F8	Action->Enable Trigger Paste	Enable triggered pasting into another program
F9	Action->Disable Trigger Paste	Disable triggered pasting into another program
F10	Action->Enable / Disable value Paste by F-Key	Enable/disable pasting into another program
F11	Action->Append values to clipboard	Append readings to clipboard
F12	Action->Copy values to clipboard	Paste Readings to Clipboard
Ctrl a	Action > Set All Zero	Zeroing All Channels
Ctrl l	Device->Load Settings...	Load device settings
Ctrl e	Device->Save Settings...	Save device settings
Ctrl f	Device->Frequency...	Changing the Measurement Data Rate
Ctrl Image↑	Channel >Next	Increase Display Channel
Ctrl Image↓	Channel->Previous	Decrease the displayed channel
Ctrl z	Channel >Zero	Set Displayed Channel Zero
Spacebar	-	Retrieve a single measured value from your device (send command GetValue)

Appendix B: TDMS Properties

With the recorded TDMS files, properties are saved, which can be displayed in the File Monitor. Here is a list of all the *properties*.

Name	Description / Contents	Data type	Condition/Sensor/File Type
1. At group level, i.e. in <i>Measuring values</i>			
File Type	"Standard" / "Raw data"	String	All
Diagram Type	"Yt"/"XY" chart type	String	All
Program Version	BlueDAQ version used to create this file	String	All
Start Mode	Method of starting the measurement	String	All
Finish Mode	Method of starting the measurement	String	All
Decimation	About Software Decimation	String	All
AnnotationNum	Number of notes	Int	Only if available
AnnotName<0..N>	Note text	String	Only if available
AnnotVals<0..N>	In-program encoding of additional note information	String	Only if available
2. At the channel level			
Final Time	Termination Time	Time Stamp	All of them, but only available in the 1st channel
DT Mode	Timestamp calculation method for <i>wf_increment</i> "tf": start, stop time, and value count "1/f0" Device Measurement Data Rate "user": User-defined time increment	String	All of them, but only available in the 1st channel
ToffsetUTC	Time zone: Offset to UTC, in hours	Double	All of them, but only available in the 1st channel
ChannelType	Input type:"analog": Analog input"counter": Counter/Frequency", "Longitude": GPS/GNSS Geocoordinates"Altitude" GNSS Height of geoid in m"Speed" GNSS speed in km/h"UTC time" UTC time of GNSS/GPS" Math " Computed MathChannel (MathScript)	String	All
NI_ChannelName	Channel Name	String	All
NI_DataType	Encoded data type of content (=10)	Int	All
NI_ChannelLength	Total number of readings per channel	Int	All

Name	Description / Contents	Data type	Condition/Sensor/File Type
NI_UnitDescription	Unit	String	All
wf_start_time	Acceleration time	Time Stamp	All
wf_increment	Time increment in seconds	Double	All
wf_samples	Number of readings in the last data packet	Int	All
wf_start_offset	Start offset, always =0	Double	All
InputNo	Amplifier input channel	Int	All
Serialnumber	Serial number of the amplifier or MathScript No.	Int	All
DevComNo	COM port or device number	Int	All
Color	RGB value of channel color	Int	All
DeviceType	Amplifier Model Name	String	All
Frequency	Set measurement data rate of the amplifier	Double	All
Scaling	<i>user scaling</i> or hardware-calculated multi-axis sensors. Measuring range	Double	All
name	Channel name (Unique identifier!)	String	All
unit_string	Unit	String	All
Axis	Plot axis mapping "X"/"Y"	String	XY only
PhysicalName	Default name, e.g. "Com1_1"	String	Raw File
SensorIndex	Index of the multi-axis sensor in the sensor array	Int	Raw File
Emodul	Elasticity Module	Double	Rosette Measurement
Poissons	Transverse Contraction Number	Double	Rosette Measurement
GageFactor	K-Factor of Strain Gauge	Double	Rosette Measurement
InSens	Input Sensitivity of Measurement Amplifier	Double	Rosette Measurement
SpecialSensor	"Multi-dimensional/Six-Axis/RosetteStress"	String	Raw File
CalculationInput	Multi-dimensional: "Component1-6"	Int	Raw File
SensorTypeNo	Type of multi-axis sensor / calculation	Int	Multi-axis sensor (SW)
SensorSerNo	Sensor Serial Number	Int	Multi-axis sensor (SW)
GeoOffsetX	Geometric distance in m, X-direction	Double	Multi-axis sensor (SW)
GeoOffsetY	Geometric distance in m, Y direction	Double	Multi-axis sensor (SW)
GeoOffsetZ	Geometric distance in m, Z-direction	Double	Multi-axis sensor (SW)
SensorPath	Sensor calibration data file path	String	Multi-axis sensor (SW)
MadeFromChan	For additional file Max/Min/Average: Source channel	Int	Max/Min/Mean Channel

Name	Description / Contents	Data type	Condition/Sensor/File Type
MscriptPath	Path to MathScript that created this channel	String	Math channels
InType	Input Type (Device-Dependent Enumerator)	Int	All
InRange	Analogue input range	Int	All
HW-Sync	Hardware Synchronization: "Master"/"Slave"	String	When using HW-Sync

Proof of change		
Version	Status	Processor
00.00.01	Initiated	HK, SW

Interface is the world's trusted leader in technology, design and manufacturing of force measurement solutions. Our clients include a "who's who" of the aerospace, automotive and vehicle, medical device, energy, industrial manufacturing, test and measurement industries.

Interface engineers around the world are empowered to create high-level tools and solutions that deliver consistent, high quality performance. These products include load cells, torque transducers, multi-axis sensors, wireless telemetry, instrumentation and calibration equipment.

Interface, Inc., was founded in 1968 and is a US-based, woman-owned technology manufacturing company headquartered in Scottsdale, Arizona.