

Instructions for BlueDAQ Software Upgrade

1. Uninstall

Please uninstall previous versions of Interface BlueDAQ Software and all National Instruments Software Components, (except the Excel Add-on) first.

Please notice:

You will need to uninstall components by National Instruments or other programs which require these components.

2. Installation

Unzip the downloaded zip file to any directory. Then execute the setup by double-clicking setup.exe in that directory

System Requirements

- Windows Server 2003 and following
- Windows 7
- Windows Vista
- Windows 10

Hardware Requirements

Processor with SSE2 extension (all computers not older than 5 years with one of the Windows operation systems mentioned, also Netbooks, Notebooks, Tablet-PCs, ...)

Screen

Minimum resolution: 800 x 600